



Symbol MT2070/MT2090

Integrator Guide



Symbol MT2070/MT2090
Integrator Guide

72E-117858-03

Revision A

October 2009

© 2009 by Motorola, Inc. All rights reserved.

No part of this publication may be reproduced or used in any form, or by any electrical or mechanical means, without permission in writing from Motorola. This includes electronic or mechanical means, such as photocopying, recording, or information storage and retrieval systems. The material in this manual is subject to change without notice.

The software is provided strictly on an “as is” basis. All software, including firmware, furnished to the user is on a licensed basis. Motorola grants to the user a non-transferable and non-exclusive license to use each software or firmware program delivered hereunder (licensed program). Except as noted below, such license may not be assigned, sublicensed, or otherwise transferred by the user without prior written consent of Motorola. No right to copy a licensed program in whole or in part is granted, except as permitted under copyright law. The user shall not modify, merge, or incorporate any form or portion of a licensed program with other program material, create a derivative work from a licensed program, or use a licensed program in a network without written permission from Motorola. The user agrees to maintain Motorola’s copyright notice on the licensed programs delivered hereunder, and to include the same on any authorized copies it makes, in whole or in part. The user agrees not to decompile, disassemble, decode, or reverse engineer any licensed program delivered to the user or any portion thereof.

Motorola reserves the right to make changes to any software or product to improve reliability, function, or design.

Motorola does not assume any product liability arising out of, or in connection with, the application or use of any product, circuit, or application described herein.

No license is granted, either expressly or by implication, estoppel, or otherwise under any Motorola, Inc., intellectual property rights. An implied license only exists for equipment, circuits, and subsystems contained in Motorola products.

MOTOROLA and the Stylized M Logo and Symbol and the Symbol logo are registered in the US Patent & Trademark Office. Bluetooth is a registered trademark of Bluetooth SIG. Microsoft, Windows and ActiveSync are either registered trademarks or trademarks of Microsoft Corporation. All other product or service names are the property of their respective owners.

Motorola, Inc.
One Motorola Plaza
Holtsville, New York 11742-1300
<http://www.motorola.com/enterprisemobility>

Patents

This product is covered by one or more of the patents listed on the Web site:
<http://www.motorola.com/enterprisemobility/patents>.

Warranty

For the complete Motorola hardware product warranty statement, go to:
<http://www.motorola.com/enterprisemobility/warranty>.

Revision History

Changes to the original manual are listed below:

Change	Date	Description
-01 Rev A	8/2009	Initial Release.
-02 Rev A	9/2009	Final engineering review.
-03 Rev A	10/2009	Tumble tech spec update.

Table of Contents

Patents.....	ii
Warranty	ii
Revision History	iii

About This Guide

Introduction	xiii
Documentation Set	xiii
Configurations.....	xiv
Cradle Configurations	xiv
Chapter Descriptions	xv
Notational Conventions.....	xv
Related Documents	xvi
Service Information.....	xvii

Chapter 1: Getting Started

Introduction	1-1
Unpacking	1-1
MT20X0	1-1
Cradles	1-1
STB2000-C10007R Single Slot Charge Only	1-1
STB2000-F10007R Forklift Single Slot Charge Only	1-1
STB2078-C10007WR Single Slot Multi-interface Bluetooth	1-2
STB2000-C40007R Four Slot Charge Only	1-2
STB2000-C40017R Four Slot Ethernet	1-2
SAC2000-4000CR Four Slot Spare Battery Charger	1-2
Accessories	1-2
Features	1-3
Keypad	1-4
Keypad Modes	1-6
Numeric Mode	1-6
Alphabetic Mode	1-6
Function Key Mode	1-6
ALT/CTRL Plus Character	1-6

Keypad Mapping	1-7
Host Interfaces	1-11
Quick Startup	1-12
Insert the Battery	1-12
Battery Charging	1-13
Charging LEDs	1-14
Start Up	1-14
Resetting	1-15
Performing a Warm Boot	1-15
Performing a Cold Boot	1-15
Waking the Device	1-16
Li-ion Battery Removal	1-16
Customizing the Device Startup Program	1-17
Spare Battery Charging	1-17
Lanyard	1-17

Chapter 2: Accessories

Introduction	2-1
Cradles	2-1
Battery Charger	2-1
Cables	2-2
Intellistand	2-2
Other Accessories	2-2
Unpacking	2-2
Single Slot Cradles	2-3
Configurations	2-3
Cradle Features	2-4
Front View and Connections	2-4
Back View	2-5
Mounting Cups	2-6
Cradle Accessories	2-6
Supplying Power to the Cradle	2-7
Using the USB Interface to Supply Power	2-7
Connecting the STB20XX Cradle	2-7
Battery Charging in the Cradle	2-8
Changing the Host Interface	2-8
Communication	2-8
Sending Data to the Host Computer	2-8
LED Indicators	2-9
Miscellaneous LED Indicator Information	2-9
Mounting	2-10
Horizontal (Desk) Mount	2-10
Vertical (Wall) Mount	2-10
Forklift Single Slot Charge Only Cradle	2-13
Attach the Mounting Bracket	2-13
Mounting the STB2000-F on the Forklift	2-14
Four Slot Cradles	2-15
Configurations	2-15
Accessories	2-15

Cradle Features	2-16
Front	2-16
Back	2-17
Four Slot Charge Only Cradle Connections	2-17
Ethernet Cradle Connections	2-17
Daisy Chaining	2-18
Locating the Device IP Address	2-18
Mounting the Cradle on a Wall	2-19
Setting up the Cradle for Desktop Use	2-20
Inserting Devices and Batteries in the Cradle	2-21
Sending Data to the Host Computer	2-22
Charging	2-22
LED Indicators	2-22
Four Slot Battery Charger	2-23
Accessories	2-23
Battery Charger Features	2-23
Front	2-23
Back	2-24
Mounting	2-24
Inserting Batteries	2-25
Charging Batteries	2-25
LED Indicators	2-25
Troubleshooting	2-26
Wall Mount Templates	2-26

Chapter 3: ActiveSync

Introduction	3-1
Setup	3-1
Installing ActiveSync	3-2
Setting Up an ActiveSync Connection on the Host Computer	3-2

Chapter 4: Software Installation on Development PC

Introduction	4-1
Required System Configurations	4-2
DCP for MT2070/MT2090	4-2
Installing	4-2
Components	4-3
Platform SDK	4-4
Enterprise Mobility Developer Kit	4-5
Installing Other Development Software	4-5

Chapter 5: Software Installation on the MT20X0

Introduction	5-1
ActiveSync	5-1
Updating the Operating System	5-3
Using IPL	5-3
Using ActiveSync	5-3
Using Airbeam	5-3
Adding Programs	5-4
IPL	5-4

Chapter 6: Creating/Loading Hex Images

Introduction	6-1
Starting Terminal Configuration Manager	6-2
Defining Script Properties	6-4
Creating the Script for the Hex Image	6-5
Opening a New or Existing Script	6-5
Updating TCM 1.X Scripts	6-5
Copying Components to the Script	6-5
Saving the Script	6-5
Building the Image	6-6
Downloading the Hex Image	6-7
Using a USB Connection	6-7
TCM Error Messages	6-10
IPL Error Detection	6-11
Creating a Splash Screen	6-14
Splash Screen Format	6-14
Flash Storage	6-14
FFS Partitions	6-14
Working with FFS Partitions	6-15
Non-FFS Partitions	6-16
Downloading Partitions to the Device	6-16
IPL	6-17
Partition Update vs. File Update	6-17
Upgrade Requirements	6-17

Chapter 7: Wireless Applications

Introduction	7-1
Signal Strength Icon	7-2
Turning Off the Radio (MT2090 only)	7-3
Find WLANs Application	7-4
Profile Editor Wizard	7-5
Profile ID	7-5
Operating Mode	7-6
Ad-Hoc	7-7
Authentication	7-8
Tunneled Authentication	7-9
User Certificate Selection	7-11
User Certificate Installation	7-11

Server Certificate Selection	7-12
Credential Cache Options	7-13
User Name	7-15
Password	7-15
Advanced Identity	7-16
Encryption	7-16
Key Entry Page	7-18
Passkey Dialog	7-18
IP Mode	7-19
IP Address Entry	7-19
Transmit Power	7-21
Battery Usage	7-22
Manage Profiles Application	7-23
Changing Profiles	7-24
Editing a Profile	7-24
Creating a New Profile	7-24
Deleting a Profile	7-24
Ordering Profiles	7-24
Export a Profile	7-24
Wireless Status Application	7-25
Signal Strength Window	7-26
Current Profile Window	7-27
IPv4 Status Window	7-28
Wireless Log Window	7-29
Saving a Log	7-29
Clear the Log	7-29
Versions Window	7-30
Wireless Diagnostics Application	7-31
ICMP Ping Window	7-32
Trace Route Window	7-32
Known APs Window	7-33
Options	7-34
Operating Mode Filtering	7-34
Regulatory Options	7-35
Band Selection	7-35
System Options	7-36
Change Password Dialog Box	7-36
Export	7-37
Cold Boot Persistence	7-38
Registry Settings	7-39
Login, Log Off Application	7-40
User Already Logged In	7-40
No User Logged In	7-40
BTEplorer	7-42

Chapter 8: Staging and Provisioning

Introduction	8-1
Staging	8-1
RD Client Version 3.28	8-1
Bar Code Scanning	8-2
On-Demand Staging	8-4
ActiveSync Connection Mode	8-4
Ethernet Cradle Connection Mode	8-4
Already existing IP Connection Mode	8-4
Well-known WLAN Connection Mode	8-4
RD Client Main Menu	8-6
Client Info	8-6
Log Menu	8-7
View Log	8-8
View Job Log	8-8
Set Log Level	8-9
Set Job Log Level	8-9
Package List	8-10
Provisioning	8-11
MSP Agent	8-11
MSP Agent Main Menu	8-11
AirBEAM Smart Client	8-17
AirBEAM Package Builder	8-17
AirBEAM Smart Client	8-17
AirBEAM Smart Staging	8-25

Chapter 9: Maintenance and Troubleshooting

Introduction	9-1
Maintenance	9-1
MT20X0	9-1
Battery	9-2
Cradles	9-2
Troubleshooting	9-3
MT20X0	9-3
Single Slot Charge Only Cradle	9-6
Single Slot Charge Only Vehicle Mount	9-7
Single Slot Charge Multi-interface	9-8
Four Slot Charge Only Ethernet	9-10
Four Slot Charge Only Cradle	9-11
Four Slot Spare Battery Charger	9-12
Cables	9-13

Appendix A: Specifications and Electrical Interfaces

- Technical Specifications (Typical) A-1
 - MT20X0 A-1
 - Single Slot Charge Only Cradle A-4
 - Single Slot Charge Only Vehicle Cradle A-5
 - Single Slot Charge Multi-interface Bluetooth Cradle A-6
 - Four Slot Charge Ethernet Cradle A-7
 - Four Slot Charge Only Cradle A-8
 - Four Slot Spare Battery Charger A-9
- MT2000 Series Electrical Interface/Device Pin-Outs A-10
 - Device Interface to Cradle A-10
 - Device Interface to Cable A-11
 - Auxiliary Connection A-12

Index

Glossary

About This Guide

Introduction

This guide provides information about using the Symbol MT2070/MT2090 devices.



NOTE Screens and windows pictured in this guide are samples and can differ from actual screens.

Documentation Set

The documentation set for the Symbol MT2070/MT2090 devices provides information for specific user needs, and includes:

- **MT2070/ MT2090 Quick Start Guide** - describes how to get the device up and running (p/n 72-117308-xx).
- **MT2070/ MT2090 User Guide** - describes how to use the device (p/n 72E-117859-xx).
- **MT2070/ MT2090 Integrator Guide** - describes how to set up the device and accessories (72E-117858-xx).
- **Enterprise Mobility Developer Kit (EMDK) Help File** - provides API information for writing applications.

Configurations

Configuration	Radios	Display	Memory	Data Capture	Operating System	Keypads
MT2090-SL0D6 2170WR	802.11/Bluetooth	320x240 Color	64 MB RAM 64 MB Flash	1D, Standard Range, WW	Windows CE 5.0	21 key
MT2090-SD0D 62170WR	802.11/Bluetooth	320x240 Color	64 MB RAM 64 MB Flash	1D/2D, Standard Range	Windows CE 5.0	21 key
MT2090-HD0D 62170WR	802.11/Bluetooth	320x240 Color	64 MB RAM 64 MB Flash	1D/2D, High Definition	Windows CE 5.0	21 key
MT2090-DP0D 62170WR	802.11/Bluetooth	320x240 Color	64 MB RAM 64 MB Flash	DPM	Windows CE 5.0	21 key
MT2070-SL0D6 2370WR	Bluetooth	320x240 Color	64 MB RAM 64 MB Flash	1D, Standard Range, MCL	Windows CE 5.0	21 key
MT2070-SD0D 62370WR	Bluetooth	320x240 Color	64 MB RAM 64 MB Flash	1D/2D, Standard Range, MCL	Windows CE 5.0	21 key
MT2070-HD0D 62370WR	Bluetooth	320x240 Color	64 MB RAM 64 MB Flash	1D/2D, HD, MCL	Windows CE 5.0	21 key
MT2070-DP0D 62370WR	Bluetooth	320x240 Color	64 MB RAM 64 MB Flash	DPM, MCL	Windows CE 5.0	21 key
MT2070-SL1D6 2370WR	Bluetooth	320x240 Color	64 MB RAM 64 MB Flash	Standard Range, EAS, MCL	Windows CE 5.0	21 key
MT2070-SD0D 62370WR	Bluetooth	320x240 Color	64 MB RAM 64 MB Flash	1D/2D, Standard Range, EAS, MCL	Windows CE 5.0	21 key

Cradle Configurations

Cradle Configuration	Type	Radio
STB2000-C10007R	Single Slot, Charge Only	N/A
STB2000-F10007R	Single Slot, Charge Only, Vehicle Mount	N/A
STB2000-C10007WR	Single Slot, Charge, Multi-interface	Bluetooth
STB2000-C40007R	Four Slot, Charge Only	Bluetooth
STB2000-C40017R	Four Slot, Charge Only	Ethernet
SAC2000-4000CR charger	Four bay spare battery charger	N/A

Chapter Descriptions

Topics covered in this guide are as follows:

- [Chapter 1, Getting Started](#), provides information on charging the device battery, resetting and keypad.
- [Chapter 2, Accessories](#), describes the accessories available for the device and how to set up power connections and battery charging capabilities, where applicable.
- [Chapter 3, ActiveSync](#), provides instructions on installing ActiveSync and setting up a partnership between the device and a host computer.
- [Chapter 4, Software Installation on Development PC](#), provides information about Enterprise Mobility Developer Kit (EMDK) for C for both WinCE 4.2 and Win CE 5.0; Windows CE Platform SDK for MT2070/MT2090 or Windows CE 5.0 standard SDK; and, Device Configuration Package (DCP) for MT2070/MT2090.
- [Chapter 5, Software Installation on the MT20X0](#), provides information for downloading software and files to the device.
- [Chapter 6, Creating/Loading Hex Images](#), describes how to install and use the Terminal Configuration Manager (TCM) and Initial Program Loader (IPL) to customize flash file system partitions for the device.
- [Chapter 7, Wireless Applications](#), describes the Wireless Companion application.
- [Chapter 8, Staging and Provisioning](#), describes how to stage devices using Rapid Deployment and provisioning using MSP Agent or AirBEAM Smart.
- [Chapter 9, Maintenance and Troubleshooting](#), includes instructions on cleaning and storing the device, and provides troubleshooting solutions for potential problems during device operation.
- [Chapter A, Specifications and Electrical Interfaces](#), includes electrical specifications and tables listing the technical specifications for the device and accessories.

Notational Conventions

The following conventions are used in this document:

- *Italics* are used to highlight the following:
 - Chapters and sections in this and related documents
 - Screen or window names
 - Field names
- **Bold** text is used to highlight the following:
 - Key names on a keypad
 - Button names on a screen or window.
- bullets (•) indicate:
 - Action items
 - Lists of alternatives
 - Lists of required steps that are not necessarily sequential
- Sequential lists (e.g., those that describe step-by-step procedures) appear as numbered lists.



NOTE This symbol indicates something of special interest or importance to the reader. Failure to read the note will not result in physical harm to the reader, equipment or data.



CAUTION This symbol indicates that if this information is ignored, the possibility of data or material damage may occur.



WARNING! This symbol indicates that if this information is ignored the possibility that serious personal injury may occur.

Related Documents

The following documents provide more information about the MT2070/MT2090 devices.

- *MT2070/MT2090 Quick Start Guide* (p/n 72-117308-xx) - describes how to get the device up and running.
- *MT2070/MT2090 User Guide*, p/n 72E-117859-xx - describes how to use the device.
- *Symbol STB2000 Cradle Quick Reference Guide* (p/n 72-xxxxx-xx) - describes how to install and operate the cradles.
- *Symbol SAC2000 Cradle Quick Reference Guide* (p/n 72-xxxxx-xx) - describes how to install and operate the charger.

For the latest version of this guide and all guides, go to: <http://www.motorola.com/enterprisemobility/manuals>.

Service Information

If you have a problem with your equipment, contact Motorola Enterprise Mobility support for your region. Contact information is available at: <http://www.motorola.com/enterprisemobility/contactsupport>.

When contacting Enterprise Mobility support, please have the following information available:

- Serial number of the unit
- Model number or product name
- Software type and version number

Motorola responds to calls by E-mail, telephone or fax within the time limits set forth in support agreements.

If your problem cannot be solved by Motorola Enterprise Mobility Support, you may need to return your equipment for servicing and will be given specific directions. Motorola is not responsible for any damages incurred during shipment if the approved shipping container is not used. Shipping the units improperly can possibly void the warranty.

If you purchased your Enterprise Mobility business product from a Motorola business partner, contact that business partner for support.

Chapter 1 Getting Started

Introduction

This chapter provides information about the device, accessories, charging the device and resetting the device.

Unpacking

Carefully remove all protective material from around the equipment and inspect it for damage. If the equipment was damaged in transit, contact Motorola Enterprise Mobility Support. See [page xvii](#) for contact information. **KEEP THE PACKING.** It is the approved shipping container and should be used if the equipment ever needs to be returned for servicing.

MT20X0

Verify that the equipment listed below is included in the box:

- MT2070/MT2090 device
- Lithium-ion (Li-ion) battery
- Quick Start Guide.

Cradles

STB2000-C10007R Single Slot Charge Only

Verify that the equipment listed below is included in the box:

- Cradle with desk mount cup installed
- Wall mount cup
- Regulatory Guide.

STB2000-F10007R Forklift Single Slot Charge Only

Verify that the equipment listed below is included in the box:

- Cradle with forklift cup installed
- Metal mounting bracket with isolators
- Quick Reference Guide.

STB2078-C10007WR Single Slot Multi-interface Bluetooth

Verify that the equipment listed below is included in the box:

- Cradle with desk mount cup installed
- Wall mount cup
- Quick Reference Guide.

STB2000-C40007R Four Slot Charge Only

Verify that the equipment listed below is included in the box:

- Cradle with wall mount cups installed
- Quick Reference Guide.

STB2000-C40017R Four Slot Ethernet

Verify that the equipment listed below is included in the box:

- Cradle with wall mount cups installed
- Quick Reference Guide.

SAC2000-4000CR Four Slot Spare Battery Charger


Verify that the equipment listed below is included in the box:

- Charger
- Quick Reference Guide.


Accessories

See [Chapter 2, Accessories](#) for a list all accessories available for the MT2070/MT2090 devices.

Features



*** Note:** The accessory port is not available for use at this time. The device is not water sealed if the accessory port cover is removed.



WARNING! Never connect an Ethernet or phone cable to the host interface port.

Figure 1-1 MT2070/MT2090

Keypad



See [Table 1-1](#) for detailed information about the keypad.

Figure 1-2 MT2070/MT2090

Table 1-1 Keypad Functionality

Key	Default	Press Orange Key (For letter sequences, each letter represents a key press.)	Press Blue Key
	Left Soft Key, ALT	N/A	ALT
	Right Soft Key; CTRL	N/A	CTRL
	Up, Down, Left, Right	N/A	n/a
	Tab	N/A	Asterisk
	Backspace	N/A	ESC

Table 1-1 Keypad Functionality

Key	Default	Press Orange Key (For letter sequences, each letter represents a key press.)	Press Blue Key
	1	. , - /	F1
	2	abcABC	F2
	3	defDEF	F3
	4	ghiGHI	F4
	5	jklJKL	F5
	6	mnoMNO	F6
	7	pqrPQRS	F7
	8	tuvTUV	F8
	9	wxyzWXYZ	F9
	0	Space	Home Note: The <i>Home</i> key automatically loads the Navigator by default. This key can be programmed for other applications.
	Enter	N/A	N/A
	Orange	Press to enable the orange characters on the keypad (a filled orange circle ● displays on the device screen).	N/A
	Blue	N/A	Press once to display an empty blue circle ○ on the device screen. Press again to remove.

Keypad Modes

Numeric Mode

Numeric mode is the keypad default. When the keypad is *not* in CTRL, ALT or Alpha mode (i.e., the Orange key is not enabled), each numeric key represents its associated number and no multi-tapping a key is required.

Alphabetic Mode

The keypad goes into alphabetic (alpha) mode when the orange key is pressed and remains in alpha mode until the orange key is pressed a second time. A solid orange dot appears in the device display when alpha mode is active and disappears when it is turned off.

In this mode, multi-tapping a key generates the letters on the respective key; lower case letters first, followed by upper case letters. For example, in alpha mode the '2' key cycles through 'a', 'b', 'c', 'A', 'B', and 'C' depending on the number of taps.

Function Key Mode

The keypad goes into function key mode when the blue key is pressed. 'F' keys, displayed on the keypad in blue, are accessible in un-shifted mode only (when alpha mode is off). If the keypad is currently in alpha mode (an orange dot appears in the device display) and 'F1' is required, press the orange key to exit alpha mode and return to un-shifted mode; press the blue key; press the appropriate number key (e.g., press number '1' for 'F1', press number '2' for 'F2', etc.).

ALT/CTRL Plus Character

Some applications support shortcut keys (hot keys), such as ALT+F, CTRL+C.

To use shortcut key combinations:

1. In un-shifted mode, press the blue key one time.
2. Press the left soft key (ALT) or right soft key (CTRL).
3. Press the orange key to enter alpha mode.
4. Multi-tap the appropriate key to select the desired letter (e.g., multi-tap the '3' key three times to select lower case 'f').
5. Press the orange key again to exit alpha mode.

When the orange key is pressed the second time to exit alpha mode, the key combination generates (e.g., ALT+F). The blue key is automatically released after exiting the alpha mode.

Keypad Mapping

Table 1-2 Keypad Mapping

Key	DEFAULT	ALPHA STATE - ORANGE KEY ENBALED (KEY PRESS 1)	ALPHA STATE - ORANGE KEY ENBALED (KEY PRESS 2)	ALPHA STATE - ORANGE KEY ENBALED (KEY PRESS 3)	ALPHA STATE - ORANGE KEY DISBALED (KEY PRESS 4)	ALPHA STATE - ORANGE KEY ENBALED (KEY PRESS 1)	ALPHA STATE - ORANGE KEY ENBALED (KEY PRESS 5)	ALPHA STATE - ORANGE KEY ENBALED (KEY PRESS 6)	ALPHA STATE - ORANGE KEY ENBALED (KEY PRESS 7)	FUNCTION KEY - -BLUE KEY ENABLED	HEX-DECIMAL SCAN CODE VALUE
F1 . , - / 	SC_1KEY										0x02
		SC_PERIOD									0x34
			SC_COMMAKEY								0x33
				SC_MINUS							0x0c
					SC_FSLASH						0x35
										F1	0x3b
F2 2 A B C a b c 	SC_2KEY										0x03
		SC_AKEY									0x1e
			SC_BKEY								0x30
				SC_CKEY							0x2e
					SC_AKEY						0x1e
						SC_BKEY					0x30
							SC_CKEY				0x2e
									F2	0x3c	
F3 3 D E F d e f 	SC_3KEY										0x04
		SC_DKEY									0x20
			SC_EKEY								0x12
				SC_FKEY							0x21
					SC_DKEY						0x20
						SC_EKEY					0x12
							SC_FKEY				0x21
										F3	0x3d

Table 1-2 Keypad Mapping (Continued)

Key	DEFAULT	ALPHA STATE - ORANGE KEY ENBALED (KEY PRESS 1)	ALPHA STATE - ORANGE KEY ENBALED (KEY PRESS 2)	ALPHA STATE - ORANGE KEY ENBALED (KEY PRESS 3)	ALPHA STATE - ORANGE KEY DISBALED (KEY PRESS 4)	ALPHA STATE - ORANGE KEY ENBALED (KEY PRESS 1)	ALPHA STATE - ORANGE KEY ENBALED (KEY PRESS 5)	ALPHA STATE - ORANGE KEY ENBALED (KEY PRESS 6)	ALPHA STATE - ORANGE KEY ENBALED (KEY PRESS 7)	FUNCTION KEY - -BLUE KEY ENABLED	HEX-DECIMAL SCAN CODE VALUE
F4 4 GHI ghi 	SC_4KEY										0x05
		SC_GKEY									0x22
			SC_HKEY								0x23
				SC_IKEY							0x17
					SC_GKEY						0x22
						SC_HKEY					0x23
							SC_IKEY				0x17
									F4		0x3e
F5 5 JKL jkl 	SC_5KEY										0x06
		SC_JKEY									0x24
			SC_KKEY								0x25
				SC_LKEY							0x26
					SC_JKEY						0x24
						SC_KKEY					0x25
							SC_LKEY				0x26
									F5		0x3f
F6 6 MNO mno 	SC_6KEY										0x07
		SC_MKEY									0x32
			SC_NKEY								0x31
				SC_OKEY							0x18
					SC_MKEY						0x32
						SC_NKEY					0x31
							SC_OKEY				0x18
									F6		0x40

Table 1-2 Keypad Mapping (Continued)

Key	DEFAULT	ALPHA STATE - ORANGE KEY ENBALED (KEY PRESS 1)	ALPHA STATE - ORANGE KEY ENBALED (KEY PRESS 2)	ALPHA STATE - ORANGE KEY ENBALED (KEY PRESS 3)	ALPHA STATE - ORANGE KEY DISBALED (KEY PRESS 4)	ALPHA STATE - ORANGE KEY ENBALED (KEY PRESS 1)	ALPHA STATE - ORANGE KEY ENBALED (KEY PRESS 5)	ALPHA STATE - ORANGE KEY ENBALED (KEY PRESS 6)	ALPHA STATE - ORANGE KEY ENBALED (KEY PRESS 7)	FUNCTION KEY - -BLUE KEY ENABLED	HEX-DECIMAL SCAN CODE VALUE
F7 P Q R S p q r s 	SC_7KEY										0x08
		SC_PKEY									0x19
			SC_QKEY								0x10
				SC_RKEY							0x13
					SC_SKEY						0x1f
						SC_PKEY					0x19
							SC_QKEY				0x10
								SC_RKEY			0x13
									SC_SKEY		0x1f
										F7	0x41
F8 T U V t u v 	SC_8KEY										0x09
		SC_TKEY									0x14
			SC_UKEY								0x16
				SC_VKEY							0x2f
					SC_TKEY						0x14
						SC_UKEY					0x16
							SC_VKEY				0x2f
										F8	0x42
F9 W X Y Z w x y z 	SC_9KEY										0x0a
		SC_WKEY									0x11
			SC_XKEY								0x2d
				SC_YKEY							0x15
					SC_ZKEY						0x2c
						SC_WKEY					0x11
							SC_XKEY				0x2d
								SC_YKEY			0x15
									SC_ZKEY		0x2c
										F9	0x43

Host Interfaces

This device supports the following host interfaces through communication with a single slot multi-interface cradle:

- Standard RS-232 connection to a host.
- Keyboard wedge connection to a host, where scanned data is interpreted as keystrokes. The following international keyboards are supported (for Windows™ environment): North American, German, French, French Canadian, Spanish, Italian, Swedish, UK English, Japanese, and Brazilian-Portuguese.
- IBM® 468X/469X hosts.
- USB connection to a host. The device autodetects a USB host and defaults to the HID keyboard interface type. Select other USB interface types by scanning programming bar codes. Following is a sample of the supported international keyboards for a Windows™ environment: North America, German, French, French Canadian, Spanish, Italian, Swedish, UK English, Japanese and Brazilian Portuguese. For a complete list of the supported international keyboards, refer to the *MT2090/MT2070 User Guide* (p/n 72E-117859-xx).

✓ **NOTE** USB interface types can also be selected via the USB configuration menu on the device. To access the USB configuration menu from the device's *Home* screen, select *Config... > Configure USB*.

This device supports the following host interfaces without communication with a cradle:

- Standard RS-232 connection to a host.
- USB connection to a host via Bluetooth technology. The device autodetects a USB host and defaults to the HID keyboard interface type. Select other USB interface types by scanning programming bar codes. Following is a sample of the supported international keyboards for a Windows™ environment: North America, German, French, French Canadian, Spanish, Italian, Swedish, UK English, Japanese and Brazilian Portuguese. For a complete list of the supported international keyboards, refer to the *MT2090/MT2070 User Guide* (p/n 72E-117859-xx).

✓ **NOTE** USB interface types can also be selected via the USB configuration menu on the device. To access the USB configuration menu from the device's *Home* screen, select *Config... > Configure USB*.

Quick Startup

To get the MT2070/MT2090 up and running:

- Insert the rechargeable Li-ion battery
- Connect power to the cradle.
- Insert the device in the cradle.
- Charge the device.
- Configure the device.

Insert the Battery

The battery resides in a chamber in the device handle.

- ✓ **NOTE** If the battery is completely discharged, and the unit is powered from a USB or RS232 cable, it may take up to two hours for the unit to power up. There is no indication to the user of this condition and it may appear that the unit is not charging and/or not working correctly. However, if the unit is placed in an STB2000 cradle with the 12V power supply power up is immediate.

To insert the battery:

1. Insert the battery into the battery well, top first, ensuring that the battery connectors touch the device connectors inside the well.



CAUTION Avoid touching the contacts when positioning the battery.

2. Push down on the back of the battery until it snaps into place.




Figure 1-3 Battery Insertion

Battery Charging

- ✓ **NOTE** If the battery is completely discharged, and the unit is powered from a USB or RS232 cable, it may take up to two hours for the unit to power up. There is no indication to the user of this condition and it may appear that the unit is not charging and/or not working correctly. However, if the unit is placed in an STB2000 or STB2078 cradle with the 12V power supply power up is immediate.

Use the device's cradles, charge cables, and spare battery chargers to charge the device's Li-ion battery.

Before using the device for the first time, fully charge the main battery. (See [Table 2-2 on page 2-9](#) and [Table 2-7 on page 2-22](#) for charge status indications.)

A complete charge of a fully discharged battery can take up to four hours using external power and up to 10 hours using the interface cable.

Charge within the recommended temperature of 32° to 104° F (0° to 40° C) nominal, 41° to 95° F (5° to 35° C) ideal.

For information on maximizing battery life, refer to the *Symbol MT2070/MT2090 User Guide* (p/n 72E-117859-xx).

Use the following accessories to charge the Li-ion battery:

- Cradles:
 - Single slot charge only cradle with ActiveSync
 - Single slot multi-interface Bluetooth cradle
 - Four slot charge only cradle
 - Four slot charge/Ethernet cradle.
- Cables (and a power supply):
 - USB charge cable
 - RS-232 charge cable.
- Spare battery charger:
 - Four slot battery charger.

To charge Li-ion batteries use a cradle or a charge cable. The RS-232 charge cable requires both the charge cable and a Motorola approved power supply.

- Cradles

Insert the device into a cradle. The device starts to charge automatically. The charge LED lights to indicate the charge status. See [Chapter 2, Accessories](#) for accessory setup and charging indications.
- Cables

Connect a charge cable to the appropriate power source and connect the other end of the charge cable to the device. The device starts to charge automatically. The charge LED lights to indicate the charge status. See [Chapter 2, Accessories](#) for accessory setup and charging indications.

Charging LEDs

The device's green LED indicates charging activity when the device is seated in a cradle. Charge activity is also indicated by the charge icon on the device display screen.

If the device's red LED begins flashing, indicating a charging problem, remove the device from the cradle and replace the battery. If the red LED continues flashing, contact Motorola Enterprise Mobility Support.

Refer to the *Symbol MT2070/MT2090 User Guide* (p/n 72E-117859-xx) for device and cradle LED indicators.

Start Up

When the device is powered on for the first time, it initializes. The splash screen appears for a short period of time. If the device does not power on, see [Resetting on page 1-15](#).



Figure 1-4 *Splash Screen*

Resetting

If the device stops responding to input, reset it. There are two types of resets, warm boot and cold boot. A warm boot restarts the device by closing all running programs. All data that is not saved is lost.

A cold boot also restarts the device, but erases all stored records and entries from RAM. In addition it returns formats, preferences, and other settings to the factory default settings.

Perform a warm boot first. This restarts the device and saves all stored records and entries. If the device still does not respond, perform a cold boot.

Performing a Warm Boot

To perform a warm boot press and hold the 2 key and the scan trigger simultaneously for 5 seconds. During a warm boot the following three items display as text on the screen:

- IPL
- OS
- PM.



CAUTION Files that remain open during a warm boot may not be retained.

Performing a Cold Boot

A cold boot restarts the device and erases all user stored records and entries from RAM. *Never perform a cold boot unless a warm boot does not solve the problem.*



CAUTION A cold boot resets the device to the default settings and removes all added applications and all stored data. Do not cold boot without support desk approval.

To perform a cold boot press and hold the 2 key and the scan trigger simultaneously for 10 seconds. During a cold boot the following two items display as text on the screen:

- IPL
- OS.

Waking the Device

The wakeup conditions define what actions wake up the device. These settings are configurable and the factory default settings shown in [Table 1-3](#) are subject to change/update.

Table 1-3 Wakeup Conditions (Default Settings)

Status	Description	Conditions for Wakeup
Suspend	When the device is set to the suspend mode these actions wake the device.	AC power is added or removed. Cradle/cable connect or disconnect.
		Key or scan trigger press.
		Real Time Clock set to wake up.
Auto Off	When the automatic power-off function places the device in suspend mode these actions wake the device.	AC power added or removed. Cradle/cable connect or disconnect.
		Key or scan trigger press.
		Real Time Clock set to wake up.

Li-ion Battery Removal

To remove the Li-ion battery:

1. Select *Menu > Suspend* on the *Home* window to turn off the window and place the device in suspend mode.
2. With your thumb, press down on the indentation on the battery lock and drag it backwards.
3. Lift up the back of the battery and pull it out of the battery well.




Figure 1-5 Li-ion Battery Removal

Customizing the Device Startup Program

For information about customizing the Startup.run file to alter the default startup application refer to the MT2070/MT2090 User Guide, p/n 72E-117859-xx.



Spare Battery Charging

Use the Spare Battery charger to charge spare Li-ion batteries. See to [Chapter 2, Accessories](#) for more information on spare battery charging.

Lanyard

To attach the optional lanyard:

1. Insert the loop on the lanyard into the slot at the bottom of the device.
2. Thread the upper portion of the lanyard into the loop.



3. Pull the clip through the loop over the tether point and tighten into place.




Figure 1-6 Attaching the Lanyard

Chapter 2 Accessories

Introduction

The MT2070/MT2090 accessories provide a variety of product support capabilities. This chapter provides information about cables, single slot cradles, multi-slot cradles and the four slot battery charger.

Cradles

- STB2000-C10007R single slot charge only cradle (with ActiveSync) charges the device's Li-ion battery installed in the device. It also synchronizes the device with a host computer using ActiveSync through a USB connection.
- STB2078-C10007WR single slot multi-interface Bluetooth cradle charges the device's Li-ion battery installed in the device and, when the pairing bar code on the cradle is scanned, it pairs with the device allowing the device and cradle to exchange information. Refer to the *MT2090/MT2070 User Guide* (p/n 72E-117859-xx) for detailed information about pairing and Bluetooth technology.

✓ **NOTE** ActiveSync is not supported on this cradle.

- STB2000-F10007R forklift single slot charge only cradle charges the device's Li-ion battery installed in the device. The following accessories are not included but may be required: 9 Vdc, minimum 2A power supply for forklift configuration (Motorola p/n 50-14000-122R); three 1.25" #8 Phillips head screws (for wall mounting, if applicable, not available from Motorola).
- STB2000-C40007R four slot charge only cradle charges up to four spare batteries and up to four devices with batteries installed.
- STB2000-C40017R four slot Ethernet cradle charges up to four spare batteries and up to four devices with batteries installed. It also synchronizes up to four devices with a host computer through an Ethernet connection. An Ethernet cable is required for communication (not available from Motorola).
- SAC2000-4000CR four slot spare battery charger charges up to four single batteries.

Battery Charger

- Four slot spare battery charger charges up to four spare batteries.

Cables

The following cables can connect to the device or single slot cradles:

- USB Client Charge Cable
- RS-232 Serial Cable with Power Supply.

Intellistand

The Intellistand provides a hands-free method of scanning.

Other Accessories

- Lanyard
- Belt Holster.

Unpacking

Carefully remove all protective material from around the equipment and inspect it for damage. If the equipment was damaged in transit, contact Motorola Enterprise Mobility Support. **KEEP THE PACKING.** It is the approved shipping container and should be used if the equipment ever needs to be returned for servicing.

Single Slot Cradles

The Symbol STB2000-C10007R, STB2078-C10007WR and STB2000-F10007R cordless device cradles act as power pass throughs to the device and host communication interfaces for the Symbol MT2000 Series cordless devices. Cradles can sit on a desktop, mount on a wall or mount on a forklift (STB2000-F only). Any discussion of transmission of information refers specifically to cradles with Bluetooth technology.

- ✓ **NOTE** Use only a Motorola/Symbol approved power supply (50-14000-148R) output rated at 12 Vdc and minimum 3.3 A or DC to DC converter 50-14000-122R output rated at 9 Vdc and minimum 1.0 A.


Configurations

Table 2-1 *Single Slot Cradle Configurations*

Cradle Configuration	Description
STB2000	Single slot, charge only. Charge only cradles can communicate with a PC via ActiveSync by attaching a USB cable to the USB connector.
STB2078	Single slot, multi-interface with Bluetooth technology. Bluetooth cradles receive data from the device via a Bluetooth radio and send the data to the host through an attached cable. Note: ActiveSync is not supported on this cradle.
STB2000-F	Forklift single slot, charge only.

Cradle Features

Front View and Connections



✓ **NOTE** The functionality of the USB connection to a host PC varies by cradle type. For the single slot charge only cradle, the USB connection can be used with a device in the cradle for ActiveSync only. The charge only cradle LED does not light when powered off USB only.

Figure 2-1 Single Slot Cradle - Connections/Pairing Bar Code

Back View




Figure 2-2 Single Slot Cradle - Back

Mounting Cups




Figure 2-3 Single Slot Cradle - Mounting Cups

Cradle Accessories

The following equipment may be needed:

For the STB2000/STB2078 cradle:

- Power supply for desk/wall mounting configuration (p/n KT-14000-148R).
- If applicable two screws, depending on the surface, for wall mounting (not available from Motorola).

For the STB2000-F cradle:

- Mounting bracket (provided).
- Power supply for forklift configuration (p/n 50-14000-122R, provided).
- Three 8-32 x 1.25 in screws to fasten the cradle to the bracket (provided).
- Four screws to fasten bracket to mounting surface (not available from Motorola).

Supplying Power to the Cradle

The cradle receives power from one of two sources:

- An external power supply.
- When connected to the host through an interface cable that supplies power.

The cradle detects whether the host or the external supply is supplying power. It always draws power from the external supply when available, regardless of the presence of power from a host.

Using the USB Interface to Supply Power

When the cradle is connected to the host via the USB interface, the USB port can power the cradle so that an external power supply is not necessary. Note that powering from a USB host charges the device at a slower rate than when charging from an external power supply.

✓ **NOTE** It is recommended to use a 12V power supply to accelerate charge times.

Connecting the STB20XX Cradle



IMPORTANT Connect the interface cable and power supply (if necessary) in the following order to ensure proper operation of the device and cradle.

1. Insert the host interface cable into the cradle's host port.
2. Connect the other end of the host interface cable to the host.
3. If necessary, connect the appropriate cable to the power supply and an AC power source (if the interface requires, or to allow fast charging of the device).
4. If applicable, insert the power supply cable ferrite into the support features on the cradle bottom and run the host and power cables into their respective cable grooves.
5. For forklift cradles only, connect the forklift power supply to the cradle's power port, if applicable. Insert the power supply cable ferrite into the support features on the cradle bottom and run the host and power cables into their respective cable grooves, or use cable ties to secure them to the mounting plate after attaching it to the cradle. For more information about mounting options and procedures, refer to the documentation included with the cradle.
6. For Bluetooth cradles only, pair the device to the cradle by scanning the pairing bar code on the cradle.
7. If necessary, scan the appropriate host bar code (for non-autodetected interfaces). Refer to the specific host chapter in the *MT2090/MT2070 User Guide* (p/n 72E-117859-xx).

✓ **NOTE** Disconnect the power supply before changing host cables, or the device may not recognize the new host.

Different cables are required for different hosts. The connectors illustrated in each host chapter are examples only. The connectors may be different from those illustrated, but the steps to connect the device remain the same.

Battery Charging in the Cradle

Single slot cradles act as power pass throughs to the device allowing the device to charge the Li-ion battery in the device. A complete charge of a fully discharged battery can take up to four hours using external power and up to 10 hours using the interface cable.

- ✓ **NOTE** To charge the battery for your device, battery and charger temperatures must be between +32° F and +104° F (0° C to +40° C).

To charge the device:

1. Connect the single slot USB cradle to a power source.
2. Insert the battery into the battery slot in the device noting the battery polarity.
3. Insert the top of the device into the cradle first, then firmly press the device into place. The device's green charge LED indicates the device battery charging status.
4. When charging is completed, the green LED is off and the device can be lifted out of the cradle.

- ✓ **NOTE** If the battery is completely discharged, and the unit is powered from a USB or RS-232 cable, it may take up to two hours for the unit to power up. There is no indication to the user of this condition and it may appear that the unit is not charging and/or not working correctly. However, if the unit is placed in an STB2000 or STB2078 cradle with the 12V power supply power up is immediate.

Changing the Host Interface

To connect to a different host, or to the same host using a different cable:

1. Disconnect the power supply from the cradle, if applicable.
2. Disconnect the interface cable from the host.
3. Connect the interface cable to the new host, or the new interface cable to the existing host.
4. Reconnect the power supply, if required.
5. If necessary, scan the appropriate host bar code (for non-autodetected interfaces). Refer to the *MT2070/MT2090 User Guide* (p/n 72E-117859-xx).



CAUTION If the device does not recognize the host, disconnect the power supply, then reconnect after connecting the host cable.

Communication

Sending Data to the Host Computer

The STB2078-C10007WR single slot multi-interface Bluetooth cradle receives data from the device via a wireless radio connection and transmits it to the host computer via the host cable. The device and cradle must be paired for successful wireless communication. For detailed information about pairing, radio communications, Bluetooth technology and lost connections to the host computer, refer to the *MT2070/MT2090 Integrator Guide* (p/n 72E-117858-xx).

LED Indicators

Table 2-2 LED Charging Status Indicators - Single Slot Charge Only Cradles

LED	Indication
LED on Device	
Off	No power applied to device (battery discharged or removed); device is in low power and ready to scan; or, battery is fully charged and device is ready to scan.
Green Flash	Device is charging (when cradle is powered from external power supply).
Red Flash	Charging problem or data transmission problem.
LED on Cradle	
Off	Cradle is not powered or power fault on contacts.
Solid Blue	Cradle is powered.

Table 2-3 LED Charging Status Indicators - Single Slot Multi-interface Cradles

LED	Indication
LED on Device	
Off	No power applied to device (battery discharged or removed); device is in low power and ready to scan; or, battery is fully charged and device is ready to scan.
Green Flash	Device is charging (when cradle is powered from external power supply).
Red Flash	Charging problem or data transmission problem.
LED on Cradle	
Off	Cradle is not powered.
Solid Blue	Cradle is powered.
Red/Blue/Purple	Power up sequence.
Rapid Red/Blue/Red/Blue	Power fault on all contacts.

Miscellaneous LED Indicator Information

- Single slot charge only cradle (STB2000)
 - Blue LED is off when there is a USB connection but no external power supply is used.
- Single slot multi-interface Bluetooth cradle (STB2078)
 - Blue LED lights when there is a USB or keyboard wedge connection but no external power supply is used.

Mounting

Horizontal (Desk) Mount

1. The cradle is packaged with the horizontal mount desk cup installed. If it was replaced with the wall cup, remove the wall cup and reattach the desk cup.
2. Use a Phillips screwdriver to turn the *wall mount conversion dial* to the correct position for a horizontal/desktop mount.
3. Attach the appropriate cables.
4. Place the cradle on the desk to and insert the device.

Vertical (Wall) Mount

Replace the desk mount cup with the wall (vertical) mount cup:

1. Use a Phillips screwdriver to turn the *wall mount conversion dial* on the back of the cradle to the correct position for a vertical (wall) mount. The front latches protract to engage the depressions at the base of the device's handle.




Figure 2-4 Set Conversion Dial for Wall Mounting

2. Use a Phillips screwdriver to remove the screws on the back of the cradle.




Figure 2-5 Remove Back Screws

3. Use your fingers to squeeze and hold the cup release snaps while pulling the desk cup off.




Figure 2-6 Remove Desk Cup

4. Use a Phillips screwdriver to remove the screws on the front of the cradle. These screws are used to secure the wall mount cup to the cradle in [Step 6](#).




Figure 2-7 Remove Front Screws

5. Insert the wall mount cup into place.




Figure 2-8 Insert Wall Mount Cup

6. Using a Phillips screwdriver and the two screws removed from the cradle in [Step 4](#), screw the wall mount cup to the cradle.




Figure 2-9 Screw Wall Mount Cup Into Place

To mount the cradle:

1. Attach the interface and power cables to the appropriate ports (see [Figure on page 2-7](#)).
2. Insert the power supply cable ferrite into the support features on the cradle bottom and run the host and power cables into their respective cable grooves.
3. Position the cradle on the mounting surface and outline the mounting holes with a pencil, or use the mounting template on [page 2-27](#) to determine the location of the screw holes.
4. Pre-drill holes to accommodate two screws.
5. Attach the cradle key-holes to the screws and ensure the cradle hangs securely on the surface.
6. Place the device in the cradle.

✓ **NOTE** Ensure the device does not loosen from the wall during routine usage.

Forklift Single Slot Charge Only Cradle

The mounting bracket is used to install the STB2000-F cradle on a forklift.

Attach the Mounting Bracket

1. Use a Phillips screwdriver to turn the *wall mount conversion dial* on the back of the cradle to the correct position for a vertical (wall) mount. The front latches protract to engage the depressions at the base of the device's handle.




Figure 2-10 Attaching Forklift Mounting Bracket to Cradle

2. Attach the applicable cables to the appropriate ports (see [Connecting the STB20XX Cradle on page 2-7](#)).
3. Position the cradle with the screw holes in the cradle aligning with the holes in the isolators. Three isolators ensure secure attachment with minimized vibration. The bracket has holes that provide access to the host and power ports, and enable securing the cables with cable ties.
4. Attach the cradle to the bracket using three 8-32 x 1.25" Phillips screws through the cradle and isolator holes.

Mounting the STB2000-F on the Forklift

1. Consult an environmental health and safety manager to determine an appropriate mounting location within the recommended 15" reach envelope.




Figure 2-11 Forklift Reach Envelope

2. Mark the mounting surface through the four screw holes on the mounting bracket, or use the mounting template on [page 2-27](#) to determine the location of the screw holes.
3. Pre-drill holes into the mounting surface to accommodate four screws.
4. If desired, thread cable ties through the holes on each side of the bracket and secure the host and power cables along the edges of the bracket.
5. Attach the bracket to the mounting surface.
6. Place the device in the cradle.

Four Slot Cradles

The Symbol STB2000-C40007R four slot charge only and STB2000-C40017R four slot Ethernet cradle act as chargers and host communication interfaces for the Symbol MT2000 Series cordless devices and batteries. Cradles can sit on a desktop or be mounted on a wall. This document provides basic instructions for cradle set up and use. Unless otherwise noted, *cradle* refers to both configurations of the cradle. Any discussion of transmission of information refers specifically to the STB2000-C40017R four slot Ethernet cradle.

Configurations

Table 2-4 Single Slot Cradle Configurations

Cradle Configuration	Description
STB2000-C40007R	Four slot, charge only. Charges up to four devices and up to four spare batteries.
STB2000-C40017R	Four slot, Ethernet. Charges up to four devices and up to four spare batteries; synchronizes up to four devices with a host computer through an Ethernet connection (see Ethernet Cradle Connections on page 2-17).

Accessories

- Power supply (p/n 50-14000-241R) and DC cable (p/n 50-16002-029R) for desk/wall mounting configuration.

Optional:

- DC split cable (p/n 25-121355-01R); when daisy chaining, allows one power supply for two cradles.
- Four screws for wall mounting (not available from Motorola).

Cradle Features

Front




Figure 2-12 Four Slot Cradle - Front View




Figure 2-13 Four Slot Cradle - Back View

Four Slot Charge Only Cradle Connections

1. Connect the power supply to the cradle's power port.
2. If applicable, secure the cables into the cable well in the back of the cradle.
3. Connect the power supply to an AC power source with the appropriate AC line cord.

Ethernet Cradle Connections



IMPORTANT Connect the Ethernet cable and power supply (if necessary) in the following order to ensure proper operation of the device and cradle.

1. Insert the Ethernet cable into the cradle's primary Ethernet port.
2. Connect the other end of the Ethernet cable to the Ethernet hub.
3. Connect the power supply to the cradle's power port.
4. Connect the power supply to an AC power source with the appropriate AC line cord.
5. If desired, secure the cables into the cable wells in the back of the cradle.

Daisy Chaining

When daisy chaining Ethernet cradles:

1. Connect the power supply to the cradle's power port.
2. Connect the power supply to an AC power source with the appropriate AC line cord.
3. Insert the Ethernet cable into the primary Ethernet port of the first cradle in the daisy chain.
4. Connect the other end of the Ethernet cable to the Ethernet hub.
5. Insert an Ethernet cable into the first cradle's secondary port and connect the other end to the primary port of second cradle in the chain.
6. Insert an Ethernet cable into the second cradle's secondary port and connect the other end to the primary port of the third cradle in the daisy chain and continue until all cradles in the daisy chain are connected.
7. If desired, secure all cables into the cable wells in the back of each cradle.

✓ **NOTE** Each cradle in the daisy chain requires its own power supply, or use cable p/n 25-121355-01R which is a DC split cable allowing one power supply to be used for two cradles.

Bandwidth Considerations when Daisy chaining

Each cradle added to the daisy chain impacts the bandwidth allocated to each of the inserted devices, particularly when the devices attempt to send and receive at data rates that exceed the bandwidth provided to the chain (typically 100 Mbps). If a device in a daisy chained cradle does not use its bandwidth, that bandwidth is available to other inserted devices.

[Table 2-5](#) shows allocated bandwidth (based on 100 Mbps) for the number of daisy chained cradles, with each device attempting transmission at the maximum data rate.

Table 2-5 *Daisy chaining Bandwidth*

Daisy chained Ethernet Cradles	Bandwidth Allocation For Each Ethernet Cradle (bits/sec)	Bandwidth Allocation For Each Device (bits/sec)
Cradle 1	100,000,000	20,000,000*
Cradle 2	20,000,000	4,000,000
Cradle 3	4,000,000	800,000
Cradle 4	800,000	160,000
Cradle 5**	160,000	32,000
Cradle 6**	32,000	6,400
Cradle 7**	6,400	1,280

* The maximum bandwidth capacity for the device is 12,000,000 bits/sec.
 ** Depending on the application, allocated bandwidth may not be adequate.

Locating the Device IP Address

To locate the device IP address, go to the *Home* window on the device and select *Utilities > File Explorer > Windows > cmd.exe*. Press the *Enter* key to run *cmd.exe*, type *ipconfig* at the command prompt and press the *Enter* key.

Mounting the Cradle on a Wall

The four slot cradle ships from the factory with the four wall mount cups installed. To mount the cradle on a vertical surface:

1. Use a Phillips screwdriver to turn the wall mount conversion dial to point to the vertical cradle/device icon.




Figure 2-14 Wall Mount Conversion Dial - Wall Mount Position

2. The wall mounting latches in the cradle protract to engage the depressions at the base of the device's handle.
3. Attach the interface and power cables to the appropriate ports (see the *Connections* sections [on page 17](#)).
4. Secure the cables into the cable well in the back of the cradle.
5. Position the cradle on the mounting surface, or use the template included in the *User Guide*.
6. Mark the surface through the four holes on the bottom of the cradle, or use the mounting template to determine the location of the screw holes.
7. Pre-drill holes to accommodate four screws.
8. Attach the cradle securely to the surface.
9. Place the device(s) and/or batteries in the cradle.

Setting up the Cradle for Desktop Use

Remove the wall mount cups to use the four slot cradle on a desktop. Each wall mount cup is attached with two screws on the back of the cradle.

To mount the cradle on a horizontal surface:

1. Use a Phillips screwdriver to remove the two screws on the back of the cradle attaching each wall mount cup.




Figure 2-15 *Remove Screws*

2. Pull each wall mount cup out of the device well.




Figure 2-16 *Remove Wall Mount Cup*

- Use a Phillips screwdriver to turn the wall mount conversion dial to point to the horizontal cradle/device icon.




Figure 2-17 Wall Mount Conversion Dial - Desk Mount Position

- The wall mounting latches in the cradle truncate.
- Attach the interface and power cables to the appropriate ports (see the *Connections* sections [on page 17](#)).
- Secure the cables into the cable well in the back of the cradle.
- Place the cradle on a flat surface.
Optional: The cradle can be attached securely to the surface using the wall mounting holes. See [Mounting the Cradle on a Wall on page 2-19](#) for details.
- Place the device(s) and/or batteries in the cradle.

Inserting Devices and Batteries in the Cradle

When inserting the device in the cradle, insert the device top first. Push the handle until it clicks into place, engaging the contacts in the cradle and device.

When inserting batteries in the cradle, align the connectors on the bottom of the battery with the battery charging connectors in the cradle. Push down on the top of the battery until it clicks into place, engaging the contacts in the cradle.




Figure 2-18 Inserting Devices



NOTE When inserting the device in a wall mounted cradle, ensure the device's hook recesses engage the hooks on the wall mount adapter.

Sending Data to the Host Computer

MT2000 Series include Ethernet cradle drivers that initiate automatically when you place the device in a properly connected four slot Ethernet cradle. The cradle receives data from the device and transmits it to the host computer via the Ethernet cable.

Prior to inserting the device in the cradle, it is recommended that you turn off the device's wi-fi radio to avoid interference. To turn off the radio, go to the *Home* window on the device and select *Config > Wireless Companion > Disable Radio*.

Charging

To charge the battery in the device and/or a spare battery, ensure the correct power supply is connected then place the device/battery in the cradle (see [Inserting Batteries](#)). Charging begins when the LED indicators, on the device and in the cradle's spare battery section, start flashing green. A complete charge of a fully discharged battery can take up to four hours.

LED Indicators

Table 2-6 LED Charging Status Indicators - Device LEDs

LED Indicators	
Off	No power applied to device (battery discharged or removed); device is in low power and ready to scan; or, battery is fully charged and device is ready to scan.
Green Flash	Device is charging.
Red Flash	Charging problem or data transmission problem.

Table 2-7 LED Charging Status Indicators - Cradle LEDs

LED Indicators	
Solid Blue (Cradle Power LED)	Cradle is powered.
Ethernet Activity LEDs (Ethernet cradles only)	Speed LED (100/10) - Primary Port Connection The cradle's green Speed LED lights to indicate that the transfer rate is 100 Mbps. When it is not lit it indicates that the transfer rate is 10Mbps.
	Link LED () - Primary Port Connection The cradle's amber Link LED blinks to indicate activity, or stays lit to indicate that a link is established. When it is not lit it indicates there is no link.

Four Slot Battery Charger

The Symbol SAC2000-4000CR four slot spare battery charger charges up to four single spare batteries. The cradle can sit on a desktop or be mounted on a wall. This document provides basic instructions for cradle set up and use.

For best performance, fully charge the device battery before using the device for the first time. To charge the device battery, insert the battery in the cradle. The battery begins charging when the LED indicator on the battery charger starts flashing green. A complete charge of a fully discharged battery can take up to four hours. Charge within the recommended temperature of 32° to 104° F (0° C to 40° C) nominal, 41° to 95° F (5° to 35° C) ideal.

Accessories

- Four screws (for wall mounting, if applicable, not available from Motorola).
- Power supply for desk/wall mounting configuration (p/n 50-14000-148R).

Battery Charger Features

Front




Figure 2-19 Four Slot Battery Charger - Front




Figure 2-20 Four Slot Battery Charger - Back

Mounting

To mount the cradle on a vertical (wall) surface:

1. Connect the power cable to the power port and an AC power source.
2. Insert the power supply cable ferrite into the power cable ferrite well on the bottom of the cradle; run the power cable into the cable groove.
3. Use the mounting template beginning on [page 2-26](#) to determine the location of the screw holes.
4. Pre-drill holes to accommodate four screws.
5. Attach the cradle securely to the surface.
6. Insert up to four batteries to charge.

Inserting Batteries

To insert batteries in the cradle, align the connectors on the bottom of the battery with the battery charging connectors in the cradle. Push down on the top of the battery until it clicks into place, engaging the contacts in the cradle.




Figure 2-21 *Inserting Batteries*

Charging Batteries

The battery begins charging when the green LED indicator flashes. A complete charge of a fully discharged battery can take up to four hours using external power.

LED Indicators

Table 2-8 *LED Charging Status Indicators - Four Slot Battery Charger LEDs*

LED	Indication
Flashing Green Battery LED	Flashes when battery charges.
Solid Green Battery LED	Battery is fully charged.
Solid Blue Cradle LED	Lights when power is applied; off when there is no power applied.
Fast Green Flash	Error condition.

Troubleshooting


For detailed cradle and battery charger information see *Chapter 9, Maintenance and Troubleshooting*.

Wall Mount Templates


Wall mount templates for the single slot cradle and forklift cradle begin on *page 2-27*.

The four slot cradle template is located on the Web at: <http://www.motorola.com/enterprisemobility/manuals>.

Single Slot Cradle Mounting Template



Four Slot Battery Charger Mounting Template



Chapter 3 ActiveSync

Introduction

To communicate with the host computer, install Microsoft ActiveSync (version 4.0 or higher) on the host computer. Changes made on the device or host computer appear in both places after synchronization.

ActiveSync software:

- Allows working with device-compatible host applications on the host computer. ActiveSync replicates data from the device so the host application can view, enter, and modify data on the device.
- Synchronizes files between the device and host computer, converting the files to the correct format.
- Backs up the data stored on the device. Synchronization is a one-step procedure that ensures the data is always safe and up-to-date.
- Copies (rather than synchronizes) files between the device and host computer.
- Controls when synchronization occurs by selecting a synchronization mode, e.g., set to synchronize continually while the device is connected to the host computer, or set to only synchronize on command.
- Selects the types of information to synchronize and control how much data is synchronized.

Setup

The device communicates with a host PC via ActiveSync in an STB 2000 cradle with a USB cable connection, or with a direct USB cable connection from device to host PC. [Chapter 2, Accessories](#) provides information about setting up the device/cradle to communicate.

✓ **NOTE** The STB2078 cradle does not support ActiveSync.

Installing ActiveSync

To install ActiveSync on the host computer, download the latest version of the software from the Microsoft Web site at <http://www.microsoft.com>. Refer to the installation and RAS instructions included with the ActiveSync software.

✓ **NOTE** Microsoft recommends installing ActiveSync on the host computer before connecting the device.

ActiveSync is automatically enabled when the device is placed in the STB2000 cradle with a USB cable connection. Alternatively, ActiveSync can be enabled through the on-board RJ45 jack on the device. This requires device configuration on the *Configure USB* window. On the device *Home* window, select *Configure USB > ActiveSync*. Refer to *Chapter 2, Operating* in the *MT2070/MT2090 User Guide* (p/n 72E-117859-xx) for detailed information about configuring the device.

Setting Up an ActiveSync Connection on the Host Computer

1. If not already installed, install Microsoft ActiveSync on the host computer.
2. Select *Start > Programs > Microsoft ActiveSync* on the host computer. The *ActiveSync* window displays.

✓ **NOTE** If the device is connected to the host computer prior to running ActiveSync, a *Guest* connection occurs automatically. If the device is not connected to the host computer prior to running ActiveSync, a *Guest* connection occurs as soon as the device connects.




Figure 3-1 ActiveSync Window

✓ **NOTE** Assign each device a unique device name. Do not try to synchronize more than one device to the same name.

3. In the *ActiveSync* window, select *File > Connection Settings*. The *Connection Settings* window displays.



Figure 3-2 *Connection Settings Window*

4. Select the appropriate check box for the type of connection used.
5. Select the *Show status icon in taskbar* check box.
6. Select the *Open ActiveSync when my device connects* check box.
7. Select *Automatic* in the *This computer is connected to:* drop-down list.
8. Click **OK** to save any changes made.

No partnership is necessary to synchronize information between the device and host computer.

For more information about using ActiveSync, start ActiveSync on the host computer, then see ActiveSync Help.

Chapter 4 Software Installation on Development PC

Introduction

To develop applications to run on the device, use one or all of the following:

- Enterprise Mobility Developer Kit (EMDK) for C for both WinCE 4.2 and Win CE 5.0
- Windows CE Platform SDK for MT2070/MT2090 or Windows CE 5.0 standard SDK
- Device Configuration Package (DCP) for MT2070/MT2090
- MCL Collection, p/n SWE-123872-01, includes MCL Designer and MCL Link. Refer to Solution Builder for additional MCL part numbers.

The EMDK is a development tool used to create native C applications for devices. It includes documentation, header files (.H), and library files (.LIB) for native code application development that targets Motorola value-add APIs.

The Windows CE Platform SDK for the MT2070/MT2090 is used in conjunction with the EMDK for eVC4 to create Windows CE applications for the MT2070/MT2090 device. The Platform SDK installs a new Windows CE device type and its associated libraries onto the development PC. This new device is added to the Active WCE Configuration field of Microsoft eMbedded Visual C++ 4.0 (eVC4). You may also use the standard CE 5.0 SDK from Microsoft.

The Device Configuration Package (DCP) is required to create and download hex images that represent flash partitions to the device. The DCP includes the user documentation, flash partitions, Terminal Configuration Manager (TCM) and the associated TCM scripts, and Symbol Configuration Manager (SCM).

Required System Configurations

The minimum system configuration required to use the EMDK for MT2070/MT2090 is:

- IBM-compatible host computer with Pentium 450 MHz processor or higher
- Microsoft Windows XP or Microsoft Windows 2000 operating system
- 128 MB RAM
- 100 MB available hard disk space
- CD-ROM drive
- One available serial port
- Mouse
- Adobe® Acrobat® Reader® 3.0 or higher, available at the Microsoft Web site: <http://www.microsoft.com>
- Microsoft ActiveSync version 3.7 or higher, available at the Microsoft Web site: <http://www.microsoft.com>
- Microsoft Embedded Visual C++ v4.0 with SP2
- Microsoft Windows Mobile 2003 SDK.

DCP for MT2070/MT2090

Installing

To install the DCP for MT2070/MT2090:

1. Download the EMDK from the Support Central Web site at: <http://www.motorola.com/enterprisemobility/support>.
 - a. Select *Software Downloads* from the menu list on the left side of the page.
 - b. Select *Bar Code Scanners*.
 - c. Select *MT2070/MT2090*.
 - d. On the MT2070/MT2090 product page, select the *Device Configuration Package (DCP) for MT2070/MT2090* from the *Software Downloads* section.
 - e. Save the .exe file to the development computer.
2. Locate the .exe file on the development computer, double-click the file, and follow the install prompts.
3. Once installed, access the major components of the DCP from the *Device Configuration Package (DCP) for MT2070/MT2090* program group.

Components

Table 4-1 lists the components of the MT2070/MT2090 DCP.

Table 4-1 DCP for MT2070/MT2090 Components and Locations

Component	Description	Directory Location
Files that make up the flash partitions	Used to configure the device.	\Program Files\Motorola Device Configuration Packages\MT209070c50Aen\v1.0\Flash Folders
Hex image - default location	Loads onto the device for configuration.	\Program Files\Motorola Device Configuration Packages\MT209070c50Aen\v1.0\Hex Images
User Documentation	User manuals that provide guidance on using and integrating the MT2070/MT2090.	\Program Files\Motorola Device Configuration Packages\MT209070c50Aen\v1.0
Readme	Contains important information for the DCP.	\Program Files\Motorola Device Configuration Packages\MT209070c50Aen\v1.0
Operating System Update	Contains the OSUPDATE Package Builder and Images.	\Program Files\Motorola Device Configuration Packages\MT209070c50Aen\v1.0\OSUpdate
Scripts	Used to customize flash partitions.	\Program Files\Motorola Device Configuration Packages\MT209070c50Aen\v1.0\TCM Scripts
Tools (e.g., Keyboard remap, if any)	Used in developing applications for the device.	\Program Files\Motorola Device Configuration Packages\MT209070c50Aen\v1.0\Tools\kbtool

Platform SDK

To download and install the MT2070/MT2090 Platform SDK:

1. Download the appropriate Platform SDK from the Support Central Web site at: <http://www.motorola.com/enterprisemobility/support>.
 - a. Select *Software Downloads* from the menu list on the left side of the page.
 - b. Select *Bar Code Scanners*.
 - c. Select *MT2070/MT2090*.
 - d. On the MT2070/MT2090 product page, select the appropriate Platform SDK for MT2070/MT2090 from the *Software Downloads* section.
 - e. Save the .exe file to the development computer.
2. Locate the .exe file on the development computer, double-click the file, and follow the install prompts.

Enterprise Mobility Developer Kit

To install the EMDK:

1. Download the EMDK from the Support Central Web site at:
<http://www.motorola.com/enterprisemobility/support>.
 - a. Select *Software Downloads* from the menu list on the left side of the page.
 - b. Select *Bar Code Scanners*.
 - c. Select *MT2070/MT2090*.
 - d. On the MT2070/MT2090 product page, select the appropriate Enterprise Mobility Developer Kit for C from the *Software Downloads* section.
 - e. Save the .exe file to the development computer.
2. Locate the executable, double-click the executable file, and follow the installation prompts.
3. Once installed, access the major components of the EMDK from the *Enterprise Mobility Developer Kit* program group of the Windows *Start* menu. The components include: Help, Platform Integrator, Readme, Samples, and Web Updates.

Download updates to the EMDK from the URL above. Check this site periodically for important updates and new software versions.

Installing Other Development Software

Developing applications for the device may require installing other development software such as application development environments on the development PC. Follow the installation instructions provided with this software.

Chapter 5 Software Installation on the MT20X0

Introduction

With the appropriate accessory, software and connection, the device can share information with the host device. This chapter provides information about installing software and files on the device.

To download and install software use:

- ActiveSync
- IPL.

ActiveSync

Use ActiveSync to copy files from a host computer to the device.

1. Install ActiveSync on the development PC. See [Chapter 3, ActiveSync](#) for more information.
2. Connect the device to the host computer using a USB cradle or an appropriate cable. See [Chapter 2, Accessories](#) for connection information.
3. On the host computer, select *Start > Programs > ActiveSync*.



Figure 5-1 ActiveSync Connected Window


4. Select *Explore*.

Figure 5-2 ActiveSync Explorer

5. Double-click a folder to expand the contents of the folder.




Figure 5-3 Application Folder Contents

6. Use Explorer to locate the host computer directory that contains the file to download. Click that directory in the left pane to display its contents in the right pane.
7. Drag the desired file(s) from the host computer to the desired mobile device folder.
 - *Program Files* folder: files stored in this folder are discarded after a cold boot.
 - *Application* folder: files stored in this folder are retained after a cold boot.

Updating the Operating System

Using IPL

See [Chapter 6, Creating/Loading Hex Images](#) to update the OS via TCM.

Using ActiveSync

1. Install the DCP onto the desktop computer.
2. Connect the MT20X0 to the desktop computer.
 - a. Connect the desktop computer to the MT20X0 via a USB cable and an STB2000 cradle.
 - or**
 - b. Connect the desktop computer directly to the MT20X0 via a USB cable.
 - c. On the device's *Home* screen, select *Config... > Configure USB > ActiveSync*.
3. On the drive in which you installed the DCP, execute the following batch file:
 - a. MT2070: ActiveSyncOSUpdateMT2070.bat
 - b. MT2090: ActiveSyncOSUpdateMT2090.bat
4. The operation should complete in approximately 20 minutes. If the operation fails to complete, remove excess files from the application partition, cold boot the device and retry the update.

Using Airbeam

See [AirBEAM Smart Client on page 8-17](#).

Adding Programs

Install the appropriate software on the host computer before installing it on the device:

1. Download the program to the host computer (or insert the CD or disk that contains the program into the host computer). The program may consist of a single *.exe file, a *.zip file, or a Setup.exe file.
2. Read any installation instructions, Read Me files, or documentation that comes with the program. Many programs provide special installation instructions.
3. Connect the device to the host computer.
4. Double-click the executable file on the host computer.

If the file is an installer, the installation wizard begins. Follow the directions on the window. Once the software is installed on the host computer, the installer transfers the software to the device.

If the file is not an installer, an error message states that the program is valid but is designed for a different type of computer. Move this file to the device. Follow the installation instructions for the program in the Read Me file or documentation, or use ActiveSync Explore to copy the program file to the Program Files folder on the device as described in [ActiveSync on page 5-1](#). For more information on copying files using ActiveSync, see ActiveSync Help.

5. When installation is complete, go to *Home > Utilities > File Explorer* to find and launch the new program.

IPL

See [Chapter 6, Creating/Loading Hex Images](#) to download customized flash file system partitions to the device and load hex files to the flash memory of the device using IPL.

Chapter 6 Creating/Loading Hex Images

Introduction

Terminal Configuration Manager (TCM) is an application used to customize flash file system partitions for the device. The most common use is to create an application partition hex file that contains the customer's application. TCM can also be used to load hex files to the flash memory of the device.

The program resident on the device that receives the hex file and burns it to the flash memory is called Initial Program Loader (IPL).

TCM scripts control the customization of partitions. The scripts contain all of the necessary information for building an image. The script is a list of copy commands specifying the files to copy from the development computer to the partition.

TCM works with a pair of directory windows, one displaying the script and the other displaying the source files resident on the development computer. Use standard drag and drop operations to add and delete from the script window.

The DCP includes scripts used by Motorola to build the standard factory installed *Platform* and *Application* partitions provided on the device. The standard *Platform* partition contains drivers while the *Application* partition contains demo applications and optional components. The standard TCM scripts can be found in the following folder: *C:\Program Files\Symbol Windows CE EMDK (MT2070/MT2090)\SymbolPlatforms\MT2070/MT2090\TCMScripts*.

✓ **NOTE** Before creating a script to build a hex image, identify the files required (system files, drivers, applications, etc.) and locate the files' source directories to make the script building process easier.

The required processes for building a hex image in TCM include:

- Starting TCM
- Defining script properties
- Creating the script for the hex image
- Building the image
- Sending the hex image
- Creating a splash screen
- Flash storage.

Starting Terminal Configuration Manager

✓ **NOTE** Screens and windows pictured are samples and can differ from actual screens.

Click the *Windows* start menu > *TCM* icon to start TCM. The *TCM* window appears displaying two child windows: *Script1* and *File Explorer*. The *Script1* window contains a newly created script and the *File Explorer* window contains a file explorer view used for selecting files to place in the script.




Figure 6-1 TCM Startup Window

The following table lists the components of the *TCM* window.

Table 6-1 TCM Components

Icon	Component	Function
	Script window	Displays the files to use in the creation of the partition(s).
	File Explorer window	Used to select the files to add to the script.
	Create button	Create a new script file.
	Open button	Open an existing script file.

Table 6-1 TCM Components (Continued)

Icon	Component	Function
	Save button	Save the current script file.
	Large icons button	View the current script items as large icon.
	Small icons button	View the current script items as small icon.
	List button	View the current script items as a list.
	Details button	View the current script items with more details.
	About button	Display version information for TCM.
	Properties button	View/change the current script properties.
	Build button	Build the current script into a set of hex files.
	Check button	Check the script for errors (files not found).
	Send button	Download the hex image to the device.
	Tile button	Arrange the sub-windows in a tiled orientation.
	Build and Send	Build the current script into a set of hex images and send the hex images to the device.
	Preferences button	View/change the global TCM options.

Defining Script Properties

Define script properties before creating a script. This defines the type of device, flash type, number of disks being created, and the memory configuration of each disk partition.

- ✓ **NOTE** The windows displayed in the following steps are examples only. The data displayed in the window fields do not reflect the actual data for the MT2070/MT2090 devices.

To define the script properties:

1. Select the *Script* window to make it active.
2. Click the **Properties** button. The *Script Properties* window > *Partition Data* tab displays.



Figure 6-2 *Script Properties* Window - *Partition Data* Tab

3. In the *Terminal* drop-down list, ensure the *MT2070/MT2090w v1.0 64M* entry is selected.
4. Use the default *Flash Type*.
5. In the *Disks* drop-down list, select the number of disk partitions to create.
6. Select the (memory) *Size* for each partition. Note that adding space to one disk partition subtracts it from another.
7. In the *Access* drop-down list for each disk partition, determine and select the Read/Write access option.
8. Click the *Options* tab.




Figure 6-3 *Script Properties* Window - *Options* Tab

9. Set the paths for the Script File, Flash File, and Hex File Build.
10. Click **OK**.

Creating the Script for the Hex Image

On start-up, *TCM* displays the *TCM* window with the *Script1* window and *File Explorer* window pointing to the following directory:

```
\Program Files\Symbol Device Configuration Packages\MT2070\MT2090w\v0.1\TCMScripts\
```

The *Script1* window directory pane displays two partitions: *Platform* and *Application*. Depending on the type of flash chip, the number of partitions may change. Files can be added to each of the partitions. *TCM* functionality includes:

- Opening a new or existing script file
- Copying components to the script window
- Saving the script file.

Opening a New or Existing Script

A script file can be created from scratch or based on an existing script file. Click **Create** to create a new script or click **Open** to open an existing script (for example, a script provided in the MT2070/MT2090 DCP. If changes are made to an existing script saving the changes overwrites the original script. To avoid this use the *Save As* function to save the script using a different file name.

Updating TCM 1.X Scripts

To upgrade script files created with older versions of *TCM* to *TCM* 2.0 scripts click **Open** to open the existing script. The *Conversion* window displays.




Figure 6-4 Conversion Window - Upgrading to *TCM* 2.0

In the *Select a Version* field, select a version and then click **OK**.

Copying Components to the Script

Script contents are managed using standard file operations such as *New Folder*, *Delete*, and *Rename*. To add items to the script files and folders in the *File Explorer* window and drag them to the *Script* window. The *File Explorer* window supports standard windows; to select multiple files click while holding the **SHIFT** or **CTRL** keys.

Saving the Script

To save modifications to a script file use the *Save* or the *Save As* function. Saving changes to an existing script overwrites the original script. To use a Motorola-supplied standard script as a base and save the changes in a new script, use the *Save As* function.

Building the Image

After creating the script, build the hex image defined by the script.

As part of the build, TCM performs a check on the script which verifies that all files referenced in the script exist. This check is important for previously created scripts to ensure that files referenced in the script are still in the designated locations.

To build scripts:

1. Click **Build** on the TCM toolbar. The *Configure Build* window displays.




Figure 6-5 *Configure Build Window*

2. Select the items (partitions) to build using the check box(es) to the left of each named partition.
3. Specify the *Build Path* to define where to store all built partitions.
4. Select the hex image check box to reduce the size and speed up the download.
5. Click **OK** and follow the on-screen instructions.

If building the splash screen partitions, a prompt appears requesting both the source bitmap file and the destination hex file.

6. TCM perform a check and if there are no errors, creates the partition hex files.

If the build fails, TCM does not create the hex files and displays an error message. Two of the most common reasons for a build failure are:

- Files defined in the script can not be found. This error can occur when the files referenced by the script are no longer stored on the development computer or the folders where they are stored were renamed.
- The total amount of flash memory space required by the script exceeds the image size. To correct this, reduce the number of files in the partition or increase the size of the partition. See [Defining Script Properties on page 6-4](#) for more information about setting the image size appropriately.

Downloading the Hex Image

Once the hex file is built, download it to the device.

Using a USB Connection

To load the hex files on to the device:

1. For downloads using a USB connection, connect the device to the development computer using the single slot USB cradle.



CAUTION Ensure that power is applied to the device. To ensure a successful download, do not remove power from the device while in IPL mode.

2. Press and hold the yellow **Scan** trigger and the **2** key simultaneously until the device cold boots.
3. Release the yellow **Scan** trigger and the **2** key and press and hold the **ENT** (Enter) key until the device resets into IPL.
4. When the *Initial Program Loader* menu appears, release the **ENT** (Enter) key.




Figure 6-6 *Initial Program Loader Menu*

5. Choose *Auto Select* or use the up and down scroll buttons to select the partition to download, then press **ENT**.

Table 6-2 *IPL Menu Partitions*

Partition Name	Description
Platform	Contains the files in the Platform folder.
Application	Contains the files in the Application folder.
Config Block	Contains information to correctly configure the operating system for the device. This information is loaded by the manufacturer. Note: Ensure that a correct config block is loaded in the device. Loading an incorrect config block prevents the correct operation of the device.
Windows CE	Contains the operating system for the device.


Table 6-2 IPL Menu Partitions (Continued)

Partition Name	Description
Monitor	Contains the Monitor and IPL programs.
Splash Screen	Contains the splash screen that displays while booting the device. Note: Splash screens are generated from .bmp images. See Splash Screen Format on page 6-14 . For mono displays, the bmp image must be 8 bits per pixel (bpp).
Power Micro	The Power Micro is a small computer contained within the device that controls several system resources. In the unlikely event that the Power Micro firmware needs updating, select this item to program the device.
Partition Table	Contains the partition information for all other partitions. Note: The partition table should never need changing unless the sizes of the platform and application images are changed within TCM. If this is done, load the new partition table first, followed by both platform and application in any order.
Command File	Displays the <i>Select Transport</i> menu.
System Reset	Exits IPL and cold boots the operating system.
Auto Select	Allows downloading one or more files without manually selecting the destination. (The content of the downloaded files directs the file to the correct destination.) For technical reasons, Auto Select can not be used to download Monitor, Power Micro, or Partition Table. These items must be specifically selected.



NOTE If the platform or application partition size changes, download a new partition table first.

6. IPL displays the *Select Transport* menu which lists the available methods of downloading the file.

**Figure 6-7** Select Transport Menu

- Use the up and down scroll keys to select the *USB* transport method, then press **ENT**. The *Select Transport* menu, the *Waiting for Download* message displays.




Figure 6-8 *Waiting for Download*

- On the development computer, click **Load** on the TCM toolbar. The *Load Terminal* window - *Serial* tab displays.




Figure 6-9 *Load Terminal Window - Serial Tab*

- Select the *Image Files To Load*.
- Select *USB: Symbol Device* from the *Comm Port* drop-down list.

✓ **NOTE** The *USB: Symbol Device* option does not appear on the *Comm Port* drop-down list until after the *Waiting for Download* message completes.

- Click **Download** to begin the download process. The *Downloading* screen on device displays the *Device Status* and a progress bar.
- When complete, *Device Status* displays *Result was: Success!*, or in the case of an error, the cause of the error.




Figure 6-10 *Downloading Complete Screen*

- Press **ENT** to return to the *IPL* menu to select the next partition to download.
- To exit *IPL*, select the *System Reset* item from the *IPL* menu.

TCM Error Messages

TCM validates the cells in the partition table when the **Execute** button is clicked. Cells highlighted in red contain an error. Partition loading is disabled until all errors are corrected.

Table 6-3 *TCM Error Messages*

Error	Description/Solution
Failed to build images: flash file system DLL not loaded!	TCM could not load the DLL required to build images for the targeting flash file system. Reinstall TCM or recover the DLL.
Failure finding directory xxx	Building process failed because directory xxx was not found.
Failure creating volume	Building process failed because TCM could not create a certain disk volume.
Failure adding system file to image	Build process failed because TCM failed to add a certain system file to the disk image.
INVALID PATH	The path for the image file to build is not valid.
Nothing Selected To Build	In the <i>Config Build</i> window, no item is selected to build.
Illegal ESS ID	In the <i>Build ESSID Partition</i> window, no ESS ID was entered or the ESS ID entered was illegal.
Disk Full	TCM failed to create Hex image file at the selected path. Check available disk space.
Target Disk Full	Build process failed because TCM failed to add file to the image of a disk volume. Remove some files or increase the disk size.
Hex file is READ ONLY	The Hex image file to be created exists and is read-only. Delete the existing file or change its attribute.
Error opening the file xxx with write access	TCM could not open file xxx with write access. Check if file is in use.
Failure creating binary file	TCM failed to open/create an intermediate binary file.
Hex File To load is missing or invalid	In <i>Load Terminal</i> window, the file selected to load has invalid status.
Could not locate terminal name in TCM.ini file	While loading the <i>Script Properties</i> window, TCM could not find the TCM.ini section corresponding to the device type specified by the current opening script. Either TCM.ini or the script file is invalid.
Incorrect disk sizes in TCM.ini file	The total disk size specified in the script does not match the total disk size defined in the corresponding TCM.ini section. Check if the script is corrupt or the TCM.ini has changed after the script was created.
INVALID DIRECTORY	In <i>Script Properties</i> window, the selected System File Path is not a valid directory.
One of the disk sizes is one sector in size	In <i>Script Properties</i> window, one of the disks is too small (one sector in size). This may cause problem while building images, especially when cushion is enabled. Increase the disk size.

Table 6-3 TCM Error Messages (Continued)

Error	Description/Solution
INVALID VOLUME NAME	In <i>Script Properties</i> window, one of the volume labels is not valid.
Corrupt TCM.INI file! (Invalid value of VolumeDivisor)	The VolumeDivisor entry is missing or invalid in the TCM.ini. Reinstall TCM or recover TCM.ini.
Invalid version of TCM script file	The TCM script was not created by this version of TCM.
Corrupt or missing TCM.ini file	TCM could not find TCM.ini file.
FAILED CONNECTION TO COM PORT (Could not get status)	While downloading images to device, TCM failed to connect to the selected COM port. Check if the COM port is free and is properly configured.
FAILED CONNECTION TO TERMINAL (Terminal Not Connected Properly/Terminal Not Ready to Receive)	While downloading images, TCM failed to connect to the device. Check if the correct flow control protocol is selected and the device is properly connected and is in a listening state.

IPL Error Detection

While receiving data, IPL performs many checks on the data to ensure that the data is received correctly. If an error is detected, IPL immediately aborts the download, and reports the error on an error screen.

Error screens vary depending on the action performed. A sample error screen may look like the screen pictured below:

```

Downloading:
Platform

via Serial Port 115200
Error # -2 : Messages:
Cancelled by user

Press any key to continue

```

Figure 6-11 IPL Error Screen

This error message screen displays until a key is pressed. Once the screen is acknowledged, IPL returns to the *Initial Program Loader* main menu to wait for a new selection.

To find the probable cause of the error, use the error number and/or the error text displayed on the screen to look up the error in [Table 6-4](#).

Table 6-4 *IPL Errors*

Error Text	Error Number	Probable Cause
Unknown error	-1	A general error occurred. Retry the download. If the failure persists, it is most likely due to a hardware failure; the device requires servicing.
Cancelled by user	-2	The user cancelled the download.
Can't open the source	-7	An error occurred opening the source device (either radio card or serial port). Check source device connectivity and retry.
Can't open the destination	-8	An error occurred opening the destination device (either flash ROM or Power Micro). Retry the download. If the failure persists, it is most likely due to a hardware failure; the device requires servicing.
Can't read from the source device	-9	The source device (either radio card or serial port) could not be read from. Check source device connectivity and retry.
Can't write to the destination device	-10	The destination device (either flash ROM or Power Micro) could not be written to. Retry the download. If the failure persists, it is most likely due to a hardware failure; the device requires servicing.
Transmission checksum error	-11	An error occurred during transmission from the source device (either radio card or serial port) and the checksum check failed. Check source device connectivity and retry.
Readback checksum error	-12	A checksum, generated from reading back data that was written to the destination device, was incorrect. An error during transmission or a write error to the destination device could cause this.
There is no more heap space available	-14	There is no more heap space available for the download procedure. Restart IPL and retry the download. If the failure persists, contact service with details of what is being downloaded.
Insufficient data available to complete record	-21	A Symbol hex file download was attempted but the hex file is invalid. Ensure the file is in Symbol hex file format.
Invalid Symbol HEX file	-23	A Symbol hex file download was attempted but the hex file is invalid. Ensure the file is in Symbol hex file format.
Unrecognized or unsupported HEX record	-24	The Symbol hex file being downloaded contains an invalid or unrecognized hex record. Ensure the file is in proper Symbol hex file format.
Invalid data in HEX file	-25	The Symbol hex file being downloaded contains invalid data. Ensure the file is in proper Symbol hex file format with valid hex data.
Exceeded max size	-26	The download file is too large to fit into the space allocated for it. Either make the file smaller or increase the space allocated for it by altering the partition table.
Partition is not valid on this device	-27	The downloaded file specifies a partition entry that does not exist on the device. Only download files that are valid for this device, or change the partition table so that the new file is valid on the device.

Table 6-4 *IPL Errors (Continued)*

Error Text	Error Number	Probable Cause
Wrong destination code	-28	A specific partition was chosen from the Main Menu (not Auto Select) but the file selected for download was for another partition. Ensure that the partition selected from the Main Menu matches the file selected for download.
File type does not support IPL Auto Select	-29	Monitor, Power Micro and Partition Table cannot be loaded with Auto Select. Select the appropriate area, and try again.
Non-contiguous record found	-30	A Symbol hex file download was attempted but the hex file is invalid. Ensure the file is in Symbol hex file format.
Timed Out - No data	-31	IPL was waiting for data from the source device but timed out before receiving any. Check the source device connectivity and retry.
Fail: Buffer Overrun	-32	The serial port device could not keep up with incoming data. Retry the serial download with a lower baud rate.
Partition Table not Valid	-33	The size of flash memory is different than that described in the partition table. Retry the download with the correct partition table file.
Invalid file format	-34	The file format is invalid. IPL only supports Symbol hex files.

Creating a Splash Screen

The MT2070/MT2090 DCP includes source bitmap files used to create the default splash screens for the device. Modify these files using any of the standard windows image editors to allow customization.

To create a custom splash screen:

1. Use the image editor to open the Splashmono.bmp file supplied with the Series 1000 DCP.
2. Modify the bitmap file and save.
3. Create a splash partition using the steps shown in [Building the Image on page 6-6](#).

Splash Screen Format

If the default files are not used to create the new splash screens, be sure to preserve the image format. The formats are as follows:

Table 6-5 *Splash Screen Format*

Screen Type	Dimensions	Color Format
Monochrome	216 x 240	8 bits per pixel

See [Downloading the Hex Image on page 6-7](#) for information about loading the splash screen using TCM and IPL.

Flash Storage

In addition to the RAM-based storage standard on Windows CE devices, the device is also equipped with a non-volatile Flash-based storage area which can store data (partitions) that can not be corrupted by a cold boot. This Flash area is divided into two categories: Flash File System (FFS) Partitions and Non-FFS Partitions.

FFS Partitions

The device includes two FFS partitions. These partitions appear to the device as a hard drive that the OS file system can write files to and read files from. Data is retained even if power is removed.

The two FFS partitions appear as two separate folders in the Windows CE file system and are as follows:

- Platform: The Platform FFS partition contains Motorola-supplied programs and Dynamic Link Libraries (DLLs). This FFS is configured to include DLLs that control system operation. Since these drivers are required for basic device operation, only experienced users should modify the content of this partition.
- Application: The Application FFS partition is used to store application programs needed to operate the device.

Working with FFS Partitions

Because the FFS partitions appear as folders under the Windows CE file system, they can be written to and read like any other folder. For example, an application program can write data to a file located in the Application folder just as it would to the Windows folder. However, the file in the Application folder is in non-volatile storage and is not lost on a cold boot (e.g., when power is removed for a long period of time).

Use standard tools such as ActiveSync to copy files to and from the FFS partitions. They appear as the “Application” and “Platform” folders to the ActiveSync explorer. This is useful when installing applications on the device. Applications stored in the Application folder are retained even when the device is cold booted, just as the Demo 1000 program is retained in memory.

There are two device drivers included in the Windows CE image to assist developers in configuring the device following a cold boot: RegMerge and CopyFiles.

RegMerge.dll

RegMerge.dll is a built-in driver that allows modify the Windows CE Registry. Regmerge.dll runs very early in the boot process and looks for registry files (.reg files) in certain Flash File System folders during a cold boot. It then merges the registry changes into the system registry located in RAM.

Since the registry is re-created on every cold boot from the default ROM image, the RegMerge driver is necessary to make registry modifications persistent over cold boots.

RegMerge is configured to look in the root of two specific folders for .reg files in the following order:

```
\Platform
\Application
```

Regmerge continues to look for .reg files in these folders until all folders are checked. This allows folders later in the list to override folders earlier in the list. This way, it is possible to override Registry changes made by the Platforms partitions folders. Take care when using Regmerge to make Registry changes. The MT2070/MT2090 DCP contains examples of .reg files.

✓ **NOTE** Regmerge only merges the .reg files on cold boots. A warm boot skips the merge process.

Typically, do not make modifications to registry values for drivers loaded before RegMerge. However, these values may require modification during software development. Since these early loading drivers read these keys before RegMerge gets a chance to change them, the device must be cold booted. The warm boot does not re-initialize the registry and the early loading driver reads the new registry values.

Do not use Regmerge to modify built-in driver registry values, or merge the same Registry value to two files in the same folder, as the results are undefined.

CopyFiles

Windows CE expects certain files to be in the Windows folder, residing in volatile storage. Windows CE maintains the System Registry in volatile storage. CopyFiles copies files from one folder to another on a cold boot. A cold boot copies files from a non-volatile partition (Application or Platform) to the Windows or other volatile partition during a cold boot. During a cold boot CopyFiles looks for files with a .CPY extension in the root of the Platform and Application FFS partitions (Platform first and then Application). These files are text files containing the source and destination for the desired files to be copied separated by “>”. The following example from the file application.cpy is contained on the demo application partition included in the MT2070/MT2090 DCP. Also obtain this from the Support Central Web site at <http://www.motorola.com/enterprisemobility/contactsupport>.

Files are copied to the Windows folder from the Flash File System using copy files (*.cpy) in the following order:

\Platform
 \Application

Example:

```
\Application\ScanSamp2.exe>\Windows\ScanSamp2.exe
```

This line directs CopyFiles to copy the ScanSamp2.exe application from the \Application folder to the \Windows folder.

Non-FFS Partitions

Non-FFS Partitions include additional software and data pre-loaded on the device that can be upgraded. Unlike FFS Partitions, these partitions are not visible when the operating system is running. They also contain system information. Non-FFS partitions include the following:

- Windows CE: The complete Windows CE operating system is stored on Flash devices. If necessary, download the entire OS image to the device using files provided by Motorola. The current OS partition on the device is included as part of the TCM installation package. Obtain any upgrades from Motorola. This partition is mandatory for the device.
- Splash Screen: a bitmap smaller than 16 Kb (and limited to 8 bits per pixel) appears as the device cold boots. To download a customized screen to display, see [Creating a Splash Screen on page 6-14](#).

✓ **NOTE** 8 bits per pixel only applies to splash screen images. Once Windows CE is running, the color density is 16 bits per pixel.

- IPL: This program interfaces with the host computer and allows downloading via cradle any or all of the partitions listed above, as well as updated versions of IPL. Use caution downloading updated IPL versions; incorrect downloading of an IPL causes permanent damage to the device. IPL is mandatory for the device.
- Partition Table: Identifies where each partition is loaded in the device.

Downloading Partitions to the Device

Use TCM to specify a hex destination file for each partition and download each file to the device. This download requires a program loader stored on the device. The device comes with a program loading utility, Initial Program Loader (IPL), stored in the device's write-protected flash.

IPL

IPL allows the user to upgrade the device with software updates and/or feature enhancements.

Partition Update vs. File Update

There are two types of updates supported by the device: partitions and files. The MT2070/MT2090 uses the same file system as the file system used on a desktop computer. A file is a unit of data that can be accessed using a file name and a location in the file system. Replacing a file erases the contents of the previous file. The operating system must be running for a file to be updated, so the IPL cannot perform individual file updates as it is a stand-alone program that does not require the operating system to be running.

A typical partition is a group of files combined into a single “partition” that represents a specific area of storage. Examples of partitions are the flash file systems such as Platform or Application. (Using the desktop computer comparison, these partitions are roughly equivalent to a C: or D: hard disk drive.) In addition to the “hard disk” partitions, some partitions are used for single items such as the operating system, monitor, or splash screen. (Again using a desktop computer comparison, these partitions are roughly the equivalent of the BIOS or special hidden system files.) Updating a partition erases all data previously in its storage region - i.e., it is not a merge but rather a replacement operation. Typically, the operating system is not running when partitions are updated, so IPL can perform partition updates.

Use TCM to create partition images for selected partitions. All partition images suitable for use by IPL are in hex file format for transfer by TCM from the development computer to the device.

Upgrade Requirements

- The hex files to be downloaded (on development computer)
- A connection from the host computer and the device (either USB or wireless)
- TCM (on development computer) to download the files.

After satisfying these requirements, invoke IPL and navigate the menu to upgrade the MT2070/MT2090. See [Downloading the Hex Image on page 6-7](#) for procedures on downloading a hex file to the device.

Chapter 7 Wireless Applications

Introduction

Wireless LANs allow the MT2090 to communicate wirelessly and to send captured data to a host device in real time. Before an MT2090 can be used on a Spectrum24 WLAN, the facility must be set up with the required hardware to run the wireless LAN and the device must be properly configured. Refer to the documentation that came with the Access Points (APs) for instructions on setting up the hardware.

To configure the device, a set of wireless applications provide the user with the tools to configure and test the wireless radio embedded in the device cradle. The following wireless applications are available on the task tray from the **Wireless Application** menu:

- Wireless Status
- Wireless Diagnostics
- Find WLANs
- Manage Profiles
- Options
- Log On/Off
- Enable/Disable Radio (Fusion 2.5 only).

From the *Home* window, select *Config...* and press the up or down *Scroll* key to highlight *Wireless Companion*; then press *ENT* to display the *Wireless Companion* menu.




Figure 7-1 *Wireless Companion Menu*

Signal Strength Icon

The **Signal Strength** icon in the task tray indicates the cradle's wireless signal strength as follows:

Table 7-1 *Wireless Applications Icons, Signal Strength Descriptions*

Icon	Status	Action
	Excellent signal strength	Wireless LAN network is ready to use.
	Very good signal strength	Wireless LAN network is ready to use.
	Good signal strength	Wireless LAN network is ready to use.
	Fair signal strength	Wireless LAN network is ready to use. Notify the network administrator that the signal strength is only "Fair".
	Poor signal strength	Wireless LAN network is ready to use. Performance may not be optimum. Notify the network administrator that the signal strength is "Poor".
	Out-of-network range (not associated)	No wireless LAN network connection or not associated. Notify the network administrator.

Turning Off the Radio (MT2090 only)

The Wireless Companion is used to configure and manage the device's wireless network settings. On the *Config...* window press the up or down *Scroll* key to highlight *Wireless Companion* and press *ENT* to display the *Wireless Companion* menu.



Figure 7-2 *Config... Wireless Companion Menu*

On the *Wireless Companion* menu, press the up or down *Scroll* key to highlight *Enable* or *Disable Radio* and press *ENT*. The radio is enabled or disabled, depending on its current state.

Find WLANs Application

Use the **Find WLANs** application to discover available networks in the vicinity of the user and device. Open the **Find WLANs** application, via the Wireless Companion menu. The *Find WLANs* window displays.




Figure 7-3 Find WLAN Window



NOTE Find WLAN display is limited to 32 items (ESSIDs or MAC addresses). A combination of up to 32 ESSIDs/APs may be displayed.

Valid ESSIDs that were not displayed in the *Find WLAN* window may be entered manually. See [Figure 7-4 on page 7-5](#).

The **Find WLANs** list displays:

- WLAN Networks - Available wireless networks with an icon that indicates signal strength and encryption type. The signal strength and encryption icon is described in tables [Table 7-2](#) and [Table 7-3](#).
- Network Type - Type of network.
- Channel - Channel that the AP is transmitting on.
- Signal Strength - Displays the signal strength of the signal from the AP. (See [Table 7-1 on page 7-2](#) signal strength icons.)

Highlight a network in the list and press *ENT* to open a pop-up menu which provides two options:

Connect and Refresh. Select Refresh to refresh the WLAN list. Select Connect to create a WLAN profile from that network (refer to the *MT2090/MT2070 User Guide* (p/n 72E-117859-xx) for information about managing profiles). This opens the *Profile Entry* window which allows you to set the values for the selected network. After editing the profile, the device automatically connects to this new profile.

Profile Editor Wizard

The **Profile Editor Wizard** displays when creating a new profile, or editing an existing profile. If editing a profile, the fields are populated with the current settings for that profile. If creating a new profile, the known information for that WLAN network are populated into the fields.

Navigate through the wizard using the soft keys to manipulate the **Next** and **Back** buttons. Tab to **X** to quit, a notification box appears asking the user to confirm the quit. Select **No** to return to the wizard or **Yes** to quit and return to the *Manage Profiles* window.

Profile ID

The **Profile ID** dialog box is the first dialog box in the **Profile Editor Wizard**. Use the **Profile ID** dialog box to input the fields for the profile name and the ESSID.



Figure 7-4 Profile ID Dialog Box

Table 7-2 Profile ID Fields

Field	Description
Name	Populated with the name and (WLAN) identifier of the network connection. Use the <i>Name</i> : field to enter a user friendly name of the device profile used to connect to either an AP or another networked computer. Example: The Public LAN.
ESSID	The ESSID is the 802.11 extended service set identifier. The ESSID is 32-character (maximum) string identifying the WLAN. The ESSID assigned to the device is required to match the AP ESSID for the device to communicate with the AP.



NOTE Two profiles with the same user friendly name are valid but not recommended.

Select **Next**. The **Operating Mode** dialog box displays.

Operating Mode

Use the **Operating Mode** dialog box to select the operating mode (Infrastructure or Ad-Hoc) and the country location.




Figure 7-5 Operating Mode Dialog Box

Table 7-3 Operating Mode Fields

Field	Description
Operating Mode	<p>Infrastructure: Select Infrastructure to enable the device to transmit and receive data with an AP. Infrastructure is the device default mode.</p> <p>Ad Hoc: Select Ad Hoc to enable the device to form its own local network where devices communicate peer-to-peer without APs using a shared ESSID.</p>
Country	<p>Country: is used to determine if the profile is valid for the country of operation. The profile country must match the country in the options. page or it must match the acquired country if 802.11d is enabled.</p> <p>Single Country Use:</p> <p>When the device is only to be used in a single country, set every profile country to Allow Any Country. In the Options > Regulatory dialog box (see Figure 7-43 on page 7-35), set the country to the specific country the device is to be used in, and deselect (uncheck) the Enable 802.11d option. This is the most common and the efficient configuration. It eliminates the initialization overhead associated with acquiring a country via 802.11d.</p> <p>Multiple Country Use:</p> <p>When the device may be used in more than one country, select (check) the <i>Enable 802.11d</i> option in the Regulatory Options dialog box (see Figure 7-43 on page 7-35). This eliminates the need for reprogramming the country (in Options > Regulatory) each time a new country is entered. However, this only works if the infrastructure (i.e. APs) support 802.11d (some infrastructures do not support 802.11d, including some Cisco APs). When the Enable 802.11d option is selected, the Options > Regulatory > Country setting is not used. For a single profile that can be used in multiple countries, with infrastructure that supports 802.11d (including Symbol infrastructure), set the Profile Country to Allow Any Country. Under Options > Regulatory, select Enable 802.11d. The Options > Regulatory > Country setting is not used.</p> <p>For a single profile that can be used in multiple countries, but with infrastructure that does not support 802.11d, set the profile country to Allow Any Country, and de-select (uncheck) Enable 802.11d. In this case, the Options > Regulatory > Country setting must always be set to the country the device is currently in. This configuration option is the most efficient and may be chosen for use with any infrastructure. However, the Options > Regulatory > Country setting must be manually changed when a new country is entered.</p> <p>(continued)</p>

Table 7-4 *Operating Mode Fields (continued)*

Field	Description
Country (continued)	<p>Note that using a single profile in multiple countries implies that there is a common ESSID to connect to in each country. This is less likely than having unique ESSIDs in each country, this requires unique profiles for each country.</p> <p>For additional efficiency when using multiple profiles that can be used in multiple countries, the country setting for each profile can be set to a specific country. If the current country (found via 802.11d or set by Options > Regulatory > Country when 802.11d is disabled) does not match the country set in a given profile, then that profile is disabled. This can make profile roaming occur faster. For example, if two profiles are created and configured for Japan, and two more profiles are created and configured for USA, then when in Japan only the first two profiles are active, and when in USA only the last two are active. If they had all been configured for Allow Any Country, then all four would always be active, making profile roaming less efficient.</p>

Select **Next**. If **Ad-Hoc** mode was selected the **Ad-Hoc** dialog box displays. If **Infrastructure** mode was selected the **Authentication** dialog box displays. See [Authentication on page 7-8](#) for instruction on setting up authentication.

Ad-Hoc

Use the **Ad-Hoc** dialog box to select the necessary information to control **Ad-Hoc** mode. This dialog box does not display if **Infrastructure** mode is selected. To select Ad-Hoc mode:


1. Select a channel number from the **Channel** drop-down list.

Table 7-5 *Ad-Hoc Channels*

Band	Channel	Frequency
2.4 GHz	1	2412 MHz
	2	2417 MHz
	3	2422 MHz
	4	2427 MHz
	5	2432 MHz
	6	2437 MHz
	7	2442 MHz
	8	2447 MHz
	9	2452 MHz
	10	2457 MHz
	11	2462 MHz

Table 7-5 Ad-Hoc Channels (Continued)

Band	Channel	Frequency
5 GHz	36	5180 MHz
	40	5200 MHz
	44	5220 MHz
	48	5240 MHz

**Figure 7-6** Ad-Hoc Settings Dialog Box

2. Select **Next**. The **Authentication** dialog box displays.

Authentication

Use the **Authentication** dialog box to configure authentication. If **Ad-Hoc** mode is selected, this dialog box is not available and authentication is set to None by default. [Table 7-6](#) lists the available authentication options.

**Figure 7-7** Authentication Dialog Box**Table 7-6** Authentication Options

Authentication	Description
None	Default setting when authentication is not required on the network.
EAP-TLS	Select this option to enable EAP-TLS authentication. EAP-TLS is an authentication scheme through IEEE 802.1x. It authenticates users and ensures only valid users can connect to the network. It also restricts unauthorized users from accessing transmitted information. EAP TLS achieves this through secure authentication certificates.


Table 7-6 Authentication Options (Continued)

Authentication	Description
PEAP	Select this option to enable PEAP authentication. This method uses a digital certificate to verify and authenticate a user's identity.
LEAP	Select this option to enable LEAP authentication. LEAP is founded on mutual authentication. The AP and the device attempting to connect to it require authentication before access to the network is permitted.
TTLS	Select this option to enable TTLS authentication.

Select an authentication type from the drop-down list and select **Next**. If **PEAP** or **TTLS** is selected, the **Tunneled** dialog box displays. If **None**, **EAP TLS** or **LEAP** is selected the **Encryption** dialog box displays. See [Encryption on page 7-16](#) for encryption options.

Tunneled Authentication

Use the **Tunneled Authentication** dialog box to select the tunneled authentication options. There are different selections available for PEAP or TTLS authentication. To select a tunneled authentication type:

**Figure 7-8** Tunneled Auth Dialog Box

1. Select a tunneled authentication type from the drop-down list.
2. Select the **User Certificate** check box if a certificate is required. The TLS tunnel type requires a user certificate, so the check box is automatically selected.
3. Select **Next**. The **Installed User Certs** dialog box displays.

[Table 7-7](#) lists the PEAP tunneled authentication options.

Table 7-7 PEAP Tunneled Authentication Options

PEAP Tunneled Authentication	Description
MS CHAP v2	Microsoft Challenge Handshake Authentication Protocol version 2 (MS CHAP v2) is a password-based, challenge-response, mutual authentication protocol that uses the industry-standard Message Digest 4 (MD4) and Data Encryption Standard (DES) algorithms to encrypt responses. The authenticating server challenges the access client and the access client challenges the authenticating server. If either challenge is not correctly answered, the connection is rejected. MS CHAP v2 was originally designed by Microsoft as a PPP authentication protocol to provide better protection for dial-up and virtual private network (VPN) connections. With Windows XP SP1, Windows XP SP2, Windows Server 2003, and Windows 2000 SP4, MS CHAP v2 is also an EAP type.
TLS	EAP TLS is used during the phase 2 of the authentication process. This method uses a user certificate to authenticate.

[Table 7-8](#) lists the TTLS tunneled authentication options.

Table 7-8 TTLS Tunneled Authentication Options

TTLS Tunneled Authentication	Description
CHAP	Challenge Handshake Authentication Protocol (CHAP) is one of the two main authentication protocols used to verify the user name and password for PPP Internet connections. CHAP is more secure than PAP because it performs a three way handshake during the initial link establishment between the home and remote machines. It can also repeat the authentication anytime after the link has been established.
MS CHAP	Microsoft Challenge Handshake Authentication Protocol (MS CHAP) is an implementation of the CHAP protocol that Microsoft created to authenticate remote Windows workstations. In most respects, MS CHAP is identical to CHAP, but there are a few differences. MS CHAP is based on the encryption and hashing algorithms used by Windows networks, and the MS CHAP response to a challenge is in a format optimized for compatibility with Windows operating systems.
MS CHAP v2	MS CHAP v2 is a password based, challenge response, mutual authentication protocol that uses the industry standard Message Digest 4 (MD4) and Data Encryption Standard (DES) algorithms to encrypt responses. The authenticating server challenges the access client and the access client challenges the authenticating server. If either challenge is not correctly answered, the connection is rejected. MS CHAP v2 was originally designed by Microsoft as a PPP authentication protocol to provide better protection for dial-up and virtual private network (VPN) connections. With Windows XP SP1, Windows XP SP2, Windows Server 2003, and Windows 2000 SP4, MS CHAP v2 is also an EAP type.
PAP	Password Authentication Protocol (PAP), has two variations PAP and CHAP PAP. It verifies a user name and password for PPP Internet connections, but it is not as secure as CHAP, since it works only to establish the initial link. PAP is also more vulnerable to attack because it sends authentication packets throughout the network. Nevertheless, PAP is more commonly used than CHAP to log in to a remote host like an Internet service provider.
MD5	Message Digest-5 (MD5) is an authentication algorithm developed by RSA. MD5 generates a 128-bit message digest using a 128-bit key, IPsec truncates the message digest to 96 bits.

User Certificate Selection

If the **User Certificate** check box on the **Tunneled Authentication** dialog box is checked or if **TLS** is the selected authentication type, then the **Installed User Certificates** dialog box displays. The user is required to select a certificate before proceeding. Select a certificate from the drop-down list of currently installed certificates. When a certificate is selected its name appears in the drop-down list. If the required certificate is not in the list, it must be installed.



Figure 7-9 *Installed User Certs Dialog Box*

User Certificate Installation

To install a user certificate (EAP TLS only) and a server certificate for EAP TLS and PEAP authentication:

1. Select **Install Certificate**. The **Credentials** dialog box displays.




Figure 7-10 *Credentials Dialog Box*

2. Enter the **User:**, **Pwd:** (password), and **Server:** information in their respective text boxes.
3. Select **Retrieve**. A **Progress** dialog appears to indicate the status of the certificate retrieval.
4. Select **ok** to exit.

After the installation is complete, the **Installed User Certs** dialog box displays and the certificate is available in the drop-down list for selection.



NOTE In order to successfully install a user certificate, the device must already be connected to a network from which the server is accessible.

Server Certificate Selection

If the **Validate Server Cert** check box is checked, a server certificate is required. The wizard displays the **Installed Server Certs** dialog box and a certificate must be selected before proceeding. An hour glass may be displayed as the wizard populates the existing certificate list. If the required certificate is not listed, then it must be installed.

To select a certificate:

1. Select the **Install Certificate** button to install a certificate.



Figure 7-11 *Installed Server Certs Dialog Box*

A dialog box displays that lists the currently loaded certificate files found in the default directory (Application) with the default extension.




Figure 7-12 *Browse Server Certificates*

2. Navigate to the folder where the certificate is stored. Select the certificate filename and then select **ok**.

3. A confirmation dialog verifies the installation. If the information in this dialog is correct, select the **Yes** button, If the information in this dialog is not correct select the **No** button. The wizard returns to the **Installed Server Certs** dialog box.




Figure 7-13 Confirmation Dialog Box

Credential Cache Options

If any of the password based authentication types are chosen, then different credential caching options may be specified. These options allow an administrator to specify when the network credentials prompts appear. The network credentials prompts can be set to appear; at connection, on each resume, or at a specified time.

An administrator can enter the credentials directly into the profile which permanently caches the credentials. In this case, user login to the device is not required. If a profile does not contain credentials entered through the configuration editor, then the user must login to the device before connecting.

Caching options only apply on credentials that are entered through the login dialog box.



Figure 7-14 Prompt for Login at Dialog Box

If the device does not have the credentials, the user is prompted to enter a username and password. If the device has the credentials (previous entered via a login dialog box), it uses these credentials unless the caching options require the device to prompt for new credentials. If the credentials were entered via the profile, the device does not prompt for new credentials. [Table 7-9](#) lists the caching options.

Table 7-9 *Cache Options*


	Description
At Connect	If this option is selected, then a user is prompted for credentials whenever the WCS tries to connect to a new profile. If this option is not set, then the cached credentials are used to authenticate. If the credentials are not cached, then the user is prompted to enter credentials. This option only applies if a user is logged in.
On Resume	If the On Resume option is selected, an authenticated user is reauthenticated when a suspend/resume occurs. Once the user is reauthenticated, the user is prompted for credentials. If the user does not enter the same credentials that were entered prior to the suspend/resume, the user is disconnected from the network. The user may try up to three times to enter the correct credentials. If the correct credentials are entered, then the network connection remains intact. This option only applies if a user is logged in.
At Time	Use this option to perform a local verification on an authenticated user at a specified time. The time can be an absolute time or a relative time from the authentication, the times should be at least 5 minutes intervals. Once the time has passed, the user is prompted for credentials. If the user enters the correct credentials, the network connection remains intact. If the user enters the wrong credentials, the user is disconnected from the network. The user may try up to three times to enter the correct credentials. If the correct credentials are entered, then the network connection remains intact. This option only applies if a user is logged in.

When a user enters the credentials, the credentials are applied to a particular profile. If a user logs out, all of the cached credentials are cleared. If a profile is edited, then all cached credentials for that profile are cleared.

The following authentication types have credential caching:

- EAP TLS
- PEAP
- LEAP
- TTLS.

If the **At Time** check box is selected the *Time Cache Options* dialog box displays.

**Figure 7-15** *Time Cache Options Dialog Box*

1. Select the **Interval** radio button to check credentials at a set time interval.
2. Enter the value in minutes, in the **Min** box.
3. Select **Next** to continue.
4. Select the **At (hh:mm)** radio button to check credentials at a set time.

5. Select **Next**. The **At Time** dialog box displays.



Figure 7-16 *At Time Dialog Box*

6. Enter the time using the 24 hour clock format in the **(hh:mm)** box.
7. Select **>** to move the time to the right. Repeat for additional time periods.
8. Select **Next**. The **User Name** dialog box displays.

User Name

The user name and password can be entered (but is not required) when the profile is created. When a profile authenticates with credentials that were entered in the profile, caching rules do not apply. Caching rules only apply on credentials that are entered through the login dialog box.




Figure 7-17 *Username Dialog Box*

Password

Use the **Password** dialog box to enter a password. If EAP/TLS is the selected authentication type, the password is not required and the field is disabled.




Figure 7-18 *Password Dialog Box*

1. Enter a password in the **Password** field.

2. Select the **Advanced ID** check box, if advanced identification is required.
3. Select **Next**, the **Encryption** dialog box displays. See [Encryption on page 7-16](#) for setting the encryption information.

Advanced Identity

Use the **Advanced ID** dialog box to enter the 802.1X identity. The 802.1X identity value can be 63 characters long and is a case sensitive identity supplied to the authenticator. In TTLS and PEAP, it is recommended that this field not contain a true identity, but instead the identity **anonymous**, plus any desired realm (e.g. anonymous@myrealm). A user ID is required before proceeding.

✓ **NOTE** When authenticating with a Microsoft IAS server, do not use advanced identity.




Figure 7-19 Advanced Identity Dialog Box

Select **Next**, the **Encryption** dialog box displays.

Encryption

Use the **Encryption** dialog box to select an encryption type. The **Encryption** dialog box only allows encryption types that can be used with the currently selected authentication type. See [Table 7-11](#) for the encryption types available with each authentication type.



Figure 7-20 Encryption Dialog Box

Table 7-10 Encryption Options

Encryption	Description
Open	Use the <i>Open</i> option as the default setting when no data packet encryption is needed over the network. Selecting this option provides no security for the data being transmitted over the network.
40-Bit WEP	Select 40-Bit WEP for the adapter to use the 40-bit key length WEP encryption. WEP keys are manually entered in the edit boxes. Only the required number of edit boxes for a key length is displayed (10 Hex digit value for 40-bit keys). Use the Key Index drop-down list to configure the four WEP keys. The adapter uses the selected key. Note: The default Hex digit keys are visible any time they are used. As a security precaution after setting the key values for the network, the digits are replaced with asterisks * within the encryption key fields. If the associated AP is using an optional passkey, the active adapter WLAN profile is required to use one as well. The passkey is a plain text representation of the WEP keys displayed in the encryption dialog box. The passkey provides an easy way to enter WEP key data without having to remember the entire 40-bit (10 character) Hex digit string.
128-Bit WEP	Select 128-Bit WEP for the adapter to use the 128-bit key length WEP encryption. WEP keys are manually entered in the edit boxes. Only the required number of edit boxes for a key length is displayed (26 Hex digit value for 128-bit keys). Use the Key Index drop-down list to configure the four WEP keys. The adapter uses the selected key. Note: The default Hex digit keys are visible any time they are used. As a security precaution after setting the key values for the network, the digits are replaced with asterisks * within the encryption key fields. If the associated AP is using an optional passkey, the active adapter WLAN profile is required to use one as well. The passkey is a plain text representation of the WEP keys displayed in the encryption dialog box. The passkey provides an easy way to enter WEP key data without having to remember the entire 128-bit (26 character) Hex digit string.
TKIP	Select this option to use Wireless Protected Access (WPA) via TKIP. Manually enter the shared keys in the passkey field. Select Next to display the passkey dialog box. Enter an 8 to 63 character string.
AES (Fusion 2.5 only)	Select this option to use Advanced Encryption Standard (AES). Manually enter the shared keys in the passkey field. Select Next to display the passkey dialog box. Enter an 8 to 63 character string.

Table 7-11 Encryption / Authentication Matrix

Authentication	Encryption			
	Open	WEP	TKIP	AES (Fusion 2.5 only)
None	Yes	Yes	Yes	Yes
EAP TLS	No	Yes	Yes	Yes
PEAP	No	Yes	Yes	Yes
LEAP	No	Yes	Yes	Yes
TTLS	No	Yes	Yes	Yes

Key Entry Page

If either **40-Bit WEP** or **128-Bit WEP** is selected the wizard proceeds to the key entry dialog box unless the **Use Passkey** check box was selected in the Encryption Dialog Box (see [Figure 7-20 on page 7-16](#)). The **Key Entry** dialog box will be shown only if the authentication is set to **None**. To enter the key information:

1. Enter the 40-bit or 128-bit keys into the fields.
2. Select **Next**.



Figure 7-21 40-Bit WEP Keys Dialog Box




Figure 7-22 128-Bit WEP Keys Dialog Box

Passkey Dialog

When a user selects **None** as an authentication and **WEP** as an encryption, the user can choose to enter a passkey by checking the **Use PassKey** check box. The user is prompted to enter the passkey. For WEP, the **Use PassKey** checkbox is only available if the authentication is **None**.

When a user selects **None** as an authentication and **TKIP** as an encryption, the user is forced to enter a passkey. The user cannot enter a passkey if the encryption is **TKIP** and the authentication is anything other than **None**.

When you select **None** as an authentication and **AES** as an encryption, you must enter a passkey. The user cannot enter a passkey if the encryption is **AES** and the authentication is anything other than **None**.



Figure 7-23 Passkey Dialog Box

Select **Next**. The **IP Mode** dialog box displays.

IP Mode

Use the **IP Mode** dialog box to configure network address parameters: IP address, subnet, gateway, DNS and WINS.




Figure 7-24 IP Config Tab (DHCP)

Table 7-12 IP Mode Options

Encryption	Description
DHCP	Select Dynamic Host Configuration Protocol (DHCP) from the IP Mode drop-down list to obtain a leased IP address and network configuration information from a remote server. DHCP is the default setting for the device profile. When DHCP is selected, the IP address fields are read-only.
Static	Select Static to manually assign the IP, subnet mask, default gateway, DNS and WINS addresses used by the device profile.

Select either **DHCP** or **Static** from the drop-down list and then select **Next**. If **Static IP** is selected, the **IP Address Entry** dialog box displays. If **DHCP** is selected, the **Transmit Power** dialog box displays.

IP Address Entry

Use the **IP Address Entry** dialog box to enter the IP address and subnet information.




Figure 7-25 Static IP Address Entry Dialog Box

Table 7-13 Static IP Address Entry Fields

Field	Description
IP Address	The Internet is a collection of networks with users that communicate with each other. Each communication carries the address of the source and destination networks and the particular machine within the network associated with the user or host computer at each end. This address is called the IP address (Internet Protocol address). Each node on the IP network must be assigned a unique IP address that is made up of a network identifier and a host identifier. Enter the IP address as a dotted-decimal notation with the decimal value of each octet separated by a period, for example, 192.168.7.27.
Subnet Mask	Most TCP/IP networks use subnets in order to effectively manage routed IP addresses. Having an organization's network divided into subnets allows it to be connected to the Internet with a single shared network address, for example, 255.255.255.0.

Select the **Advanced** check box to enter additional address information.

If the **Advanced** check box is selected then selecting **Next** displays the **Advanced Address Entry** dialog box to enter the Gateway, DNS, and WINS address. If the **Advanced** check box is not selected then selecting **Next** displays the **Transmit Power** dialog box.

**Figure 7-26** Advanced Address Entry Dialog Box

The IP information that is entered in the profile is only used when the **Enable IP Mgmt** check box is enabled in the **Options > System Options** dialog box ([System Options on page 7-36](#)). When **Enable IP Mgmt** check box is disabled, the IP information in the profile is ignored and the IP information entered in the Microsoft interface applies.

Table 7-14 IP Config Advanced Address Entry Fields

Field	Description
G/W	The default Gateway is a device that is used to forward IP packets to and from a remote destination.
DNS	The Domain Name System (DNS) is a distributed Internet directory service. DNS is used mostly to translate domain names and IP addresses. It is also used to control Internet email delivery. Most Internet service requires DNS to operate properly. If DNS is not configured, Web sites cannot be located and/or email delivery fails.
WINS	WINS is a Microsoft® Net BIOS name server. WINS eliminates the broadcasts needed to resolve computer names to IP addresses by providing a cache or database of translations.

Select **Next**. The **Transmit Power** dialog box displays.

Transmit Power

The transmit power can be selected for both Ad-Hoc and Infrastructure network types. The **Transmit Power** drop-down list contains different options for each mode. Automatic (i.e. use the current AP settings) and Power Plus (use higher than the current AP settings) are available for **Infrastructure** mode.

Adjusting the **Radio Transmission Power** level enables the user to expand or confine the transmission area with respect to other wireless devices that could be operating nearby. Reducing a coverage area in high traffic areas improves transmission quality by reducing the amount of interference in that coverage area.




Figure 7-27 Transmit Power Dialog Box (Infrastructure Mode)

Table 7-15 Transmit Power Dialog Box (Infrastructure Mode)

Field	Description
Automatic	Select Automatic to use the AP power level. Automatic is the default mode for devices operating in Infrastructure mode.
Power Plus	Select Power Plus to set the device transmission power one level higher than the level set for the AP.




Figure 7-28 Transmit Power Dialog Box (Ad-Hoc Mode)

Table 7-16 Power Transmit Options (Ad-Hoc Mode)

Field	Description
Full	Select Maximum power to set the device to the highest transmission power level. Select Maximum power when operating in highly reflective environments and areas where other devices could be operating nearby. Additionally, use the maximum power level when attempting to communicate with devices at the outer edge of a coverage area.
30 mW	Select 30 mW, to set the transmit power level to that power level.
15 mW	Select 15 mW, to set the transmit power level to that power level.
5 mW	Select 5 mW to set the transmit power level to that power level.
1 mW	Select Minimum power to set the device to the lowest transmission power level. Use the minimum power level when communicating with other devices in very close proximity. Additionally, select minimum power in instances where little or no radio interference from other devices is anticipated.

Select **Next** to implement power consumption changes for the device profile. the **Battery Usage** dialog box displays.

Battery Usage

Use the **Battery Usage** dialog box to select power consumption of the wireless LAN. There are three settings available: CAM, Fast Power Save and MAX Power Save. Battery Usage cannot be configured in Ad-Hoc profiles.

**Figure 7-29** Battery Usage Dialog Box

NOTE Power consumption is also related to the transmit power settings.

Table 7-17 Battery Usage Options

Field	Description
CAM	Continuous Aware Mode (CAM) provides the best network performance, but yields the shortest battery life.
Fast Power Save	Fast Power Save performs in the middle of CAM and MAX Power Save with respect to network performance and battery life. Default.
MAX Power Save	Max Power Save yields the longest battery life while potentially reducing network performance. In networks with minimal latency. Max Power Save will perform just as well as Fast Power Save, but with increased battery savings.

Manage Profiles Application

The *Manage Profiles* window provides a list of user-configured wireless profiles. Define up to 32 profiles at any one time. On the *Wireless Companion* menu, press the up or down *Scroll* key to highlight *Manage Profiles* and press *ENT* to display the *Manage Profiles* window.



Figure 7-30 *Manage Profiles Window*

Icons next to each profile identify the profiles current state.

Table 7-18 *Profile Icons*

Icon	Description
No Icon	Profile is not selected, but enabled.
	Profile is disabled.
	Profile is Cancelled. A Cancelled profile is disabled until a connect or login function is performed through the configuration editor.
	Profile is currently in use and describes an infrastructure profile not using encryption.
	Profile is currently in use and describes an infrastructure profile using encryption.
	Profile is currently in use and describes an ad-hoc profile not using encryption.
	Profile is currently in use and describes an ad-hoc profile using encryption.
	Profile is not valid in the device current operating regulatory domain.

The profiles are listed in priority order for use by the automatic roaming feature. Change the order by moving profiles up or down. Edit existing profiles by selecting one in the list and then pressing *ENT* to display the menu. The menu allows the selected profile to be connected, edited, disabled (enabled) or deleted. (Note: the **Disable** menu item changes to **Enable** if the profile is already disabled.)

A dialog displays to confirm the users desire to delete a profile, if selected.

Changing Profiles

A completed profile is a set of configuration settings that can be used in different locations to connect to a wireless network. Creating different profiles is a good way of having pre-defined operating parameters available for use in various network environments. When the **WLAN Profiles** window initially displays, existing profiles appear in the list.

Select a profile from the list. Select **Connect** from the pop-up menu to set that profile as the active profile. Once selected, the device uses the authentication, encryption, ESSID, IP Config and power consumption settings initially configured for that profile.

Editing a Profile

Select a profile from the list. Select **Edit** from the pop-up menu to display the **Profile Wizard** where the ESSID and operating mode can be changed for the profile. Use the wizard to edit the profile power consumption and security parameters. See [Profile Editor Wizard on page 7-5](#) for procedure on using the wizard.

Creating a New Profile

Create new profiles from the *Manage Profiles* window by selecting *Add*. A menu with only the **Add** highlighted displays.

Select **Add** to display the **Profile Wizard** wherein the profile name and ESSID can be set. Use the **Profile Wizard** to set security, network address information and power consumption level for the new profile.

Deleting a Profile

To delete a profile from the list and select **Delete** from the pop-up menu. A confirmation dialog box displays.

Ordering Profiles

Select a profile from the list and select **Move Up** or **Move Down** from the pop-up to order the profile. If the current profile association is lost, the device attempts to associate with the first profile in the list and then the next until a new association is achieved.

✓ **NOTE** Profile Roaming must be enabled.

Export a Profile

To export a profile to a registry file, select a profile from the list and select **Export** from the pop-up menu. The **save As** dialog box displays with the **Application** folder and a default name of `WCS_PROFILE{profile GUID}.reg` (Globally Unique Identifier).




Figure 7-31 Save As Dialog Box

If required, change the **Name** field and select **OK**. A confirmation dialog box displays after the export is complete.

Wireless Status Application

The **Wireless Status** application window displays the current wireless connection status and information about the wireless connection.

To open the **Wireless Status** window, select the **Signal Strength** from the **Wireless Companion** menu. The **Wireless Status** window displays.




Figure 7-32 *Wireless Status Window*

The **Wireless Status** window contains the following options. Select the option to display the option window.

- Signal Strength - provides information about the connection status of the current wireless profile.
- Current Profile - displays basic information about the current profile and connection settings
- IPv4 Status - displays the current IP address, subnet and other IP related information assigned to the device
- Wireless Log - displays a log of important recent activity, such as authentication, association, DHCP renewal completion, in time order
- Versions - displays software, firmware and hardware version numbers
- Quit - Exits the *Wireless Status* window.

Option windows contain a back button () to return to the main *Wireless Status* window.

Signal Strength Window

The *Signal Strength* window provides information about the connection status of the current wireless profile that includes signal quality, missed beacons and transmit retry statistics. The BSSID address (shown as “AP MAC Address”) displays the AP currently associated with the connection. If Ad-Hoc mode is in use, the AP MAC Address shows the BSSID of the Ad-Hoc network. All information in this window updates every 2 seconds.

To open the *Signal Strength* window, select **Signal Strength** in the *Wireless Status* window. The *Signal Strength* window displays.




Figure 7-33 *Signal Strength Window*

After viewing the *Signal Strength* window, select the back button to go back to the *Wireless Status* window.

Table 7-19 *Signal Strength Status*

Field	Description
Signal	<p>Displays the Relative Signal Strength Indicator (RSSI) of the signal transmitted between the AP and device. As long as the Signal Quality icon is green the AP association is not jeopardized. If the icon is red (poor signal), an association with a different AP could be warranted to improve the signal. The signal strength icon changes depending on the signal strength.</p> <ul style="list-style-type: none">  Excellent Signal  Very Good Signal  Good Signal  Fair Signal  Poor Signal  Out of Range (no signal)
Status	Indicates if the device is associated with the AP.
Signal Quality	Displays a text format of the Signal Quality icon.
Tx Retries	Displays a percentage of the number of data packets retransmitted by the device. The fewer transmit retries, the more efficient the wireless network is.


Table 7-19 *Signal Strength Status*

Field	Description
Missed Beacons	Displays a percentage of the amount of beacons missed by the device. The fewer transmit retries, the more efficient the wireless network is. Beacons are uniform system packets broadcast by the AP to keep the network synchronized.
Signal Level	The AP signal level in decibels per milliwatt (dBm).
Noise Level	The background interference (noise) level in decibels per milliwatt (dBm).
SNR	The access point/device Signal to Noise Ratio (SNR) of signal strength to noise (interference) in decibels per milliwatt (dBm).
Roaming Count	Displays the number of APs that the device has connect to while roaming.
AP MAC Address	Displays the MAC address of the AP to which the device is currently connected to.
Transmit Rate	Displays the current rate of the data transmission.

Current Profile Window

The *Current Profile* window displays basic information about the current profile and connection settings. This window updates every two seconds.

To open the *Current Profile* window, select *Current Profile* in the *Wireless Status* window. The *Current Profile* window displays.

**Figure 7-34** *Current Profile Window***Table 7-20** *Current Profile Fields*

Field	Description
Profile Name	Displays the current profile name that the device is using to communicate with the AP.
ESSID	Displays the current profile ESSID name.
Mode	Displays the current profile mode, either Infrastructure or Ad-Hoc.
Security Mode	Displays the current profile's security mode.
Authentication	Displays the current profile's authentication type.
Encryption	Displays the current profile's encryption type.


Table 7-20 *Current Profile Fields (Continued)*

Field	Description
Channel	Displays the current profile channel setting.
Country	Displays the current profile country setting.
Transmit Power	Displays the radio transmission power level.

IPv4 Status Window

The *IPv4 Status* window displays the current IP address, subnet and other IP related information assigned to the device. It also allows the address to be renewed if the profile is currently using DHCP to obtain the IP information. When the user select **Renew** a full DHCP discover initiates. The *IPv4 Status* window should update automatically when the IP address changes.

To open the *IPv4 Status* window, select **IPv4 Status** in the *Wireless Status* window. The *IPv4 Status* window displays.

**Figure 7-35** *IPv4 Status Window***Table 7-21** *IPv4 Status Fields*

Field	Description
IP Type	Displays the IP type for the current profile, either DHCP or Static. If the current IP type is DHCP, leased IP address and network address data display for the device. If the current IP type is Static, the values displayed were input manually in the IP Config tab on page 7-19.
IP Address	Displays the IP address assigned to the device. The Internet is a collection of networks with users that communicate with each other. Each communication carries the address of the source and destination networks and the particular machine within the network associated with the user or host computer at each end. This address is called the IP address. Each node on the IP network must be assigned a unique IP address that is made up of a network identifier and a host identifier. The IP address as a dotted-decimal notation with the decimal value of each octet separated by a period, for example, 192.168.7.27.
Subnet	Displays the subnet address. Most TCP/IP networks use subnets in order to effectively manage routed IP addresses. Having an organization's network divided into subnets allows it to be connected to the Internet with a single shared network address, for example, 255.255.255.0.
Gateway	Displays the gateway address. A gateway is a device that is used to forward IP packets to and from a remote destination.

Table 7-21 IPv4 Status Fields (Continued)

Field	Description
DCHP Server	The Domain Name System (DNS) is a distributed Internet directory service. DNS is used mostly to translate domain names and IP addresses. It is also used to control Internet e-mail delivery. Most Internet service requires DNS to operate properly. If DNS is not configured, Web sites cannot be located or e-mail delivery fails.
Lease Obtained	Displays the date that the IP Address was obtained.
Lease Expires	Displays the date that the IP Address expires and a new IP Address is requested.
DNS	Displays the IP Address of the DNS server.
WINS	WINS is a Microsoft Net BIOS name server. WINS eliminates the broadcasts needed to resolve computer names to IP addresses by providing a cache or database of translations.
MAC	An IEEE 48-bit address the device is assigned at the factory that uniquely identifies the adapter at the physical layer.
Host Name	Displays the name of the device.

Wireless Log Window

The *Wireless Log* window displays a log of important recent activity, such as authentication, association, DHCP renewal completion, in time order. Users can choose to save the log to a file or to clear the log (within this instance of the application only). There is also an auto scroll feature to automatically scroll down when new items are added to the log.

To open the *Wireless Log* window, select *Wireless Log* in the *Wireless Status* window. The *Wireless Log* window displays.

**Figure 7-36** Wireless Log Window

Saving a Log

To save a Wireless Log:

1. Select the **Save** button. The **Save As** dialog box displays.
2. Navigate to the desired folder.
3. In the **Name** field, enter a file name and then select **OK**. A text file is saved in the selected folder.

Clear the Log

To clear the log, select **Clear**.

Versions Window

The *Versions* window displays software, firmware and hardware version numbers. This window only updates each time it is displayed. There is no need to update constantly. The content of the window is determined at runtime, along with the actual hardware and software to display in the list. Executable paths of the software components on the list are defined in registry, so that the application can retrieve version information from the executable. “File not found” is displayed if the executable cannot be found at the specified path.

To open the *Versions* window, select **Versions** in the *Wireless Status* window. The *Versions* window displays.




Figure 7-37 *Versions Window*

The window displays software version numbers for the following:

- Configuration Editor (Fusion 2.4 and below)
- Fusion Build
- LoginService
- Photon10
- PublicAPI (Fusion 2.5 and above)
- WCConfigEd (Fusion 2.5 and above)
- WCDig
- WCLaunch
- WCSAPI
- WCSRV
- WCStatus.

Wireless Diagnostics Application

The *Wireless Diagnostics* application window provides links to perform ICMP Ping, Trace Routing and Known APs.

To open the *Wireless Diagnostics* window, select **Signal Strength** on the **Wireless Diagnostics** window. The *Wireless Diagnostics* window displays.




Figure 7-38 *Wireless Diagnostics* Window

The *Wireless Diagnostics* window contains the following options. Select the option to display the option window.

- ICMP Ping - tests the wireless network connection.
- Trace Route - tests a connection at the network layer between the device and any place on the network.
- Known APs - displays the APs in range using the same ESSID as the device.
- Quit - Exits the *Wireless Diagnostics* window.

Option windows contain a back button () to return to the main *Wireless Diagnostics* window.

ICMP Ping Window

The *ICMP Ping* window allows a user to test a connection at the network layer (part of the IP protocol), between the device and an AP. Ping tests only stop when the user selects the **Stop Test** button, closes the *Wireless Diagnostics* application, or if the device switches between infrastructure and ad-hoc modes.

To open the *ICMP Ping* window, select the *ICMP Ping* in the *Wireless Diagnostics* window. The *ICMP Ping* window displays.




Figure 7-39 ICMP Ping Window

To perform an ICMP ping:

1. In the **IP** field, enter an IP address or select an IP address from the drop-down list.
2. From the **Size** drop-down list, select a size value.
3. Select **Start Test**. The ICMP Ping test starts. Information of the ping test displays in the appropriate fields.

Trace Route Window

Trace Route traces a packet from a computer to a host, showing how many hops the packet requires to reach the host and how long each hop takes. The **Trace Route** utility identifies where the longest delays are occurring.

The *Trace Route* window allows a user to test a connection at the network layer (part of the IP protocol), between the device and any place on the network.

To open the *Trace Route* window, select *Trace Route* in the *Wireless Diagnostics* window. The *Trace Route* window displays.




Figure 7-40 Trace Route Window

A user can enter an IP address or a DNS Name in the IP combo box, and select Start Test. The IP combo box should match the same information as shown in the **ICMP Ping** window's IP combo box. When a test is started, the trace route attempts to find all routers between the device and the destination. The Round Trip Time (RTT) between the device and each router is shown, and then the total test time is also shown. The total test time may be longer than all RTTs added together because it is not just including time on the network.

Known APs Window

The **Known APs** window displays the APs in range using the same ESSID as the device. This window only available when in the **Infrastructure** mode.

To open the **Known APs** window, select **Known APs** in the **Wireless Diagnostics** window. The **Known APs** window displays.




Figure 7-41 Known APs Window

The icon next to the AP indicates:

-  The AP is the currently associated access point, and it is set to mandatory.
-  The AP is the currently associated access point, but it is not set to mandatory.
-  The device is not currently associated to this AP, but the AP is set as mandatory.
-  The device is not currently associated to this AP, and AP is not set as mandatory.

Select an AP to display a pop-up menu with the following options: Set Mandatory and Set Roaming.

Select Set Mandatory to prohibit the device from associating with a different AP. The letter M displays on top of the icon. The device connects to the selected AP and never roams until:

- Set Roaming is selected.
- Set Mandatory is selected on a different AP.
- Manually connecting to a profile from the Manage Profiles page.
- The device roams to a new profile.
- The device resets (warm or cold).

Select Set Roaming to allow the device to roam to any AP with a better signal. These settings are temporary and never saved to the registry.

Select Refresh to update the list of the APs with the same ESSID.

Options

Use the wireless *Option* dialog box to select various operation settings. The options are saved when **Save** is selected. If the user selects **X** before saving and an option was changed, a dialog box displays asking the user to close without saving the changes.

The options are:

- Operating Mode Filtering
- Regulatory
- Band Selection
- System Options
- Change Password
- Export.

Operating Mode Filtering

The Operating Mode Filtering options cause the Find WLANs application to filter the available networks found.



Figure 7-42 *OP Mode Filtering Dialog Box*

The default value has both **AP Networks** and **Ad-Hoc Networks** enabled.

Table 7-22 *OP Mode Filtering Options*

Field	Description
AP Networks	Select the AP Networks check box to display available AP networks and their signal strength within the Available WLAN Networks (see Find WLANs Application on page 7-4). These are the APs available to the device profile for association. If this option was previously disabled, refresh the Available WLAN Networks window to display the AP networks available to the device.
AD-Hoc Networks	Select the Ad-Hoc networks check box to display available peer (adapter) networks and their signal strength within the Available WLAN Networks . These are peer networks available to the device profile for association. If this option was previously disabled, refresh the Available WLAN Networks window to display the Ad Hoc networks available to the device.

Select **Save** to save the settings or select **X** to discard any changes.

Regulatory Options

Use the Regulatory settings to configure the country the device is in. Due to regulatory requirements (within a country) a device is only allowed to use certain channels.



Figure 7-43 Regulatory Options Dialog Box

Table 7-23 Regulatory Options

Field	Description
Settings	Select the country of use from the drop-down list. In order to connect to a profile, the profile country must match this setting, or the AP country setting if the Enable 802.11d check box is selected.
Enable 802.11d	With this check box selected, the WLAN adapter attempts to retrieve the country from APs. Profiles which use Infrastructure mode are only able to connect if the country set is the same as the AP country settings or if the profile country setting is set to Allow Any Country . Check this box requires that ALL APs be configured to transmit the country information.

Band Selection

The *Band Selection* settings identify the frequency bands to be scanned when finding WLANs. These values refer to the 802.11 standard networks.



Figure 7-44 Band Selection Dialog Box

Table 7-24 Band Selection Options

Field	Description
2.4GHz Band	With this box checked, the Find WLANs application list includes all networks found in the 2.4 GHz band (802.11b and 802.11g).
5GHz Band	With this box checked, the Find WLANs application list includes all networks found in the 5 GHz band (802.11a).

Select **Save** to save the settings or select **X** to discard any changes.

System Options

Use the system options to set miscellaneous system setting.



Figure 7-45 System Options Dialog Box

Table 7-25 Band Selection Options

Field	Description
Profile Roaming	Select the Profile Roaming check box to configure the device to roam to the next available WLAN profile when it moves out of range of the current WLAN profile.
Enable IP Mgmt	Select Enable IP Mgmt check box to enable the Wireless Companion Services to handle IP Address management. When checked, the Wireless Companion Service configures the IP based on what is configured in the network profile. If unchecked, the Wireless Companion Service does not configure the IP information. For this case, the user must configure the IP in the standard Windows IP dialog window. Enabled by default.
Auto Time Config	Select Auto Time Config check box to enable automatic update of the system time. The device time is updated during network association, based on the time as set in the AP. This proprietary feature is only supported with Symbol infrastructure. Enabled by default.

Change Password Dialog Box

Use the **Change Password** dialog box to require a password before any profile can be edited. This allows system administrators to pre-configure profiles and not allow a user to change the network settings. The user could also use this feature to protect their settings from a guest user. By default, the password is not set.



Figure 7-46 Change Password Window

1. To create a password for the first time, leave the **Current:** text box empty and enter the new password in the **New:** and **Confirm:** text boxes. Select **Save**.
2. To change an existing password, enter the current password in the **Current:** text box, enter the new password in the **New:** and **Confirm:** text boxes. Select **Save**.
3. Delete the password, in this case enter the current password in the **Current:** text box and leave the **New:** and **Confirm:** text boxes empty.



NOTE Passwords are case sensitive and can not exceed 160 characters.

Export

Use the **Export** dialog box to export all profiles to a registry file, and to export the options to a registry file. Each of these export functions prompts the user for a filename that is used as the registry file. The “save” dialog box defaults to the application folder, and has a default file name to use. For exporting all profiles, the default filename is: WCS_PROFILES.REG. For exporting the options, the default filename is: WCS_OPTIONS.REG.



Figure 7-47 Options - Export Dialog Box

To export options:

1. Select **Export Options**. The **Save As** dialog box displays.



Figure 7-48 Export Options Save As Dialog Box

2. The default folder is `\Application\FusionApps\Certs\`.
3. In the Name field, enter a file name.
4. Select **OK**.

To export all profiles:

1. Select **Export All Profiles**. The **Save As** dialog box displays.



Figure 7-49 Export All Profiles Save AS Dialog Box

2. Navigate to the desired folder.
3. In the **Name** field, enter a file name.
4. Select **OK**.

When **Export All Profiles** is selected the current profile is also saved. This information is used to determine which profile to connect with after a warm boot or cold boot.

Cold Boot Persistence

Exporting options and profiles can be used to provide cold boot persistence. If the exported registry files are saved in the **Application** folder, they are automatically utilized on a cold boot, restoring previous profile and option settings.

Currently, only server certificates can be saved for cold boot persistence. To save server certificates for cold boot persistence, the certificate files must be placed in the folder **Application**. Saving the certificates to this folder causes the certificates to be installed automatically on a cold boot.



NOTE User certificates cannot be saved for cold boot persistence at this time.

Registry Settings

Some of the parameters can be modified through a registry key. The registry path is:

HKLM\SOFTWARE\Symbol Technologies, Inc.\Configuration Editor

Table 7-26 *Registry Parameter Settings*

Key	Type	Default	Description												
CertificateDirectory	REG_SZ	\\Application	The default directory to find certificates.												
EncryptionMask	REG_DWORD	0x0000001F	<p>Defines the encryption types that are currently supported. This is a bitwise mask with each bit corresponding to an encryption type. 1 = Type is supported, 0 = Type is not supported</p> <table border="0"> <thead> <tr> <th>Bit Number</th> <th>Encryption Type</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>None</td> </tr> <tr> <td>1</td> <td>40-Bit WEP</td> </tr> <tr> <td>2</td> <td>128-Bit WEP</td> </tr> <tr> <td>3</td> <td>TKIP</td> </tr> <tr> <td>4</td> <td>AES (Fusion 2.5 and above only)</td> </tr> </tbody> </table>	Bit Number	Encryption Type	0	None	1	40-Bit WEP	2	128-Bit WEP	3	TKIP	4	AES (Fusion 2.5 and above only)
Bit Number	Encryption Type														
0	None														
1	40-Bit WEP														
2	128-Bit WEP														
3	TKIP														
4	AES (Fusion 2.5 and above only)														

Login, Log Off Application

When the user launches the login, log off application, the device may be in two states; the user may already be logged onto the device (having already entering credentials through the login box) or the user is not logged on. Each of these states have a separate set of use cases and a different look to the dialog box.

User Already Logged In

If already logged in to the device, launch the login dialog box to:

- Connect to and re-enable a cancelled profile. To perform this function:
 - Launch the Log On/Off dialog.
 - Select the cancelled profile from the profile list.
 - Login to the profile.

NOTE: Cancelled profiles can also be re-enabled by using the Profile Editor Wizard and choosing to connect to the cancelled profile. Cancelled profiles are also be re-enabled when a new user logs on.
- Logoff the device, to prevent another user from accessing the current users network privileges.
- Switch device users, to quickly logoff the device and allow another user to log into the device.

No User Logged In

To access user profiles, when no user is logged in, launch the login dialog box and login.

The dialog displays differently if it is:

- Launched by WCS, when the service is connecting to a new profile that needs credentials
- Launched by WCS, when the service is trying to verify the credentials due to credential caching rules
- Launched by a user, when a user is logged in
- Launched by a user, when no user is logged in.

Table 7-27 Log On/Off Options

Field	Description
Wireless Profile Field	When launching the login application, the Wireless Profile field has available all the wireless profiles that require credentials. This includes profiles that use EAP TLS, PEAP, LEAP, and EAP-TTLS.
Profile Status Icon	The profile status icon (next to the profile name) shows one of the following states: The selected profile is cancelled. The selected profile is enabled but is not the current profile. The profile is the current profile (always the case for WCS Launched).

Table 7-27 Log On/Off Options (Continued)

Field	Description
Network Username and Password Fields	The Network Username and Network Password fields are used as credentials for the profile selected in the Wireless Profile field. Currently these fields are limited to 159 characters.
Mask Password Checkbox	The <i>Mask Password</i> checkbox determines whether the password field is masked (i.e., displays only the '*' character) or unmasked (i.e., displays the entered text). Check the box to unmask the password. Uncheck the box to mask the password (the default).
Status Field	The status field displays status that is important to the login dialog. If the user opens the dialog and needs to prompt for credentials for a particular profile at this time, it can use the status field to let the user know that the network is held up by the password dialog being open.

Selecting **OK** sends the credentials though WCS API. If there are no credentials entered, a dialog box displays informing the user which field was not entered.

The **Log Off** button only displays when a user is already logged on. When the **Log Off** button is selected, the user is prompted with three options: Log Off, Switch Users, and Cancel. Switching users logs off the current user and re-initialize the login dialog box to be displayed for when there is no user logged on. Logging off logs off the current user and close the login dialog box. Selecting **Cancel** closes the Log Off dialog box and the Login dialog box displays.

When the user is logged off, the device only roams to profiles that do not require credentials or to profiles that were created with the credentials entered into the profile

The **Cancel** button closes the dialog without logging into the network. If the login dialog was launched by the WCS and not by the user, selecting **Cancel** first causes a message box to display a warning that the cancel disables the current profile. If the user still chooses to cancel the login at this point, the profile is cancelled.

Once a profile is cancelled, the profile is suppressed until a user actively re-enables it or a new user logs onto the device.

BTEplorer

BTEplorer is used to configure Bluetooth services and settings as well as to establish connections to other Bluetooth devices.



NOTE ADCServices must be disabled in order to use BTEplorer.

Refer to the *MT2090/MT2070 User Guide* (p/n 72E-117859-xx) for detailed information about BTEplorer settings.

Chapter 8 Staging and Provisioning

Introduction

This chapter describes how to stage devices using Rapid Deployment and provisioning using MSP Agent or AirBEAM Smart.

✓ **NOTE** Screens and windows pictured are samples and can differ from actual screens.

Staging

Staging is the process of setting up the device to download packages for provisioning. The device uses the Rapid Deployment (RD) Client for staging.

RD Client Version 3.28

The RD Client version 3.28 enables simple and rapid provisioning of new (out of the box) devices and simplifies the out-of-box provisioning by scanning bar codes or connecting to a profile server. The RD Client acts as a frontend for wireless radio configuration, automating the manual configurations that would normally be required to use these tools.

✓ **NOTE** The MSP 3.X Rapid Deployment Client enables staging by scanning staging profiles encoded into staging bar code sheets. It also enables staging to be performed without scanning bar codes through the use of On-Demand Staging.

When using On-Demand Staging, the RD Client pulls staging profiles directly from an On-Demand Profile Server over some form of pre-configured or automatically-configured IP connection.

For detailed information about the MSP 3.X, refer to the *Mobility Services Platform 3.X User's Guide*.

An MSP Administrator uses the MSP Console for the creation of an RD profile that contains all the wireless network and security information (for example, ESSID, WEP Keys, etc.) required to get a device onto the wireless network. The profile also contains FTP server access information needed to connect to the provisioning MSP and the list of software packages to be provisioned to the device from the provisioning MSP. The RD profile can then be encoded into an RD bar code sheet and printed from the MSP Console or loaded onto a profile server.




Figure 8-1 RD Bar Code Printout Sample

Bar Code Scanning

The *Rapid Deployment* window displays bar code scan status and provides features for resetting and exiting the application.

To access the *Rapid Deployment* window from the *Home* window, select *Config... > Rapid Deployment*.

The *Rapid Deployment* window displays bar code scan status and provides features for resetting and exiting the application.

To access the *Rapid Deployment* window:

1. Obtain the appropriate RD bar code sheet from the MSP Administrator.
2. Access the *Rapid Deployment* window from the *Home* window by selecting *Config... > Rapid Deployment*.
3. . The *Scan Barcodes To Deploy* window displays.




Figure 8-2 Waiting for Bar Codes

The RD Client waits for the first bar code scan.

4. Scan the first bar code. The window indicates which bar code to scan next.



NOTE Multi-part linear bar codes (1-D bar codes) can require scanning several bar codes. Bar codes can be scanned in any order. The display indicate the bar code to scan.




Figure 8-3 *Rapid Deployment Window*

5. After all the bar codes are scanned successfully, the device connects to the server and the *PROCESSING PROFILE* window displays while network settings are configured.




Figure 8-4 *Rapid Deployment Window - Processing Profile*

6. When staging is complete the *STAGING COMPLETE* window displays.



Figure 8-5 *Staging Complete Window*

7. Press the left function key to exit the **RD Client**.

On-Demand Staging

The MSP 3.X **RD Client** also enables staging without having to scan bar codes through the use of On-Demand Staging (Electronic Staging).

When using On-Demand Staging, the RD Client pulls staging profiles directly from an On-Demand Profile Server over some form of pre-configured or automatically-configured IP connection. The following types of IP connection modes are currently supported for Electronic Staging:

ActiveSync Connection Mode

This mode uses the IP connection that is established when the device is directly connected (via a USB cable or cradle) to a host computer running ActiveSync. The most common scenario would be where the On-Demand Profile Server is running on the host computer to which the device is connected via ActiveSync. It would, however, also work with the On-Demand Profile Server running on any other host computer that is on the same subnet as the host computer to which the device is connected via ActiveSync.

Ethernet Cradle Connection Mode

This mode uses the IP connection that is established when a device is inserted into an Ethernet cradle that is plugged into the Ethernet LAN. Some devices come ready to use with Ethernet cradles while others require software to be installed and configured before an Ethernet cradle connection can be established. The RD Client does not do anything to install Ethernet cradle software or configure or establish an Ethernet cradle connection, but does use one if it exists. The On-Demand Profile Server must be running on a host computer that is on the same subnet to which the Ethernet cradle is connected.

Already existing IP Connection Mode

This mode uses any IP connection that is already active on the device. This could be a direct Ethernet port (if available), or a WLAN connection that was configured and established before the **RD Client** was launched. It could also be any other form of IP connection that might be available on the device. The **RD Client** does not do anything to configure or establish such connections, but uses them if they exist. The On-Demand Profile Server must be running on a host computer that is on the same subnet that is accessible from the connection.

Well-known WLAN Connection Mode

This mode works only on supported Motorola WLAN adapters. The *RD Client* attempts to configure and establish WLAN IP connections using pre-defined Motorola WLAN settings. If the *RD Client* is able to successfully configure and establish such a connection, and if an On-Demand Profile Server is running on a host computer that is on the same subnet that is accessible from the connection, then Electronic Staging proceeds using that connection.

To perform On-Demand Staging:

1. In the *App Launcher* menu, press the center function key to launch the *RD Client*. The *Scan Barcodes To Deploy* window displays.




Figure 8-6 *Waiting for Bar Codes*

2. Press the left function key to select *Options*. The *Main Menu* window displays.




Figure 8-7 *RD Client Main Menu*

3. Use the up/down arrow keys to select *Search Network* and then press the center function key. The *SEARCHING NETWORKS* window displays.




Figure 8-8 *RD Client Searching for On-Demand Profile Server*

4. When complete, the *STAGING COMPLETE* window displays.




Figure 8-9 Staging Complete Window

Press the left function key to exit.

RD Client Main Menu

The RD Client **Main Menu** contains the following options:

- Search Network. See [On-Demand Staging on page 8-4](#) for detailed information.
- Scan Barcodes See [Bar Code Scanning on page 8-2](#) for detailed information.
- View Client Info
- Log Menu
- Package List
- Exit - Closes the RD Client application.




Figure 8-10 RD Client Main Menu

Client Info

Use the *Client Info* window to view the following information:

- RD Client version
- Product name
- Operating system type

- Plug-in type.

Select **View Client Info** option.




Figure 8-11 *Client Info Window*

Select **OK** to return to the **Main Menu**.

Log Menu

The **Log Menu** contains the following options:

- View Log
- View Job Log
- Set Log Level
- Set Job Log Level.

Select **Log Menu** option.




Figure 8-12 *Log Menu Window*

Select **OK** to return to the **Main Menu**.

View Log

Use the **View Log** option to display a list of events that have occurred.

Select **View Log** option.




Figure 8-13 *View Log Window*

Select **OK** to return to the **Log Menu**.

View Job Log

Use the **View Job Log** option to display a list of jobs that have been processed.

Select **View Job Log** option.




Figure 8-14 *View Job Log Window*

Select **OK** to return to the **Log Menu**.

Set Log Level

Use the **Set Log Level** option to set the level of the information that appears in the log.




Figure 8-15 *Set Log Level Window*

Select a level option.

Set Job Log Level

Use the **Set Job Log Level** option to set the level of the information that appears in the Job log.




Figure 8-16 *Set Job Log Level Window*

Select a level option.

Package List

Use the **Package List** option to display the packages that have been installed on the device.

Select the **Package List** option.




Figure 8-17 *Package List Window*

Select **OK** to return to the **Main Menu**.

Provisioning

The device supports two types of provisioning:

- MSP Agent
- AirBEAM Smart Client.

MSP Agent



NOTE MSP Agent is also known as MSP 3.X Provisioning Client.

The Provisioning Client replaces AirBEAM Client and is responsible for implementing device-side provisioning activities as defined by a policy. A policy is evaluated on the MSP 3.X system and delivered to devices as job documents via relay servers.

The MSP 3.X Provisioning Client is 100% backward compatible to prior versions of the AirBEAM Client. Existing AirBEAM Smart users can use the MSP 3.X Provisioning Client as a 100% backward compatible replacement for prior versions of AirBEAM client, when used in Classic AirBEAM mode with existing FTP servers.

Existing MSP 2.X users can use the new Provisioning Client as a 100% backward compatible replacement for previous versions of AirBEAM Client, when used in Level 2 Agent and Level 3 Agent modes with existing MSP 2.X Appliances.

For more detailed information on MSP Agent (Provisioning Client), refer to the *MSP 3.X User's Guide* (p/n 72E-100158-xx).

MSP Agent Main Menu

The MSP Agent **Main Menu** contains the following options:

- Monitoring Processing
- Force Check-In
- Package List
- View Client info
- Log Menu
- Hide UI
- Exit - exits the MSP Agent application.




Figure 8-18 MSP Agent Main Menu

Monitor Processing

Use the **Monitor Processing** option to view the status of packages being processed.

Select the **Monitor Processing** option.




Figure 8-19 Monitor Processing Window

Select **OK** to return to the **Main Menu**.

Force Check-In

Use the **Force Check-In** option to check instantly for pending package downloads instead of waiting for the next automatic check that the client performs.

Select the **Force Check-In** option.




Figure 8-20 *Force Check-in Window*

Select **OK** to return to the **Main Menu**.

Package List

Use the **Package List** option to display the packages that have been installed on the device.

Select the **Package List** option.




Figure 8-21 *Package List Window*

Select **OK** to return to the **Main Menu**.

Client Info

Use the *Client Info* window to view the following information:

- RD Client version
- Product name
- Operating system type
- Plug-in type.

Select *View Client Info* option.




Figure 8-22 *Client Info Window*

Select **OK** to return to the **Main Menu**.

Log Menu

The **Log Menu** contains the following options:

- View Log
- View Job Log
- Set Log Level
- Set Job Log Level.

Select **Log Menu** option.




Figure 8-23 *Log Menu Window*

Select **OK** to return to the **Main Menu**.

View Log

Use the **View Log** option to display a list of events that have occurred.

Select **View Log** option.




Figure 8-24 *View Log Window*

Select **OK** to return to the **Log Menu**.

View Job Log

Use the **View Job Log** option to display a list of jobs that have be processed.

Select **View Job Log** option.




Figure 8-25 *View Job Log Window*

Press the left function key to return to the **Log Menu**.

Set Log Level

Use the **Set Log Level** option to set the level of the information that appears in the log.




Figure 8-26 Set Log Level Window

Select a level option.

Set Job Log Level

Use the **Set Job Log Level** option to set the level of the information that appears in the Job log.




Figure 8-27 Set Job Log Level Window

Select a level option.

Hide UI

Use the **Hide UI** option to minimize the MSP Agent application. The MSP Agent application runs in the background while minimized.

To un-hide the application, select the **MSP Agent** icon in the task tray and select the **UnHide UI** menu item.

AirBEAM Smart Client

The AirBEAM Smart product allows specially designed software packages to be transferred between a host server and a device. Before transfer, AirBEAM Smart checks and compares package version, so that only updated packages are loaded.

AirBEAM Smart resides on the device and allows it to request, download and install software, as well as to upload files and status data. Both download and upload of files can be accomplished in a single communications session. The ability to transfer software over a wireless network can greatly reduce the logistical efforts of client software management.

In an AirBEAM Smart system, a network-accessible host server acts as the storage point for the software transfer. The AirBEAM Smart Client uses the industry standard FTP or TFTP file transfer protocols to check the host system for updates and, if necessary, to transfer updated software.

✓ **NOTE** For more detailed information about AirBEAM Smart, refer to the AirBEAM® Smart Windows® CE Client Product Reference Guide (p/n 72-63060-xx).

AirBEAM Package Builder

In a typical distributed AirBEAM system, software to be transferred is organized into packages. In general, an AirBEAM package is simply a set of files that are assigned attributes both as an entire package and as individual component files. The package is assigned a version number and the transfer occurs when an updated version is available.

An AirBEAM package can optionally contain developer-specified logic to be used to install the package. Installation logic is typically used to update client device flash images or radio firmware. Examples of common AirBEAM packages would include packages for custom client application software, radio firmware and AirBEAM Smart Client software.

Once these packages are built, they are installed on the host server for retrieval by the device. The AirBEAM Package Builder is a utility used to define, generate and install AirBEAM packages to a server. The packages are then loaded from the server onto a client device equipped with an AirBEAM Smart Client executable.

For detailed instructions on how to define, generate and install AirBEAM packages to the server, refer to the *AirBEAM Package Builder Product Reference Guide*, p/n 72-55769-xx.

AirBEAM Smart Client

The AirBEAM Smart Client is installed on the device. It is configured with the server access information, the names of the packages to be downloaded and other controlling parameters. When the AirBEAM Smart Client is launched, the device connects to the specified FTP server and checks the packages it is configured to look for. If the package version was updated, the client requests the transfer.

AirBEAM License

The AirBEAM Smart Client is a licensed software product. The AirBEAM Smart Client's version synchronization functionality is enabled through a license key file that is stored on the device. The license key file can be built into AirBEAM Smart Client's image, or downloaded in a special AirBEAM package.

The AirBEAM license key file contains a unique key and a customer specific banner that is displayed when the AirBEAM Smart Client version synchronization logic is invoked.

Configuring the AirBEAM Smart Client

1. On the device, navigate to the *ABClient.exe* file via *Utilities > File Explorer > Platform > AirBeam* folder.
2. Use the Up and Down *Scroll* key to select the *ABCLIENT.EXE* file and press *ENT* to run the AirBEAM client software. The AirBEAM Smart CE window displays.



Figure 8-28 AirBEAM Smart CE Window

3. Select *File > Configure*. The AirBEAM configuration window displays.



Figure 8-29 AirBEAM Configuration Window

The configuration window is used to view and edit AirBEAM Smart Client configurations. This dialog box has seven tabs that you can modify - Packages(1), Packages(2), Server, Misc(1), Misc(2), Misc(3) and Misc(4).

Packages(1) Tab

Use this tab to specify the package name of the first four of eight packages that are to be loaded during the AirBEAM synchronization process. The specified package name must correspond to a package that is available on the specified package server.




Figure 8-30 Package (1) Tab


Table 8-1 *Package (1) Tab Descriptions*

Field	Description
Package 1	Package name of the first of eight packages. This is an optional field.
Package 2	Package name of the second of eight packages. This is an optional field.
Package 3	Package name of the third of eight packages. This is an optional field.
Package 4	Package name of the fourth of eight packages. This is an optional field.

✓ **NOTE** No inadvertent trailing spaces should be entered on the Packages(1) tab. Information entered in these fields are case and space sensitive.

Packages(2) Tab

Use this tab to specify the package name of the last four of eight packages that are to be loaded during the AirBEAM synchronization process. The specified package name must correspond to a package that is available on the specified package server.

**Figure 8-31** *Package (2) Tab***Table 8-2** *Package (2) Tab Descriptions*

Field	Description
Package 5	Package name of the fifth of eight packages. This is an optional field.
Package 6	Package name of the sixth of eight packages. This is an optional field.
Package 7	Package name of the seventh of eight packages. This is an optional field.
Package 8	Package name of the eighth of eight packages. This is an optional field.
Upload Pkg	Package name of a package that is to be processed for “upload files” during the AirBEAM synchronization process. The specified package name must correspond to a package that is available on the specified package server. This is an optional field.

✓ **NOTE** No inadvertent trailing spaces should be entered on the Packages(2) tab. Information entered in these fields are case and space sensitive.

Server Tab

Use this tab to specify the configurations of the server to which the client connects during the package synchronization process.



Figure 8-32 Server Tab

Table 8-3 Server Tab Descriptions

Field	Description
IP Address	The IP Address of the server. It may be a host name or a dot notation format.
Directory	The directory on the server that contains the AirBEAM package definition files. All AirBEAM package definition files are retrieved from this directory during the package synchronization process.
User	The FTP user name that is used during the login phase of the package synchronization process.
Password	The FTP password that corresponds to the FTP user specified in the User field. The specified password is used during the login phase of the package synchronization process.



NOTE No inadvertent trailing spaces should be entered on the Server tab. Information entered in these fields are case and space sensitive.

Misc(1) Tab

Use this tab to configure various miscellaneous features.




Figure 8-33 Misc (1) Tab

Table 8-4 Misc(1) Tab Descriptions

Field	Description
Auto-load	<p>This drop-down list is used to specify how the AirBEAM Smart Client is to be invoked automatically when the client device is rebooted. The selections are:</p> <p>Disable: the AirBEAM Smart Client is not invoked automatically during the boot sequence.</p> <p>Interactive: the AirBEAM Smart Client is invoked automatically during the boot sequence. The package synchronization process is started automatically. The <i>Synchronization Dialog</i> box appears and the user is required to press the OK button when the process is complete.</p> <p>Non-interactive: the AirBEAM Smart Client is invoked automatically during the boot sequence. The package synchronization process is started automatically. The <i>Synchronization Dialog</i> box is displayed, but the user is not required to select OK when the process is complete. The <i>Synchronization Dialog</i> box terminates automatically.</p> <p>Background: the AirBEAM Smart Client is invoked automatically during the boot sequence. The package synchronization process is started automatically. Nothing is displayed while the synchronization process is occurring.</p>
RAM Management	<p>This check box specifies whether the automatic RAM management is enabled during the package synchronization process.</p> <p>If enabled, RAM management logic is invoked when there is not enough free disk space to download a package. The RAM management logic attempts to remove any discardable AirBEAM packages resident on the client.</p>
Suppress Separator	<p>This check box specifies whether the automatic insertion of a file path separator character should be suppressed when the client generated server package definition file names.</p> <p>When enabled, the parameter also disables the appending of .apd to the package. This feature is useful for AS/400 systems, in which the file path separator character is a period.</p> <p>When this feature is enabled, the server directory (Directory) and package name (Package 1, Package 2, Package 3 and Package 4) are appended “as is” when building the name for the server package definition file.</p> <p>When this feature is disabled, a standard file path separator is used to separate the server directory (Directory) and package name (Package 1, Package 2, Package 3 and Package 4) when building the name for the server package definition file. In addition, an .apd extension is appended automatically.</p>
TFTP	<p>This check box specifies whether the TFTP protocol is to be used to download files. By default, the AirBEAM Smart Client uses the FTP protocol.</p>
WNMS	<p>This check box specifies whether the AirBEAM Smart Client uploads a WNMS information file at the end of each version synchronization.</p>

Misc(2) Tab

This tab is used to configure various miscellaneous features.

**Figure 8-34** Misc (2) Tab

Table 8-5 *Misc(2) Tab Descriptions*

Field	Description
Auto-retry	<p>This field is used to specify whether the AirBEAM Smart Client automatically retries if there is a failure during the synchronization process.</p> <p>If this feature is enabled, the AirBEAM Smart Client displays a popup dialog indicating the attempt of a retry. The popup dialog is displayed for the number of seconds specified in the <i>Retry Delay</i> field.</p> <p>The valid values for this field are:</p> <ul style="list-style-type: none"> -1: the AirBEAM Smart Client automatically retries indefinitely. 0: the AirBEAM Smart Client does not automatically retry. -0: the AirBEAM Smart Client automatically retries up to the number of times specified.
Retry Delay	This field specifies the amount of time, in seconds, that the AirBEAM Smart Client delays before automatically retrying after a synchronization failure.
In-use Test	This check box specifies whether the AirBEAM Smart Client tests to determine if a file is in-use before downloading. If the <i>In-use Test</i> feature is enabled, the AirBEAM Smart Client downloads a temporary copy of any files that are in-use. If any temporary in-use files are downloaded the AirBEAM Smart Client automatically resets the client to complete the copy of the in-use files. If the <i>In-use Test</i> feature is disabled, the synchronization process fails (-813) if any download files are in-use.
Wait Welcome	This check box specifies whether the AirBEAM Smart Client waits for the <i>WELCOME</i> windows to be completed before automatically launching the synchronization process after a reset.
Close Apps	This check box specifies whether the AirBEAM Smart Client automatically attempts to close non-system applications prior to resetting the mobile unit. If enabled the AirBEAM Smart Client sends a WM_CLOSE message to all non-system applications before resetting the mobile unit. This feature offers applications the opportunity to prepare (i.e. close open files) for the pending reset.

Misc(3) Tab

Use this tab to configure various miscellaneous features.



**Figure 8-35** *Misc (3) Tab*

Table 8-6 Misc (3) Tab Descriptions

Field	Description
Use DHCP server	This check box control specifies whether the AirBEAM Smart Client uses the DHCP response option 66 to specify the <i>IP address</i> of the FTP/TFTP server. If enabled, special RF network registry settings are required to force the DHCP server to return the “TFTP server name” field (option 66). The special RF network registry settings are included, but commented out, in the radio network registry initialization files (essid_xxxx_yy.reg).
Use DHCP bootfile	This check box control specifies whether the AirBEAM Smart Client uses the DHCP response option 67 to specify the <i>Package</i> and <i>Package 1</i> parameters. If enabled, special RF network registry settings are required to force the DHCP server to return the “Bootfile name” field (option 67). The special RF network registry settings are included, but commented out, in the radio network registry initialization files (essid_xxxx_yy.reg).

Misc(4) Tab

Use this tab to configure various miscellaneous features.

**Figure 8-36** Misc (4) Tab**Table 8-7** Misc (4) Tab Descriptions

Field	Description
Sched Mode	Specifies whether (and how) the scheduled mode is enabled. If enabled, schedule mode causes the AirBEAM synchronization process to occur periodically. The selections are: Disable - The schedule mode is disabled. Fixed time - The schedule mode is enabled. The AirBEAM synchronization will be launched once per day at the time specified in the Sched Time setting. The synchronization will be launched every day Sched Time minutes past midnight. Fixed period - The schedule mode is enabled. The AirBEAM synchronization will be launched at a period by the Sched Time setting. The synchronization will be launched every Sched Time minutes.
Sched Time	This edit control specifies, in minutes, the period for the schedule mode. The Sched Mode setting specifies how the Sched Time value is used.

Table 8-7 Misc (4) Tab Descriptions (Continued)

Field	Description
Sched Load	<p>This drop-down menu specifies the load mode to be used for scheduled synchronization, if enabled. The selections are:</p> <p>Default - Specifies that the load mode specified in the Auto-load setting is to be used for scheduled synchronization sessions.</p> <p>Interactive - The Synchronization Dialog displays when a scheduled synchronization session occurs. The user is required to press the OK button to dismiss the dialog.</p> <p>Non-interactive - The Synchronization Dialog displays when a scheduled synchronization session occurs. The dialog is automatically dismissed when the synchronization is complete, unless an error occurs. If an error occurs the user is required to press the OK button to dismiss the dialog.</p> <p>Background - Nothing is displayed when the scheduled synchronization sessions occur.</p>
Sched Prompt	<p>Specifies whether the AirBEAM client prompts the user when updates are available in schedule mode. The settings are:</p> <p>Disable - Updated packages are automatically downloaded. The user is not prompted.</p> <p>Alert - Updated packages are not automatically downloaded. The user is prompted to warm boot the device to initiate the package downloads.</p> <p>Launch - Updated packages are not automatically downloaded. The user is prompted to start the package download. The user can defer the package download by responding no to the prompt. The MAXNOPRESS registry setting can be used to limit the number of times the user can defer the update.</p> <p>Confirm - Updated packages are not automatically downloaded. This value behaves the same as the Launch value, except that the user is required to confirm an additional prompt before the download starts.</p>

Synchronizing with the Server

When the synchronization process is initiated, the AirBEAM Smart Client attempts to open an FTP session using the AirBEAM Smart Client configuration. Once connected, the client processes the specified packages. Packages are loaded only if the server version of a given package is different from the version loaded on the client. Once the upload process is complete, the AirBEAM Smart Client closes the FTP session with the server.

The AirBEAM Smart Client can launch an FTP session with the server either manually, when initiated by the user, or automatically.

Manual Synchronization

1. Configure the AirBEAM Smart Client. See [Configuring the AirBEAM Smart Client on page 8-18](#).
2. From the main *AirBEAM CE* window, press **ALT - ALT** and select **Synchronize**.
3. Once connected, the *AirBEAM Synchronize* window displays.

**Figure 8-37** AirBEAM Synchronize Window

- The **Status List** displays status messages that indicate the progress of the synchronization process.
- Press **ENTER** to return to the Main Menu. This button remains inactive until the synchronization process is complete.
- Select **Retry** and press **ENTER** to restart the synchronization process. This button is activated only if there is an error during the synchronization process.

Automatic Synchronization

The AirBEAM Smart Client can be configured to launch automatically using the Misc(1) Preference tab (see [Misc\(1\) Tab on page 8-20](#)). When setting automatic synchronization, use the Auto-load drop-down list to specify how the AirBEAM Smart Client should be invoked automatically when the client device is rebooted. See [Misc\(1\) Tab on page 8-20](#) for instructions on enabling Auto Sync.

AirBEAM Smart Staging

The AirBEAM Smart staging support is intended to speed up and simplify the process of staging custom or updated operating software onto mobile devices directly from manufacturing. The staging support is part of the AirBEAM Smart CE Client that is integrated into the device.

The AirBEAM Smart support works by defaulting the AirBEAM Smart Client configuration to a known set of values and launching the AirBEAM Smart package download logic. A staging environment, including an RF network, FTP server and AirBEAM Smart packages must be setup. Ideally a staging network and server should be setup to match the default AirBEAM Staging client configuration.

The AirBEAM Smart staging utility is invoked by selecting the *Files* icon from the *Series 3000 Demo* screen, select *\Platform\AirBeam* and double select on the *abstage.lnk* file.

The AirBEAM Staging support provides several benefits:

- Many devices can be simultaneously loaded over the RF network.

The AirBEAM staging utility provides a simple single dialog user interface that is used to quickly start the software installation process.

Chapter 9 Maintenance and Troubleshooting

Introduction

This chapter includes instructions on cleaning and storing the device, and provides troubleshooting solutions for potential problems during device operation.

Maintenance

For trouble-free service, observe the tips that follow when using the device and its accessories.

MT20X0

- Do not scratch the screen of the device.
- Although the device is water and dust resistant, do not expose it to rain or moisture for an extended period of time. In general, treat the device as a pocket calculator or other small electronic instrument.
 - Do not clean the device or expose it to rain or moisture when the battery is removed. Without the battery, the device is not water/dust sealed.
- Do not drop the device or subject it to strong impact.
- Protect the device from temperature extremes. Do not leave it on the dashboard of a car on a hot day, and keep it away from heat sources.
- Do not store or use the device in any location that is extremely dusty, damp, or wet.
- Do not store or use the device with the auxiliary accessory cover off. Without the accessory cover, the device is not water/dust sealed.
- Do not use window cleaning solution. Use a soft cloth dampened with a 50/50 solution of isopropyl alcohol and water.
 - Do not allow the solution to form a pool of liquid anywhere on the screen or device.
 - Do not use a large amount of solution to cause the device to remain wet.
 - The display screen and scan window can often be cleaned with common office (Scotch) tape. Apply the tape to surfaces and then peel the tape away; in most cases the dirt can be removed along with the tape.

Battery

When batteries are stored over a year, battery cell manufacturers advise that some irreversible deterioration in overall battery quality may occur. To minimize this loss, they recommend storing batteries half charged in a dry, cool place between 41° and 77°F (5° and 25°C), the cooler the better, and removed from the equipment to prevent the loss of capacity. Batteries should be charged to half capacity at least once a year. In order to charge a battery to half capacity, take a fully discharged battery and charge it for 2 hours. If an electrolyte leakage is observed, avoid any contact with the affected area and properly dispose of the battery.

Cradles

- Although the cradles are water and dust resistant, do not expose them to rain or moisture for an extended period of time. In general, treat the cradles as you would a pocket calculator or other electronic instrument.
- Do not drop the cradles or subject them to strong impact.
- Protect the cradles from temperature extremes. Do not leave them in a car on a hot day, and keep them away from heat sources.
- Do not store or use the cradles in any location that is extremely dusty, damp, or wet.
- Use a soft cloth dampened with a 50/50 solution of isopropyl alcohol and water.
 - Do not allow the solution to form a pool of liquid anywhere in the cradle.
 - Do not use a large amount of solution to cause the cradles to remain wet.

Troubleshooting

MT20X0

Table 9-1 Troubleshooting the MT20X0

Problem	Possible Causes	Possible Solutions
The aiming pattern does not appear when pressing the trigger.	No power to the device.	If the configuration requires a power supply, re-connect the power supply.
	Incorrect host interface cable is used.	Connect the correct host interface cable.
	Interface/power cables are loose.	Re-connect cables.
	Device is disabled.	For IBM 468x mode, enable the device via the host interface. Otherwise, see the technical person in charge of scanning.
	Device is disabled.	For IBM 468x mode, enable the device via the host interface. Otherwise, see the technical person in charge of scanning.
	If using RS-232 Nixdorf B mode, CTS is not asserted.	Assert CTS line.
	Aiming pattern is disabled.	Enable the aiming pattern. Refer to the <i>MT2090/MT2070 User Guide</i> (p/n 72E-117859-xx) for more information.
Battery may be discharged.	Check the battery status. If the battery is discharged: <ol style="list-style-type: none"> Place the device in the charge only cradle with a 12V power supply. The device should power on. Attach a cable to the device and connect it to a PC. Wait 2 hours until the trickle charge completes (during this period the device appears to be inoperative). When the trickle charge completes, the device should power up. If the device does not power up, contact Motorola support.	
Device emits short low/short medium/short high beep sequence (power-up beep sequence) more than once.	The USB bus may put the device in a state where power to the device is cycled on and off more than once.	Normal during host reset.

Table 9-1 Troubleshooting the MT20X0 (Continued)

Problem	Possible Causes	Possible Solutions
Device emits aiming pattern, but does not decode the bar code.	Device is not programmed for the correct bar code type.	Program the device to read that type of bar code. Refer to the <i>MT2090/MT2070 User Guide</i> (p/n 72E-117859-xx) for more information.
	Bar code symbol is unreadable.	Scan test symbols of the same bar code type to determine if the bar code is defaced.
	The symbol is not completely inside aiming pattern.	Move the symbol completely within the aiming pattern.
	Scan window may be dirty.	Clean the scan window. See Maintenance on page 9-1 .
Device emits 4 short high beeps during decode attempt.	Device has not completed USB initialization.	Wait several seconds and scan again.
Device decodes bar code, but does not transmit the data to the host.	Device is not programmed for the correct host type.	Scan the appropriate host type programming bar code. See the chapter corresponding to the host type.
	Interface cable is loose.	Re-connect the cable.
	If the device emits 4 long low beeps, a transmission error occurred.	Set the device's communication parameters to match the host's setting.
	If the device emits 5 low beeps, a conversion or format error occurred.	Configure the device's conversion parameters properly.
If the device emits low/high/low beeps, it detected an invalid ADF rule.	Program the correct ADF rules. Refer to the <i>Advanced Data Formatting</i> section of the <i>User Guide</i> .	
Host displays scanned data incorrectly.	Device is not programmed to work with the host.	Scan the appropriate host type programming bar code.
		For RS-232, set the device's communication parameters to match the host's settings.
		For a Keyboard Wedge configuration, program the system for the correct keyboard type, and turn off the CAPS LOCK key.
Program the proper editing options (e.g., UPC-E to UPC-A Conversion).		
Device emits high/high/high/low beeps when not in use.	RS-232 receive error.	Normal during host reset. Otherwise, set the device's RS-232 parity to match the host setting.

Table 9-1 Troubleshooting the MT20X0 (Continued)

Problem	Possible Causes	Possible Solutions
Device emits low/high beeps during programming.	Input error or Cancel bar code was scanned.	Scan the correct numeric bar codes within range for the parameter programmed.
Device emits low/high/low/high beeps during programming.	Out of ADF parameter storage space.	Erase all rules and re-program with shorter rules.
Device emits a power-up beep after changing USB host type.	The USB bus re-established power to the device.	Normal when changing USB host type.
Device emits one high beep when not in use.	In RS-232 mode, a <BEL> character was received and Beep on <BEL> option is enabled.	Normal when Beep on <BEL> is enabled and the device is in RS-232 mode.

✓ **NOTE** If after performing these checks the device still experiences problems, contact the distributor or call Motorola Enterprise Mobility Support.

Single Slot Charge Only Cradle

Table 9-2 Troubleshooting the Single Slot Charge Only Cradle

Symptom	Possible Cause	Action
Charge LEDs do not light when device is inserted.	Cradle is not receiving power.	Ensure the power cable is connected securely to both the cradle and to AC power.
	Device is not seated correctly in the cradle.	Remove and re-insert the device into the cradle, ensuring it is correctly seated.
	Extreme battery temperature.	Battery does not charge if battery temperature is below 32°F (0°C) or above 104°F (40°C).
Device battery is not charging.	Device was removed from cradle or cradle was unplugged from AC power too soon.	Ensure cradle is receiving power. Ensure device is seated correctly. If a device battery is fully depleted, it can take up to four hours to fully recharge the Li-ion battery.
	Battery is faulty.	Verify that other batteries charge properly. If so, replace the faulty battery.
	Device is not fully seated in the cradle.	Remove and re-insert the device into the cradle, ensuring it is correctly seated.
	Extreme battery temperature.	Battery does not charge if battery temperature is below 32°F (0°C) or above 104°F (40°C).
During data communications, no data was transmitted, or transmitted data was incomplete.	Device removed from cradle during communications.	Replace device in cradle and retransmit.
	Incorrect cable configuration.	See the system administrator.
	Communications software is not installed or configured properly.	Perform setup as described in <i>Radio Communications</i> chapter of the <i>MT2070/MT2090 User Guide</i> .
Device does not boot when placed in the cradle.	The device's battery is discharged.	Normal behavior if the battery is severely discharged. The battery must charge at a reduced charge rate until the battery acquires sufficient charge to boot the device. This can take up to 2 hours, depending on the level of battery discharge. This can be avoided by powering the cradle with the optional external power supply.

Single Slot Charge Only Vehicle Mount

Table 9-3 Troubleshooting the Single Slot Charge Vehicle Mount Cradle

Symptom	Possible Cause	Action
Device battery charging LED does not light (when using the power converter).	Cradle is not receiving power.	Ensure cables to cradle and power converter are securely connected.
	Power converter fuse is blown.	Replace power converter fuse.
	Power converter is faulty.	Replace power converter.
Device's battery is not recharging.	Device was removed from the cradle too soon.	Replace the device in the cradle. If the device's battery is fully depleted, it can take four hours to fully recharge the battery.
	Device battery is faulty.	Replace the battery.
	Device was not placed correctly in the cradle.	Remove the device from the cradle, and re-insert. If the battery still does not charge, contact your System Administrator.
Device falls out of the cradle during vibrations.	Cradle latches are adjusted incorrectly.	Remove cradle from the shock absorbing plate by unscrewing 3 screws; check that the position of the wall mount conversion dial is set to the wall-mount position; reattach the cradle to the shock absorbing plate.
	Incorrect adapter cup.	Ensure the forklift cup is mounted.
Device does not boot when placed in the cradle.	The device's battery is discharged.	Normal behavior if the battery is severely discharged. The battery must charge at a reduced charge rate until the battery acquires sufficient charge to boot the device. This can take up to 2 hours, depending on the level of battery discharge. This can be avoided by powering the cradle with the optional external power supply.

Single Slot Charge Multi-interface

Table 9-4 Troubleshooting the Single Slot Charge Multi-interface Cradle

Symptom	Possible Cause	Action
Device emits a disconnect (short high-short low) beep sequence.	Device has disconnected from cradle because it is too far from the cradle.	Move closer to the cradle and listen for a reconnection beep (short low-short high).
	Device has disconnected from the cradle because the cradle has lost power or been placed in USB suspend mode.	Check power connections to cradle, and if using a USB cable, check to make sure PC has not entered a power save mode.
Device emits four long low beeps after scanning a bar code.	Interface/power cables to cradle are loose.	Ensure all cable connections are secure.
	Device is not paired to a cradle.	Scan the PAIR bar code on the cradle that is connected to the host that is to receive data.
	A transmission error was detected.	Ensure the cradle's communication parameters match the host's setting.
	Cradle has not completed USB initialization.	Wait several seconds and scan again.
Bar code is decoded, but data is not transmitted to the host.	Device not paired to host-connected cradle.	Pair the device to the cradle (using PAIR bar code on the cradle).
	Cradle not programmed for correct host interface.	Check device host parameters or edit options.
	Interface cable is loose.	Ensure all cable connections are secure.
	Cradle has lost connection to host.	In this exact order: disconnect power supply; disconnect host cable; wait three seconds; reconnect host cable; reconnect power supply; reestablish pairing.
Cradle is not sending bar code data.	Parameter settings were scanned prior to pairing.	Pair device prior to scanning settings.
	USB cable not detected.	Connect the USB cable prior to connecting the 12V power supply.

Table 9-4 Troubleshooting the Single Slot Charge Multi-interface Cradle (Continued)

Symptom	Possible Cause	Action
Scanned data is incorrectly displayed on the host.	Cradle host communication parameters do not match host's parameters.	Ensure proper host is selected.
		For RS-232, ensure the cradle's communication parameters match the host's settings.
		For a Keyboard Wedge configuration, ensure the system is programmed for the correct keyboard type, and the CAPS LOCK key is off.
		Ensure editing options (e.g., UPC-E to UPC-A conversion) are properly programmed.
Device falls out of the cradle in the wall mount position.	Cradle has an incorrect adapter cup.	Ensure the wall mount adapter cup is installed and not the desktop cup. See Mounting on page 2-10 .
	Cradle latches are adjusted incorrectly.	Remove cradle from the shock absorbing plate by unscrewing 3 screws; check that the position of the wall mount conversion dial is set to the wall-mount position; reattach the cradle to the shock absorbing plate.
Device does not boot when placed in the cradle.	The device's battery is discharged.	Normal behavior if the battery is severely discharged. The battery must charge at a reduced charge rate until the battery acquires sufficient charge to boot the device. This can take up to 2 hours, depending on the level of battery discharge. This can be avoided by powering the cradle with the optional external power supply.

Four Slot Charge Only Ethernet

Table 9-5 Troubleshooting the Four Slot Charge Only Ethernet Cradle

Symptom	Possible Cause	Action
Charge LEDs do not light when device is inserted.	Cradle is not receiving power.	Ensure the power cable is connected securely to both the cradle and to AC power.
	Device is not seated correctly in the cradle.	Remove and re-insert the device into the cradle, ensuring it is correctly seated.
	Extreme battery temperature.	Battery does not charge if battery temperature is below 32°F (0°C) or above 104°F (40°C).
Device battery is not charging.	Device was removed from cradle or cradle was unplugged from AC power too soon.	Ensure cradle is receiving power. Ensure device is seated correctly. If a device battery is fully depleted, it can take up to four hours to fully recharge the Li-ion battery.
	Battery is faulty.	Verify that other batteries charge properly. If so, replace the faulty battery.
	Device is not fully seated in the cradle.	Remove and re-insert the device into the cradle, ensuring it is correctly seated.
	Extreme battery temperature.	Battery does not charge if battery temperature is below 32°F (0°C) or above 104°F (40°C).
During data communications, no data was transmitted, or transmitted data was incomplete.	Device removed from cradle during communications.	Replace device in cradle and retransmit.
	Incorrect cable configuration.	See the system administrator.
	Communications software is not installed or configured properly.	Perform setup as described in the <i>Radio Communications</i> chapter of the <i>MT2070/MT2090 User Guide</i> .
Device falls out of the cradle in the wall mount position.	Cradle has an incorrect adapter cup.	Ensure the wall mount adapter cup is installed and not the desktop cup.
	Cradle latches are adjusted incorrectly.	Remove cradle from the shock absorbing plate by unscrewing 3 screws; check that the position of the wall mount conversion dial is set to the wall-mount position; reattach the cradle to the shock absorbing plate.

Four Slot Charge Only Cradle

Table 9-6 Troubleshooting the Four Slot Charge Only Cradle

Symptom	Possible Cause	Action
Charge LEDs do not light when device is inserted.	Cradle is not receiving power.	Ensure the power cable is connected securely to both the cradle and to AC power.
	Device is not seated correctly in the cradle.	Remove and re-insert the device into the cradle, ensuring it is correctly seated.
	Extreme battery temperature.	Battery does not charge if battery temperature is below 32°F (0°C) or above 104°F (40°C).
Device battery is not charging.	Device was removed from cradle or cradle was unplugged from AC power too soon.	Ensure cradle is receiving power. Ensure device is seated correctly. If a device battery is fully depleted, it can take up to four hours to fully recharge the Li-ion battery.
	Battery is faulty.	Verify that other batteries charge properly. If so, replace the faulty battery.
	Device is not fully seated in the cradle.	Remove and re-insert the device into the cradle, ensuring it is correctly seated.
	Extreme battery temperature.	Battery does not charge if battery temperature is below 32°F (0°C) or above 104°F (40°C).
During data communications, no data was transmitted, or transmitted data was incomplete.	Device removed from cradle during communications.	Replace device in cradle and retransmit.
	Incorrect cable configuration.	See the system administrator.
	Communications software is not installed or configured properly.	Perform setup as described in the <i>Radio Communications</i> chapter of the <i>MT2070/MT2090 User Guide</i> .
Device falls out of the cradle in the wall mount position.	Cradle has an incorrect adapter cup.	Ensure the wall mount adapter cup is installed and not the desktop cup.
	Cradle latches are adjusted incorrectly.	Remove cradle from the shock absorbing plate by unscrewing 3 screws; check that the position of the wall mount conversion dial is set to the wall-mount position; reattach the cradle to the shock absorbing plate.
Device does not boot when placed in the cradle.	The device's battery is discharged.	Normal behavior if the battery is severely discharged. The battery must charge at a reduced charge rate until the battery acquires sufficient charge to boot the device. This can take up to 2 hours, depending on the level of battery discharge. This can be avoided by powering the cradle with the optional external power supply.

Four Slot Spare Battery Charger

Table 9-7 Troubleshooting the Four Slot Spare Battery Cradle

Symptom	Possible Cause	Action
Charge LEDs do not light when batteries are inserted.	Cradle is not receiving power.	Ensure the power cable is connected securely to both the cradle and to AC power.
	Battery is not seated correctly in the cradle.	Remove and re-insert the battery, ensuring it is correctly seated.
	Extreme battery temperature.	Battery does not charge if battery temperature is below 32°F (0°C) or above 104°F (40°C).
Battery is not charging.	Battery was removed from cradle or cradle was unplugged from AC power too soon.	Ensure cradle is receiving power. Ensure battery is seated correctly. If a battery is fully depleted, it can take up to four hours to fully recharge the Li-ion battery.
	Battery is faulty.	Verify that other batteries charge properly. If so, replace the faulty battery.
	Battery is not fully seated in the cradle.	Remove and re-insert the battery into the cradle, ensuring it is correctly seated.
	Extreme battery temperature.	Battery does not charge if battery temperature is below 32°F (0°C) or above 104°F (40°C).

Cables

Table 9-8 *Troubleshooting the Cables*

Symptom	Possible Cause	Action
Device charge LED does not light when device is connected.	Cable is not receiving power.	Ensure the power cable is connected securely to both the cable and to AC power.
	Cable is not seated correctly in the device.	Remove and re-insert the cable into the device, ensuring it is correctly seated.
	Extreme battery temperature.	Battery does not charge if battery temperature is below 32°F (0°C) or above 104°F (40°C).
Device battery is not charging.	Device was removed from cable or cable was unplugged from AC power too soon.	Ensure cable is receiving power. Ensure device is seated correctly. If a device battery is fully depleted, it can take up to four hours to fully recharge the battery.
	Battery is faulty.	Verify that other batteries charge properly. If so, replace the faulty battery.
	Cable is not seated correctly in the device.	Remove and re-insert the cable into the device, ensuring it is correctly seated.
	Extreme battery temperature.	Battery will not charge if battery temperature is below 32°F (0°C) or above 104°F (40°C).
During data communication, no data was transmitted, or transmitted data was incomplete.	Cable removed from device during communication.	Reattach cable to device and retransmit.
	Incorrect cable configuration.	See the system administrator.
	Communication software is not installed or configured properly.	Perform setup as described in Chapter 3, ActiveSync .

Appendix A Specifications and Electrical Interfaces

Technical Specifications (Typical)

MT20X0

Table A-1 Typical Device Technical Specifications

Item	Description
Physical Characteristics	
Dimensions	7.8 in H x 3.1 in. W x 5.0 in. D 19.8 cm H x 7.8 cm W x 12.7cm D
Weight (with battery)	MT2070: 13.5 oz (382.7 g) MT2090: 13.7 oz (388.4 g)
Display	320 X 240 QVGA color graphic display
Cable Power	5Volts +10/-5% VDC @ 468 mA
Keypad	21-key single stroke numeric and shifted alpha; 4-way navigation button with two soft keys for application control
Color	Dark Gray
Performance Characteristics	
Operating System	Microsoft® Windows CE Core 5.0
Application Development	Motorola EMDK, MCL Designer V 3.0 (MT2070)
Environment	Microsoft Windows CE EMDK
Processor	IntelXScale PXA270 @312MHz
Memory	64MB/64MB
Battery	2400 mAh Li-Ion @3.7Vdc

Table A-1 Typical Device Technical Specifications (Continued)

Item	Description
Data Capture	
Options	4 configurations: 1D Laser, 1D/2D Imager, 1D/2D HD Imager, DPM Imager
Communication Interface	USB 2.0 Host and RS-232
User Environment	
Operating Temperature	-4° F to 122° F (-20° C to +50° C)
Storage Temperature	-40° F to 160° F (-40° C to 70° C)
Battery Charging Environment	32° F to 104° F (0° C to +40° C)
Humidity	5% to 95%, non-condensing
Drop Specifications	6 ft./1.8 m drop to concrete over the operating temperature range; 36 times (6 per side)
Tumble Specification	250 3.2 ft./1.0 m tumbles (500 drops)
Environmental Sealing	IP 54
ESD	+/- 15kVDC air discharge, +/- 8kVDC direct/indirect discharge
Wireless LAN Data Communications	
Radio	Tri-mode IEEE® 802.11°/b/g
Output Power	100mW US and international
Data Rates Supported	802.11b - 11MBPS, 802.11a - 54MBPS, 802.11g - 54MBPS
Antenna	Internal
Frequency Range	Country dependant: typically 2.4 to 2.5 GHz for 802.11b/g and 5.15 to 5.825GHz for 802.11a
Cordless Data Communications	
Bluetooth	2.4Ghz Class I radio - 300 ft open air
Symbology Decode Capability	
1D	UPC/EAN (UPCA/UPCE/UPCE1/EAN-8/EAN-13/JAN-8/JAN-13 plus supplements), ISBN (Bookland), Coupon Code, Code 39 (Standard, Full ASCII), UCC/EAN-128, ISBT-128 Concatenated, Code 93, Codabar/NW7, Code 11, MSI, I 2 of 5 (Interleaved 2 of 5 / ITF, Discrete 2 of 5), GS1 DataBar (Omnidirectional, Truncated, Stacked, Stacked Omnidirectional, Limited, Expanded, Expanded Stacked, Inverse), Base 32 (Italian Pharmacode)
2D	TLC-39, Aztec (Standard), Maxicode, DataMatrix/ECC 200 (Standard), QR code (Standard, Micro)
Postal	U.S. Postnet and Planet, U.K. Post, Japan Post, Australian Post, Netherlands KIX Code, Royal Mail 4 State Customer, upu fics 4 State Postal, USPS 4CB

Table A-1 Typical Device Technical Specifications (Continued)

Item	Description
PDF417	PDF417 (Standard, Macro), Composite Codes (CC-A,CC-B,CC-C)
DPM (MT2090-DP only)	Data Matrix marks applied by dot peening; laser etch, ink marks, chemical etch, inkjet mold, cast and thermal spray
Typical Working Distance	Refer to the <i>Decode Distances</i> section of the <i>MT2090/MT2070 User Guide</i> (p/n 72E-117859-xx).
Regulatory	
Electrical Safety	Certified to UL60950-1, CSA C22.2 No. 60950-1, EN60950-1
Laser Safety	EC Class 2/FDA Class II in accordance with IEC60825-1/EN60825-1
EMI/RFI	North American: FCC Part 2 (SAR), FCC Part 15 Subpart B - Class B, RSS210, EU: EN 301-489-1, 489-17
Peripherals & Accessories	
Cradles	Single slot charge only cradle Single slot multi-interface with Bluetooth cradle Single slot charge only forklift cradle Four slot charge only cradle with spare battery charging Four slot Ethernet charge only cradle with spare battery charging
Chargers	Four slot battery charger
Printers	Motorola approved printers
Other Accessories	Lanyard Belt holster Desk cup Intellistand
Printers	Supports Motorola approved third party printers

Single Slot Charge Only Cradle

Table A-2 *Typical single Slot Charge Only Cradle Technical Specifications*

Item	Description
Operating Temperature	-4°F to 122°F (-20°C to +50°C)
Storage Temperature	-40° to 158°F (-40°C to +70°C)
Battery Charging Temperature	32° to 104°F (0°C to +40°C)
Humidity	5% to 95% non-condensing at 122° F (50°C)
Power Supply	12V, 3.3A; p/n 50-14000-148R for fast charging
Electrostatic Discharge (ESD)	+/- 15 kV (air) (RH 50%); +/- 8 kV (contact)
Shock and Vibration	<p>Drop/Shock: 1 time per side (6 drops total of the same unit) from a height of 30 in. (0.76 m) to vinyl tiled concrete surface at 0°F (0°C), room and 104°F (+40°C) temperatures.</p> <p>Vibration: .02g²/Hz random, 20 Hz to 2 kHz, 4 Gs peak sine sweep, 20 Hz to 2 kHz</p> <p>Cargo/Packaged: Six (6) foot drop at 73°F (23°C), 5 Hz, Vibration < 20 lbs Vehicle stacking 96 in., 73°F (23°C), and 85% relative humidity</p>
Dimensions	9.06 in. L x 4.02 in. W x 3.15 in. H (230 mm L x 102 mm W x 80 mm H)
Weight	.71 lb (0.322 kg)
Interface	USB pass thru to device

Single Slot Charge Only Vehicle Cradle

Table A-3 Typical Single Slot Charge Only Vehicle Cradle Technical Specifications

Item	Description
Operating Temperature	-4°F to 122°F (-20°C to +50°C)
Storage Temperature	-40° to 158°F (-40° to 70°C)
Battery Charging Temperature	32° to 104°F (0° to 40°C)
Humidity	5% to 95% non-condensing at 122° F (50°C)
Power Supply	9V, 1A; p/n 50-14000-122R
Electrostatic Discharge (ESD)	+/-15 kV (air) (RH 50%); +/- 8 kV (contact)
Shock and Vibration	<p>Drop/Shock: 1 time per side (6 drops total of the same unit) from a height of 30 in. (0.76 m) to vinyl tiled concrete surface at 0°F (0°C), room and 104°F (+40°C) temperatures.</p> <p>Vibration: Operating 4 g's rms, .03g²/Hz, 20 Hz to 2 kHz Damage random 26g's, 20 Hz to 2 kHz</p> <p>Cargo/Packaged: Six (6) foot drop at 73°F (23°C), 5 Hz, Vibration < 20 lbs Vehicle stacking 96 in., 73°F (23°C), and 85% relative humidity</p>
Dimensions	9.06 in. L x 4.02 in. W x 3.94 in. H, without shock absorbing plate (230 mm L x 102 mm W x 100 mm H)
Weight	.72 lb (0.325 kg), without shock absorbing plate
Interface	USB pass thru to device

Single Slot Charge Multi-interface Bluetooth Cradle

Table A-4 Typical Single Slot Charge Multi-interface Bluetooth Cradle Technical Specifications

Item	Description
Operating Temperature	-4°F to 122°F (-20°C to +50°C)
Storage Temperature	-40° to 158°F (-40° to 70°C)
Battery Charging Temperature	32° to 104°F (0° to 40°C)
Humidity	5% to 95% non-condensing at 122° F (50°C)
Power Supply	12V, 3.3V; p/n 50-14000-148R for fast charging
Electrostatic Discharge (ESD)	+/-15 kV (air) (RH 50%); +/- 8 kV (contact)
Shock and Vibration	<p>Drop/Shock: 1 time per side (6 drops total of the same unit) from a height of 30 in. (0.76 m) to vinyl tiled concrete surface at 0°F (0°C), room and 104°F (+40°C) temperatures.</p> <p>Vibration: .02g²/Hz random, 20 Hz to 2 kHz, 4 Gs peak sine sweep, 20 Hz to 2 kHz</p> <p>Cargo/Packaged: Six (6) foot drop at 73°F (23°C), 5 Hz, Vibration < 20 lbs Vehicle stacking 96 in., 73°F (23°C), and 85% relative humidity</p>
Dimensions	9.06 in. L x 4.02 in. W x 3.15 in. H 230 mm L x 102 mm W x 80 mm H
Weight	.71 lb (0.322 kg)
Interface	Keyboard Wedge, USB, RS-232, IBM

Four Slot Charge Ethernet Cradle

Table A-5 *Typical Four Slot Charge Only Ethernet Cradle Technical Specifications*

Item	Description
Operating Temperature	32° to 104°F (0° to 40°C)
Storage Temperature	-40° to 158°F (-40° to 70°C)
Battery Charging Temperature	32° to 104°F (0° to 40°C)
Humidity	5% to 95% non-condensing at 122° F (50°C)
Power Supply	12V, 9A; p/n 50-14000-241R
Electrostatic Discharge (ESD)	RH 50%; +/- 8 kV (contact)
Shock and Vibration	<p>Bench Top Handling (non-operating): Using the cradle's side edge as a pivot point, opposite side raised to the height of 8 in. above table top or 45° to the bench surface. Raised edge released and dropped to the bench surface. Process performed 2 times for each of 4 edges for a total of 8 drops, room temperature only.</p> <p>Vibration: .02g²/Hz random, 20 Hz to 2 kHz, 4 Gs peak sine sweep, 20 Hz to 2 kHz</p> <p>Cargo/Packaged: Six (6) foot drop at 73°F (23°C), 5 Hz, Vibration < 20 lbs Vehicle stacking 96 in., 73°F (23°C), and 85% relative humidity</p>
Dimensions	15.23 in. L x 11.08 in. W x 3.58 in. H (386.8 mm L x 281.5 mm W x 91.0 mm H)
Weight	4.1 lb (1.87 kg)
Interface	10/100 Ethernet

Four Slot Charge Only Cradle

Table A-6 Typical Four Slot Charge Only Cradle Technical Specifications

Item	Description
Operating Temperature	32° to 104°F (0° to 40°C)
Storage Temperature	-40° to 158°F (-40° to 70°C)
Battery Charging Temperature	32° to 104°F (0° to 40°C)
Humidity	5% to 95% non-condensing at 122° F (50°C)
Power Supply	12V, 9A; p/n 50-14000-241R
Electrostatic Discharge (ESD)	+/-15 kV (air) (RH 50%); +/- 8 kV (contact)
Shock and Vibration	<p>Drop/Shock:</p> <p>Bench Top Handling (non-operating): Using the cradle's side edge as a pivot point, opposite side raised to the height of 8 in. above table top or 45° to the bench surface. Raised edge released and dropped to the bench surface. Process performed 2 times for each of 4 edges for a total of 8 drops, room temperature only.</p> <p>Vibration: .02g²/Hz random, 20 Hz to 2 kHz, 4 Gs peak sine sweep, 20 Hz to 2 kHz</p> <p>Cargo/Packaged: Six (6) foot drop at 73°F (23°C), 5 Hz, Vibration < 20 lbs Vehicle stacking 96 in., 73°F (23°C), and 85% relative humidity</p>
Dimensions	15.23 in. L x 11.08 in. W x 3.58 in. H (386.8 mm L x 281.5 mm W x 91.0 mm H)
Weight	4.1 lb (1.87 kg)
Interface	N/A

Four Slot Spare Battery Charger

Table A-7 Typical Four Slot Spare Battery Charger Technical Specifications

Item	Description
Operating Temperature	32° to 104°F (0° to 40°C)
Storage Temperature	-40° to 158°F (-40° to 70°C)
Battery Charging Temperature	32° to 104°F (0° to 40°C)
Humidity	5% to 95% non-condensing at 122° F (50°C)
Electrostatic Discharge (ESD)	+/-15 kV (air) (RH 50%); +/- 8 kV (contact)
Shock and Vibration	<p>Drop/Shock: 1 time per side (6 drops total of the same unit) from a height of 30 in. to vinyl tiled concrete surface at 0°F (0°C), room and 104°F (+40°C) temperatures.</p> <p>Vibration: .02g²/Hz random, 20 Hz to 2 kHz, 4 Gs peak sine sweep, 20 Hz to 2 kHz</p> <p>Cargo/Packaged: Six (6) ft drop at 73°F (23°C), 5 Hz, Vibration < 20 lbs Vehicle stacking 96 in., 73°F (23°C), and 85% relative humidity</p>
Dimensions	7.48 in. L x 4.96 in. W x 2.19 in. H (190.0 mm L x 126.0 mm W x 55.5 mm H)
Weight	0.69 lb (0.312 kg)

MT2000 Series Electrical Interface/Device Pin-Outs

Device Interface to Cradle




Figure A-1 Digital Cradle Contacts

✓ **NOTE** Contact numbers are sequentially numbered for reference only.

The device has five contacts for interfacing to a cradle. The signal descriptions in [Table A-9](#) are for reference only.

Table A-8 Device to Cradle Signal Contacts

Contact	Function	Description
1	High Voltage Power	Voltage input allowing the device to charge at full charge rate. Voltage = 12V typical.
2	COM In	RXD to device; one of the USB communication signals; a static level used to determine cradle type and insertion.
3	Ground	System ground.
4	COM Out	TXD from device; one of the USB communication signals; a static level used to determine cradle type and insertion.
5	Low Voltage Power	Voltage input from the host. Used only when higher voltage is not present. This is a reduced charge current supply. Voltage = 5V typical.

✓ **NOTE** Pin definitions are for reference only. Charge device only with Motorola cradles.

Device Interface to Cable




Figure A-2 Digital Connection Pins

The device has 10 pins for interfacing with a cable. The signal descriptions in [Table A-9](#) are for reference only.

Table A-9 Device to Cable Pin-outs

Pin	IBM	RS-232	Keyboard Wedge	USB
1	Reserved	Reserved	Reserved	Jump to Pin 6
2	Power	Power	Power	Power
3	Ground	Ground	Ground	Ground
4	IBM_A(+)	TxD	KeyClock	Reserved
5	Reserved	RxD	TermData	D +
6	IBM_B(-)	RTS	KeyData	Jump to Pin 1
7	Reserved	CTS	TermClock	D -
8	Reserved	Reserved	Reserved	Reserved
9	Reserved	Reserved	Reserved	Reserved
10	Reserved	Reserved	Reserved	Reserved

Auxiliary Connection

An auxiliary port above the device trigger allows for the attachment of accessories such as Checkpoint EAS or additional illumination.



NOTE The auxiliary port is not available on all configurations of the device.



IMPORTANT When the auxiliary port cover is removed, the device is no longer water/dust sealed and is more susceptible to ESD. Do not use or store a device without the auxiliary port cover in place, or an installed auxiliary device that provides its own water/dust seal for the device.

Table A-10 Auxiliary Signal Connectors

Signal	Name	Function
1	Module present	External module connects to GND. This enables battery to VCC.
2	TXD out	Output from module.
3	RXD in	Input to module.
4	RTS out	RTS out from module.
5	CTS in	CTS input to module.
6	GND	GND
7	VCC	Battery voltage. Module must convert to whatever it needs.
8	VCC	See above.
9	GND	GND
10	IO1	IRQ from module to Bulverde. Can be used as I/O.
11	IO2	Power_En to module to control power. Can be used as I/O.
12	IO3	I/O

Index

Numerics

28-key keypad mapping	1-7
802.11 ESSID	7-5

A

accessories	1-2
four slot spare battery charger	2-1
four slot USB cradle	2-23
single slot cradle	
LED indicators	2-9
single slot forklift charge only cradle	2-13
USB cradle	2-1
ActiveSync	
downloading files	5-1
installing	3-2
setting up a connection	3-2
adding programs	5-4
ad-hoc	7-6
ad-hoc networks	7-34
Advanced Encryption Standard	7-17
AES	7-17
AirBEAM	
Client	8-17
configuring	8-18
package builder	8-17
staging	8-25
synchronization with server	8-24
AirBEAM configuration	
Misc(1) tab	8-20
Misc(2) tab	8-21
Packages(2) tab	8-19
Server tab	8-19
ALT key	1-4
AP networks	7-34

authentication

EAP-TLS	7-8
LEAP	7-9
none	7-8
PEAP	7-9

B

batteries	
charging	1-13
battery	
inserting	1-12
power	1-12, 1-13, 2-8
belt holster	2-2
bluetooth	
ad-hoc mode	7-6
Bluetooth cradle	2-1
bullets	xv

C

cables	2-2
charging	
spare batteries	1-17
via USB	2-7
charging batteries	1-13
charging spare batteries	1-17
cleaning	9-1, 9-2
cold boot	1-14, 1-15, 6-15
contents	1-1
conventions	
notational	xv
country code	7-6
cradle	
diagram	2-4, 2-5, 2-6
supply power	2-7
cradles	

four slot	2-1, 2-15
four slot battery charger	2-1
four slot USB	2-23
single slot	2-1, 2-3
LED indicators	2-9
single slot forklift charge only	2-13
USB cradle	2-1
creating splash screen	6-14
CTRL key	1-4

D

DCP	i-xv, 4-1
components	4-3
installing	4-2
default gateway	7-19
Device Configuration Package	i-xv, 4-1
components	4-3
installing	4-2
DHCP	7-19
DNS	7-19, 7-20
downloading files	5-1

E

EAP-TLS	7-8
electrical interface	
scanner	A-10
EMDK for C	4-1, 4-5
encryption	
open system	7-17, 7-19
TKIP (WPA)	7-17
Enterprise Mobility Developer Kit for C	4-1, 4-5
error messages	6-10, 6-11
Ethernet cradle	2-1

F

file explorer	6-2
flash file system	6-14
downloading partitions	6-16
non-FFS partitions	6-16
IPL	6-16
splash screen	6-16
partitions	6-14
copyfile	6-15
regmerge	6-15
flash storage	6-14
forklift cradle	2-1
four slot battery charger	2-1
four slot cradle	2-1
four slot cradles	2-15
USB spare battery charger	2-1
four slot Ethernet cradle	2-1

four slot USB cradle	2-23
----------------------	------

G

gateway	7-20
guides	
cradle guide	xvi
forklift cradle guide	xvi
integrator guide	xvi
quick start guide	xvi
user guide	xvi

I

information, service	xvii
infrastructure	7-6
Initial Program Loader	6-16
installation, battery	1-12
installing development tools	4-5
Intellistand	2-2
interfaces supported	
via communication with a cradle	1-11
via communication without cradle	1-11
IP address	7-20
IP config	
DNS	7-20
gateway	7-20
IP address	7-20
subnet mask	7-20
WINS	7-20
IPL	6-16
error messages	6-11
error screen	6-11

K

keypad	
ALT	1-4
CTRL	1-4
left soft key	1-4
right soft key	1-4
keypad map	
1 f1 . , - /	1-7
2 f2 a b c	1-7
3 f3 d e f	1-7
4 f4 g h i	1-8
5 f5 j k l	1-8
6 f6 m n o	1-8
7 f7 p q r s	1-9
8 f8 t u v	1-9
9 f9 w x y z	1-9
alt leftsoft	1-10
blue key	1-10
ctrl rightsoft	1-10

- enter 1-10
 - esc backspace 1-10
 - home 0 space 1-10
 - orange key 1-10
 - scroll 1-10
 - tab asterisk 1-10
- L**
- lanyard 2-2
 - LEAP 7-9
 - LED indicators
 - four slot battery charger 2-25
 - four slot cradles 2-22
 - miscellaneous information 2-9
 - single slot charge only 2-9
 - single slot multi-interface 2-9
- M**
- maintenance 9-1
 - mode
 - 802.11 ESSID 7-5
 - ad-hoc 7-6
 - country 7-6, 7-7
 - infrastructure 7-6
 - operating 7-6
 - profile name 7-5
- N**
- notational conventions xv
- O**
- open system 7-17, 7-19
 - operating mode 7-6
- P**
- partitions
 - downloading 6-16
 - FFS 6-14
 - non-FFS 6-16
 - IPL 6-16
 - splash screen 6-16
 - parts of the mobile computer 2-17
 - PEAP 7-9
 - pin-outs
 - cradles A-10
 - scanner A-10
 - pinouts
 - auxiliary connectors A-12
 - scanner connectors to cable A-11
 - scanner connectors to cradle A-10
 - power
 - via USB 2-7
 - profile
 - create new 7-24
 - delete 7-24
 - edit 7-24
 - profile name 7-5
 - programs
 - adding 5-4
 - flash file system 6-14
 - provisioning 8-1
- R**
- remove Li-ion battery 1-16
 - resetting 1-15
- S**
- scanner
 - cold boot 1-14, 1-15, 6-15
 - reset 1-15
 - starting 1-12, 1-14
 - warm boot 1-15
 - scripts
 - creating 6-5
 - saving 6-5
 - service information xvii
 - setup
 - installing the cable 2-7
 - supplying power 2-7
 - signal connectors A-10, A-11, A-12
 - signal strength 7-26
 - single slot cradle
 - LED indicators 2-9
 - single slot cradles 2-3
 - single slot forklift charge only cradle 2-13
 - single slot forklift cradle 2-1
 - single slot multi-interface cradle 2-1
 - single slot USB cradle 2-1
 - soft keys 1-4
 - spare batteries
 - charging 1-17
 - spare battery
 - charging 1-17
 - spare battery charger 2-1
 - specifications A-1
 - Spectrum24 7-1
 - splash screen
 - creating 6-14
 - staging 8-1
 - starting the scanner 1-12, 1-14
 - static 7-19

subnet mask 7-20
suspend 1-16
system requirements 4-2

T

TCM

building hex image6-1, 6-6
creating script 6-5
defining properties 6-4
error messages 6-10
hex image download 6-7
saving script 6-5
starting 6-2
technical specifications A-1
TKIP (WPA) 7-17
troubleshooting 9-3

U

unpacking1-1, 2-2
 scanner 1-1
USB cradle 2-1
USB spare battery charger 2-1

W

warm boot 1-15
WINS7-19, 7-20

Glossary

Numeric

802.11/802.11abg. A radio protocol that may be used by the Symbol radio card.

A

Access Point. Access Point (AP) refers to Symbol's Ethernet Access Point. It is a piece of communications equipment that manages communications between the host computer system and one or more wireless terminals. An AP connects to a wired Ethernet LAN and acts as a bridge between the Ethernet wired network and IEEE 802.11 interoperable radio-equipped mobile units. The AP allows a mobile user to roam freely through a facility while maintaining a seamless connection to the wired network.

AirBEAM® Manager. AirBEAM® Manager is a comprehensive wireless network management system that provides essential functions that are required to configure, monitor, upgrade and troubleshoot the wireless network and its components (including networked devices). Some features include event notification, access point configuration, diagnostics, statistical reports, auto-discovery, wireless proxy agents and monitoring of access points and mobile units.

AirBEAM® Smart Client. AirBEAM® Smart Client is part of Symbol's AirBEAM® suite, which also includes AirBEAM® Safe and AirBEAM® Manager. The AirBEAM® Smart Client system uses the network accessible host server to store software files that are to be downloaded to the devices. The AirBEAM® Smart Client provides the devices with the "smarts" to request software from the host. It allows them to request, download and install software, as well as to upload files and status data. The AirBEAM® Smart Client uses the industry standard FTP or TFTP file transfer protocols to check the host system for updates, and if necessary, to transfer updated software. Most often, AirBEAM® Smart Client is used with wireless networks, but any TCP/IP connection can be used. For more information, refer to the AirBEAM® Smart Windows® CE Client Product Reference Guide (p/n 72-63060-xx).

AP. See **Access Point**.

Aperture. The opening in an optical system defined by a lens or baffle that establishes the field of view.

API. An interface by means of which one software component communicates with or controls another. Usually used to refer to services provided by one software component to another, usually via software interrupts or function calls

Application Programming Interface. See **API**.

ASCII. American Standard Code for Information Interchange. A 7 bit-plus-parity code representing 128 letters, numerals, punctuation marks and control characters. It is a standard data transmission code in the U.S.

Autodiscrimination. The ability of an interface controller to determine the code type of a scanned bar code. After this determination is made, the information content is decoded.

B

Bar. The dark element in a printed bar code symbol.

Bar Code. A pattern of variable-width bars and spaces which represents numeric or alphanumeric data in machine-readable form. The general format of a bar code symbol consists of a leading margin, start character, data or message character, check character (if any), stop character, and trailing margin. Within this framework, each recognizable symbology uses its own unique format. See **Symbology**.

Bar Code Density. The number of characters represented per unit of measurement (e.g., characters per inch).

Bar Height. The dimension of a bar measured perpendicular to the bar width.

Bar Width. Thickness of a bar measured from the edge closest to the symbol start character to the trailing edge of the same bar.

BIOS. Basic Input Output System. A collection of ROM-based code with a standard API used to interface with standard PC hardware.

Bit. Binary digit. One bit is the basic unit of binary information. Generally, eight consecutive bits compose one byte of data. The pattern of 0 and 1 values within the byte determines its meaning.

Bits per Second (bps). Bits transmitted or received.

Bluetooth Technology. A wireless protocol for exchanging data over short distances from fixed and mobile devices, creating personal area networks (PANs). It was originally conceived as a wireless alternative to RS-232 data cables. It can connect several devices, overcoming problems of synchronization.

bps. See **Bits Per Second**.

Byte. On an addressable boundary, eight adjacent binary digits (0 and 1) combined in a pattern to represent a specific character or numeric value. Bits are numbered from the right, 0 through 7, with bit 0 the low-order bit. One byte in memory is used to store one ASCII character.

Boot or Boot-up. The process a computer goes through when it starts. During boot-up, the computer can run self-diagnostic tests and configure hardware and software.

BOOTP. A protocol for remote booting of diskless devices. Assigns an IP address to a machine and may specify a boot file. The client sends a bootp request as a broadcast to the bootp server port (67) and the bootp server responds using the bootp client port (68). The bootp server must have a table of all devices, associated MAC addresses and IP addresses.

bps. See **Bits Per Second**.

Byte. On an addressable boundary, eight adjacent binary digits (0 and 1) combined in a pattern to represent a specific character or numeric value. Bits are numbered from the right, 0 through 7, with bit 0 the low-order bit. One byte in memory is used to store one ASCII character.

C

CDRH. Center for Devices and Radiological Health. A federal agency responsible for regulating laser product safety. This agency specifies various laser operation classes based on power output during operation.

CDRH Class 1. This is the lowest power CDRH laser classification. This class is considered intrinsically safe, even if all laser output were directed into the eye's pupil. There are no special operating procedures for this class.

CDRH Class 2. No additional software mechanisms are needed to conform to this limit. Laser operation in this class poses no danger for unintentional direct human exposure.

Character. A pattern of bars and spaces which either directly represents data or indicates a control function, such as a number, letter, punctuation mark, or communications control contained in a message.

Character Set. Those characters available for encoding in a particular bar code symbology.

Check Digit. A digit used to verify a correct symbol decode. The scanner inserts the decoded data into an arithmetic formula and checks that the resulting number matches the encoded check digit. Check digits are required for UPC but are optional for other symbologies. Using check digits decreases the chance of substitution errors when a symbol is decoded.

Codabar. A discrete self-checking code with a character set consisting of digits 0 to 9 and six additional characters: (- \$: / , +).

Code 128. A high density symbology which allows the controller to encode all 128 ASCII characters without adding extra symbol elements.

Code 3 of 9 (Code 39). A versatile and widely used alphanumeric bar code symbology with a set of 43 character types, including all uppercase letters, numerals from 0 to 9 and 7 special characters (- . / + % \$ and space). The code name is derived from the fact that 3 of 9 elements representing a character are wide, while the remaining 6 are narrow.

Code 93. An industrial symbology compatible with Code 39 but offering a full character ASCII set and a higher coding density than Code 39.

Code Length. Number of data characters in a bar code between the start and stop characters, not including those characters.

Cold Boot. A cold boot restarts a device and erases all user stored records and entries.

COM Port. Communication port; ports are identified by number, e.g., COM1, COM2.

Continuous Code. A bar code or symbol in which all spaces within the symbol are parts of characters. There are no intercharacter gaps in a continuous code. The absence of gaps allows for greater information density.

Cradle. A cradle is used for charging the terminal battery and for communicating with a host computer, and provides a storage place for the terminal when not in use.

D

DCP. See **Device Configuration Package**.

Dead Zone. An area within a scanner's field of view, in which specular reflection may prevent a successful decode.

Decode. To recognize a bar code symbology (e.g., UPC/EAN) and then analyze the content of the specific bar code scanned.

Decode Algorithm. A decoding scheme that converts pulse widths into data representation of the letters or numbers encoded within a bar code symbol.

Decryption. Decryption is the decoding and unscrambling of received encrypted data. Also see, **Encryption** and **Key**.

Depth of Field. The range between minimum and maximum distances at which a scanner can read a symbol with a certain minimum element width.

Discrete 2 of 5. A binary bar code symbology representing each character by a group of five bars, two of which are wide. The location of wide bars in the group determines which character is encoded; spaces are insignificant. Only numeric characters (0 to 9) and START/STOP characters may be encoded.

Discrete Code. A bar code or symbol in which the spaces between characters (intercharacter gaps) are not part of the code.

DRAM. Dynamic random access memory.

E

EAN. European Article Number. This European/International version of the UPC provides its own coding format and symbology standards. Element dimensions are specified metrically. EAN is used primarily in retail.

Element. Generic term for a bar or space.

EMDK. Enterprise Mobility Developer's Kit.

Encoded Area. Total linear dimension occupied by all characters of a code pattern, including start/stop characters and data.

ENQ (RS-232). ENQ software handshaking is also supported for the data sent to the host.

ESD. Electro-Static Discharge

ESN. Electronic Serial Number. The unique hardware number associated with a cellular device, which is transmitted to the system when the device communicates with the cellular system.

Ethernet. Ethernet communication port. Allows a wired interface to a radio network.

F

File Transfer Protocol (FTP). A TCP/IP application protocol governing file transfer via network or telephone lines. See **TCP/IP**.

Flash Disk. An additional megabyte of non-volatile memory for storing application and configuration files.

Flash Memory. Flash memory is responsible for storing the system firmware and is non-volatile. If the system power is interrupted the data is not be lost.

FTP. See **File Transfer Protocol**.

G

Gateway Address. An IP address for a network gateway or router. A device may be part of a subnet as specified by its IP address and Netmask. It can send packets directly to any node on the same subnet. If the destination node is on a different subnet, then the terminal sends the packet to the gateway first. The gateway determines how to route the packet to the destination subnet. This field is an option used by networks that require gateways.

H

Hard Reset. See **Cold Boot**.

Host Computer. A computer that serves other terminals in a network, providing such services as computation, database access, supervisory programs and network control.

Hz. Hertz; A unit of frequency equal to one cycle per second.

I

IDE. Intelligent drive electronics. Refers to the solid-state hard drive type.

IEC. International Electrotechnical Commission. This international agency regulates laser safety by specifying various laser operation classes based on power output during operation.

IEC (825) Class 1. This is the lowest power IEC laser classification. Conformity is ensured through a software restriction of 120 seconds of laser operation within any 1000 second window and an automatic laser shutdown if the scanner's oscillating mirror fails.

IEEE Address. See **MAC Address**.

Imaging Scanning . An integrated imager which uses digital camera technology to take a digital picture of a bar code, store the resulting image in memory and execute state-of-the-art software decoding algorithms to extract the data from the image.

Input/Output Ports. I/O ports are primarily dedicated to passing information into or out of the terminal's memory. Series 9000 scanners include Serial and USB ports.

Intercharacter Gap. The space between two adjacent bar code characters in a discrete code.

Interleaved 2 of 5. A binary bar code symbology representing character pairs in groups of five bars and five interleaved spaces. Interleaving provides for greater information density. The location of wide elements (bar/spaces) within each group determines which characters are encoded. This continuous code type uses no intercharacter spaces. Only numeric (0 to 9) and START/STOP characters may be encoded.

Interleaved Bar Code. A bar code in which characters are paired together, using bars to represent the first character and the intervening spaces to represent the second.

Internet Protocol Address. See IP.

I/O Ports. interface The connection between two devices, defined by common physical characteristics, signal characteristics, and signal meanings. Types of interfaces include RS-232 and PCMCIA.

IOCTL. Input/Output Control.

IP. Internet Protocol. The IP part of the TCP/IP communications protocol. IP implements the network layer (layer 3) of the protocol, which contains a network address and is used to route a message to a different network or subnetwork. IP accepts "packets" from the layer 4 transport protocol (TCP or UDP), adds its own header to it and delivers a "datagram" to the layer 2 data link protocol. It may also break the packet into fragments to support the maximum transmission unit (MTU) of the network.

IP Address. (Internet Protocol address) The address of a computer attached to an IP network. Every client and server station must have a unique IP address. A 32-bit address used by a computer on a IP network. Client workstations have either a permanent address or one that is dynamically assigned to them each session. IP addresses are written as four sets of numbers separated by periods; for example, 204.171.64.2.

IPX/SPX. Internet Package Exchange/Sequential Packet Exchange. A communications protocol for Novell. IPX is Novell's Layer 3 protocol, similar to XNS and IP, and used in NetWare networks. SPX is Novell's version of the Xerox SPP protocol.

IS-95. Interim Standard 95. The EIA/TIA standard that governs the operation of CDMA cellular service. Versions include IS-95A and IS-95B. See CDMA.

K

Key. A key is the specific code used by the algorithm to encrypt or decrypt the data. Also see, **Encryption** and **Decrypting**.

L

LAN. Local area network. A radio network that supports data communication within a local area, such as within a warehouse of building.

LASER. Light Amplification by Stimulated Emission of Radiation. The laser is an intense light source. Light from a laser is all the same frequency, unlike the output of an incandescent bulb. Laser light is typically coherent and has a high energy density.

Laser Diode. A gallium-arsenide semiconductor type of laser connected to a power source to generate a laser beam. This laser type is a compact source of coherent light.

Laser Scanner. A type of bar code reader that uses a beam of laser light.

LCD. See **Liquid Crystal Display**.

LED Indicator. A semiconductor diode (LED - Light Emitting Diode) used as an indicator, often in digital displays. The semiconductor uses applied voltage to produce light of a certain frequency determined by the semiconductor's particular chemical composition.

Light Emitting Diode. See **LED**.

Liquid Crystal Display (LCD). A display that uses liquid crystal sealed between two glass plates. The crystals are excited by precise electrical charges, causing them to reflect light outside according to their bias. They use little electricity and react relatively quickly. They require external light to reflect their information to the user.

M

MDN. Mobile Directory Number. The directory listing telephone number that is dialed (generally using POTS) to reach a mobile unit. The MDN is usually associated with a MIN in a cellular telephone -- in the US and Canada, the MDN and MIN are the same value for voice cellular users. International roaming considerations often result in the MDN being different from the MIN.

MIL. 1 mil = 1 thousandth of an inch.

MIN. Mobile Identification Number. The unique account number associated with a cellular device. It is broadcast by the cellular device when accessing the cellular system.

Misread (Misdecode). A condition which occurs when the data output of a reader or interface controller does not agree with the data encoded within a bar code symbol.

N

Nominal. The exact (or ideal) intended value for a specified parameter. Tolerances are specified as positive and negative deviations from this value.

Nominal Size. Standard size for a bar code symbol. Most UPC/EAN codes are used over a range of magnifications (e.g., from 0.80 to 2.00 of nominal).

NVM. Non-Volatile Memory.

O

ODI. See **Open Data-Link Interface**.

Open Data-Link Interface (ODI). Novell's driver specification for an interface between network hardware and higher-level protocols. It supports multiple protocols on a single NIC (Network Interface Controller). It is capable of understanding and translating any network information or request sent by any other ODI-compatible protocol into something a NetWare client can understand and process.

Open System Authentication. Open System authentication is a null authentication algorithm.

P

PAN. Personal Area Network. Using Bluetooth wireless technology, PANs enable devices to communicate wirelessly. Generally, a wireless PAN consists of a dynamic group of less than 255 devices that communicate within about a 33-foot range. Only devices within this limited area typically participate in the network.

Parameter. A variable that can have different values assigned to it.

PC Card. A plug-in expansion card for laptop computers and other devices, also called a PCMCIA card. PC Cards are 85.6mm long x 54 mm wide, and have a 68 pin connector. There are several different kinds:

- Type I; 3.3 mm high; use - RAM or Flash RAM
- Type II; 5 mm high; use - modems, LAN adaptors
- Type III; 10.5 mm high; use - Hard Disks

PCMCIA. Personal Computer Memory Card Interface Association. See **PC Card**.

Percent Decode. The average probability that a single scan of a bar code would result in a successful decode. In a well-designed bar code scanning system, that probability should approach near 100%.

PING. (Packet Internet Groper) An Internet utility used to determine whether a particular IP address is online. It is used to test and debug a network by sending out a packet and waiting for a response.

Print Contrast Signal (PCS). Measurement of the contrast (brightness difference) between the bars and spaces of a symbol. A minimum PCS value is needed for a bar code symbol to be scannable. $PCS = (RL - RD) / RL$, where RL is the reflectance factor of the background and RD the reflectance factor of the dark bars.

Programming Mode. The state in which a scanner is configured for parameter values. See **Scanning Mode**.

Q

Quiet Zone. A clear space, containing no dark marks, which precedes the start character of a bar code symbol and follows the stop character.

QWERTY. A standard keyboard commonly used on North American and some European PC keyboards. "QWERTY" refers to the arrangement of keys on the left side of the third row of keys.

R

RAM. Random Access Memory. Data in RAM can be accessed in random order, and quickly written and read.

Reflectance. Amount of light returned from an illuminated surface.

Resolution. The narrowest element dimension which is distinguished by a particular reading device or printed with a particular device or method.

RF. Radio Frequency.

ROM. Read-Only Memory. Data stored in ROM cannot be changed or removed.

ROM-DOS. The name of the licensed Disk Operating System loaded into the device's flash file system.

Router. A device that connects networks and supports the required protocols for packet filtering. Routers are typically used to extend the range of cabling and to organize the topology of a network into subnets. See **Subnet**.

RS-232. An Electronic Industries Association (EIA) standard that defines the connector, connector pins, and signals used to transfer data serially from one device to another.

S

Scan Area. Area intended to contain a symbol.

Scanner. An electronic device used to scan bar code symbols and produce a digitized pattern that corresponds to the bars and spaces of the symbol. Its three main components are:

1. Light source (laser or photoelectric cell) - illuminates a bar code.
2. Photodetector - registers the difference in reflected light (more light reflected from spaces).
3. Signal conditioning circuit - transforms optical detector output into a digitized bar pattern.

Scanning Mode. The scanner is energized, programmed and ready to read a bar code.

Scanning Sequence. A method of programming or configuring parameters for a bar code reading system by scanning bar code menus.

Self-Checking Code. A symbology that uses a checking algorithm to detect encoding errors within the characters of a bar code symbol.

Shared Key. Shared Key authentication is an algorithm where both the AP and the MU share an authentication key.

SHIP. Symbol Host Interface Program.

SID. System Identification code. An identifier issued by the FCC for each market. It is also broadcast by the cellular carriers to allow cellular devices to distinguish between the home and roaming service.

SMDK. Symbol Mobility Developer's Kit.

Soft Reset. See **Warm Boot**.

Space. The lighter element of a bar code formed by the background between bars.

Specular Reflection. The mirror-like direct reflection of light from a surface, which can cause difficulty decoding a bar code.

Start/Stop Character. A pattern of bars and spaces that provides the scanner with start and stop reading instructions and scanning direction. The start and stop characters are normally to the left and right margins of a horizontal code.

STEP. Symbol Terminal Enabler Program.

Subnet. A subset of nodes on a network that are serviced by the same router. See **Router**.

Subnet Mask. A 32-bit number used to separate the network and host sections of an IP address. A custom subnet mask subdivides an IP network into smaller subsections. The mask is a binary pattern that is matched up with the IP address to turn part of the host ID address field into a field for subnets. Default is often 255.255.255.0.

Substrate. A foundation material on which a substance or image is placed.

SVTP. Symbol Virtual Terminal Program.

Symbol. A scannable unit that encodes data within the conventions of a certain symbology, usually including start/stop characters, quiet zones, data characters and check characters.

Symbol Aspect Ratio. The ratio of symbol height to symbol width.

Symbol Height. The distance between the outside edges of the quiet zones of the first row and the last row.

Symbol Length. Length of symbol measured from the beginning of the quiet zone (margin) adjacent to the start character to the end of the quiet zone (margin) adjacent to a stop character.

Symbology. The structural rules and conventions for representing data within a particular bar code type (e.g. UPC/EAN, Code 39, PDF417, etc.).

T

TCP/IP. (Transmission Control Protocol/Internet Protocol) A communications protocol used to internetwork dissimilar systems. This standard is the protocol of the Internet and has become the global standard for communications. TCP provides transport functions, which ensures that the total amount of bytes sent is received correctly at the other end. UDP is an alternate transport that does not guarantee delivery. It is widely used for real-time voice and video transmissions where erroneous packets are not retransmitted. IP provides the routing mechanism. TCP/IP is a routable protocol, which means that all messages contain not only the address of the destination station, but the address of a destination network. This allows TCP/IP messages to be sent to multiple networks within an organization or around the world, hence its use in the worldwide Internet. Every client and server in a TCP/IP network requires an IP address, which is either permanently assigned or dynamically assigned at startup.

Telnet. A terminal emulation protocol commonly used on the Internet and TCP/IP-based networks. It allows a user at a terminal or computer to log onto a remote device and run a program.

TFTP. (Trivial File Transfer Protocol) A version of the TCP/IP FTP (File Transfer Protocol) protocol that has no directory or password capability. It is the protocol used for upgrading firmware, downloading software and remote booting of diskless devices.

Tolerance. Allowable deviation from the nominal bar or space width.

Transmission Control Protocol/Internet Protocol. See **TCP/IP**.

Trivial File Transfer Protocol. See **TFTP**.

U

UDP. User Datagram Protocol. A protocol within the IP protocol suite that is used in place of TCP when a reliable delivery is not required. For example, UDP is used for real-time audio and video traffic where lost packets are simply ignored, because there is no time to retransmit. If UDP is used and a reliable delivery is required, packet sequence checking and error notification must be written into the applications.

UPC. Universal Product Code. A relatively complex numeric symbology. Each character consists of two bars and two spaces, each of which is any of four widths. The standard symbology for retail food packages in the United States.

V

Visible Laser Diode (VLD). A solid state device which produces visible laser light.

W

WAN. Wide-Area Network. A radio network that supports data communication beyond a local area. That is, information can be sent across a city, state, or even nationwide.

Warm Boot. A warm boot restarts the device by closing all running programs. All data that is not saved to flash memory is lost.

Wireless Local Area Network (WLAN). See **LAN**.

Wireless Wide Area Network (WWAN). See **WAN**.

WNMP. (Wireless Network Management Protocol) This is Symbol's proprietary MAC layer protocol used for inter access point communication and other MAC layer communication.



MOTOROLA

Motorola, Inc.
One Motorola Plaza
Holtsville, New York 11742, USA
1-800-927-9626
<http://www.motorola.com/enterprisemobility>

MOTOROLA and the Stylized M Logo and Symbol and the Symbol logo are registered in the U.S. Patent and Trademark Office.
All other product or service names are the property of their registered owners.
© Motorola, Inc. 2009



72E-117858-03 Revision A - October 2009